



REPLACEMENT PARTS

Ref.			Ref.		
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
2	900439	KNOB	47	900435	POINTER
3	900400	PIN	48	1311035	STOP PIN
4	900432	V-BELT	49	1343767	PINION ASSY
5	900303	PULLEY COVER	50	1311034	PIN
6	1343740	SPEED CHART	51	1311037	LOCK SCREW
7	900415	DEC PLATE	52	1343770	DEPTH STOP
8	1246002	SCREW-CHEESE HD	54	900413	SCALE
9	1343304	WASHER-RUBBER	55	n 903302	BALL
10	1243407	RING-EXT RET	56	1343768	HANDLE ASSY
11	920-04-020-5335	BEARING-BALL	57	1246110	PIN-SPRING
12	1310046	SPACER	58	900436	THUMB SCREW
13	1310044	SLEEVE	59	1246133	SCREW
14	1310048	PULLEY	60	1310022	SLIDE ROD
15	1310047	NUT	61	1310021	SPRING
16	1340719	CLAMP	62	1246017	SCREW-HEX HD
17	1342455	SCREW-PAN HD	63	1243526	WASHER-FLAT
18	1343785	CORD INSULATOR	64	1345382	NUT-LOCK
19	1310055	SCREW-HEX SOC SET	65	900438	MOTOR PLATE
20	1310054	PULLEY	66	1246016	SCREW-HEX HD
21	902-01-020-1227	NUT-JAM	69	900302	MOTOR
22	1310084	SPRING W/HSG.	70	1343784	MOTOR JUMPER
23	1310035	RETAINER	71	1311072	POWER CORD
24	1343772	SPRING SEAT	72	900433	RING
25	900417	WARNING LABEL	73	1243321	SCREW-HEX SOC SET
27	1246133	SCREW-HEX SOC SET	74	900301	TABLE
28	1243398	NUT-HEX	75	1343716	SCREW-HEX HD
29	1343774	SCREW-HEX SOC SET	76	902-01-120-1034	NUT-HEX
30	1320101	WASHER-EXT TOOTH	77	1310013	THD. PIN
31	1310155	SCREW-CHEESE HD	78	1343747	PIN
32	1343778	SWITCH BOX	79	1310017	HANDLE
33	1246001	SCREW-CHEESE HD	80	1310016	SCREW-DRIVE
34	1343783	SWITCH PLATE	81	n 900959	SCALE
35	1310547	SCREW-PAN HD	82	1343786	WORM
36	1343758	KEY	83	1343754	PINION
37	1343759	SWITCH	84	1344257	HANDLE ASSY
38	900437	HEAD STOCK	85	1246014	SCREW-HEX HD
39	1310064	RING-EXT RET	86	1343735	RACK
40	1310039	WASHER-RUBBER	87	1343736	COLUMN W/FLANGE
41	1310041	BEARING-BALL	88	1246016	SCREW-HEX HD
42	1343775	QUILL	89	900300	BASE
43	1343776	SPINDLE	100	1311071	KEY
44	1310049	CHUCK	103	1243569	NUT-HEX
45	1313104	CHUCK KEY 1/2"	104	1320102	WASHER-EXT TOOTH
46	1310016	SCREW-DRIVE	105	1243501	SCREW-CHEESE HD
			106	n 900452	HARDWARE PACK

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Center for repair with damaged or missing standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department, your service outlet, or by visiting the Delta Website @ www.deltamachinery.com.