


31-122, 31-125, 31-126, 31-131 & 31-132 12" DISC FINISHING MACHINE

AFM-5C Part No 416-02-651-0007

Revised 3-3-99




REPLACEMENT PARTS

REF <u>NO</u>	PART NUMBER	DESCRIPTION
1		SELF ADHESIVE ABRASICE DISC
2	1085259	DISK ASSY, INCL:
3	901-03-030-0761	1/4-20 X 1/2" FLAT HD SCREW
4	901-04-190-0201	5/16-18 X 5/16" HEX SOC SET SCREW
7	416-02-091-0001	TILTING TABLE
*	416-02-395-0001	TRUNNION ASSY, CONST OF:
8	416-02-095-0001	TRUNNION
9	901-06-450-2250	#04 X 3/16" ROUND HD SCREW
10	951-02-010-7820	TILT SCALE
11	416-02-095-0001	TRUNNION
12	904-01-010-1614	FLAT WASHER
13	901-01-060-0612	1/4-20 X 5/8" HEX HD SCREW
14	406-03-138-0004	KNOB
15	928-01-021-4125	SPRING
16	904-01-031-2925	FLAT WASHER
17	416-02-327-0002	CLAMP W/ROLL PINS
18	420-01-075-0001	POINTER
19	901-02-010-0502	1/4-20 X 1/4" ROUND HD SCREW
20	420-01-111-0003	STUD
21	416-02-054-0003	GUARD
22	961-01-010-7499	HOLE PLUG
25	82-041	MOTOR - 115/230V, SINGLE PHASE
25	86-044	MOTOR - 230/460V, THREE PHASE
25	86-038	MOTOR - 200V, THREE PHASE
26	901-01-060-0607	5/16-18 X 3/4" HEX HD SCREW
27	904-01-010-1605	3/8" FLAT WASHER
28 30	904-10-031-2097	WASHER (For Use On 31-122 & 31-125 Models Only)
31	416-02-005-0003 904-02-020-1704	BASE 3/8" LOCK WASHER
32	901-01-060-0642	
32 34	31-123	3/8-16 X 1" HEX HD SCREW SUB BASE, INCL;
35	901-01-060-0645	3/8-16 X 3" HEX HD SCREW
36	904-01-010-1606	3/8" FLAT WASHER
37	406-03-137-0003	NAMEPLATE
37A	1087794	RIVET
38	52-346	SWITCH - SINGLE PHASE MANUAL PUSH BUTTON (For Use on 31-125 Models Only)
38	52-348	SWITCH - SINGLE & 3 PHASE PUSH BUTTON MAGNETIC CONTROL
		(For Use On 31-126, 31-131 & 31-132 Models Only)
**	52-704	SINGLE PHASE MOTOR STARTER (For Use On 31-126 Models Only)
**	52-702	THREE PHASE MOTOR STARTER (For Use On 31-126, 31-131 & 31-132 Models Only)
39	901-01-060-3118	5/16-18 X 3" HEX HD SCREW
40	904-02-010-1703	5/16" LOCK WASHER
41	904-01-010-1605	3/8" FLAT WASHER
45	416-02-314-0001	BRACKET (For Use On 31-126, 31- 131, & 132 Only)
**	406-00-752-0001	WARNING DECAL (For Use On 31-132 Models Only)

- NOT SHOWN ASSEMBLED
- ** NOT SHOWN

REPLACEMENT PARTS



- * NOT SHOWN ASSEMBLED
- ** NOT SHOWN

STANDARD SAFETY EQUIPMENT

438-01-011-0051 BUSHING INSULATOR

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.