



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	1087139	Table Insert	**	Cannot Furnish	Caster Set, Const. Of:
2	901-04-080-0101	1/4-20 X 1/4" Headless Set Scr.	70	1087225	Wheel
3	34-862	Extension Wing Assembly, Incl:	71	905-05-040-2107	1/8 X 3/4" Cotter Pin
4	901-01-060-0664	7/16-20 X 1" Hex Hd. Cap Scr.	72	904-01-010-1607	1/2 X 1-1/4 X 5/64" Washer
5	904-02-010-1716	7/16" Light Split Lockwasher	73	1087227	Bearing
6	1087157	Table	74	1087222	Bracket
7	904-01-010-1604	5/16 X 3/4 X 1/16" Flat Washer	75	1087224	Rod
8	901-01-060-0606	5/16-18 X 5/8" Hex Hd. Cap Scr.	76	901-01-060-0608	5/16-18 X 7/8 Hex Hd. Cap Scr.
9	1087166	Cabinet Assembly, Const. Of:	77	904-02-010-1703	5/16" Lockwasher
*	1087050	Side Panel	78	904-01-010-1604	5/16 X 3/4 X 1/16" Flat Washer
*	1087051	Support	79	902-01-010-1300	5/16-18 Hex Nut
*	1087484	Front Panel	101	931-02-011-9026	Knob
*	1087485	Rear Panel	102	904-07-010-5554	Fiber Washer
*	1087165	1/4-14 X 1/2 Screw	103	422-03-333-0002	Crank Assembly
10	422-03-389-0002	Support	104	1087170	Pointer Assembly, Incl:
11	901-02-050-0707	5/16-18 X 1" Fil Hd. Scr.	105	901-04-150-0208	1/4-20 X 1/4" Hex Soc. Scr.
12	904-01-010-1604	5/16 X 3/4 X 1/16" Flat Washer	106	426-03-388-0001	Collar Assembly, Incl:
13	902-01-010-1300	5/16-18 Hex Nut	107	901-04-150-0208	1/4-20 X 1/4" Hex Soc Scr.
14	1087052	Nameplate & Scale	108	1087160	Tilting Shaft w/Worm
15	0908459	Screw	109	905-01-010-2711	1/8 X 5/8" Roll Pin
16	1087086	Fence Bracket	110	904-07-010-5554	Fiber Washer
17	1087194	Miter Gage Bracket	111	1087233	Front Trunnion Bracket Ass'y.
18	424-01-014-0002	Switch Plate	112	901-01-060-0649	5/16-18 X 1" Hex Hd. Cap Scr.
19	422-16-055-0005	Front Guide Rail	113	904-01-030-1643	21/64 X 11/16 X 1/8" Washer
20	422-03-112-0003	5/16-18 Spec. Screw	114	1087081	Front Trunnion
21	422-16-104-0001	Spacer	115	422-02-088-0001	Stop Block
22	422-16-055-0004	Rear Guide Rail	116	901-04-120-0108	1/4-20 X 3/4" Headless Set Scr.
	422-16-343-0003	Rip Fence Complete, Const. Of:	117	902-01-120-1034	1/4"-20 Hex Nut
23	1087198	Front Clamp Block, Incl:	118	901-01-060-0612	1/4-20 X 5/8" Hex Hd. Cap Scr.
24	904-01-031-7720	21/64 X 1/2 X .032" Washer	119	904-01-010-1603	1/4 X 9/16 X 3/64" Flat Washer
25	1087212	Clamp Block	120	902-01-020-1226	5/8"-18 Hex Jam Nut
26	422-16-075-0003	Pointer	121	1087172	Tie Rod
27	901-02-010-0551	#10-32 X 1/2" Rd. Hd. Mach. Scr.	122	1087083	Guard
28	1087534	Kurled Knob	123	901-02-010-0514	1/4-20 X 5/16" Rd. Hd. Mach. Scr.
29	904-01-010-1603	1/4 X 9/16 X 3/64" Washer	124	904-02-020-1702	1/4" Lockwasher
30	901-01-060-9929	3/8-24 X 5/8" Hex Hd. Cap Scr.	125	905-01-010-2710	3/16 X 7/8" Roll Pin
31	904-01-030-1650	25/64 X 11/16 X 1/16" Washer	126	901-04-020-0301	1/4-20 X 1/2" Sq. Hd. Set Scr.
32	422-04-343-5001	Rip Fence	127	928-06-010-7381	Spring Washer
33	901-01-060-0612	1/4-20 X 5/8" Hex Hd. Cap Scr.	128	1087085	Spacer
34	904-01-010-1603	1/4 X 9/16 X 3/64" Steel Washer	129	422-02-105-0001	Eccentric
35	422-04-108-5001	Clamp Rod	130	1087168	Elevating Shaft w/Worm
36	422-04-010-5002	Rear Clamp Block	131	905-01-010-2711	1/8 X 5/8" Roll Pin
37	928-01-041-4118	Spring	132	904-07-010-5554	Fiber Washer
38	905-04-071-4459	1/4 X 51/64 Pin	133	1087087	Spacer
39	422-04-067-5001	Lever	134	1087082	Arbor Bracket
40	422-03-027-0001	Rear Clamp Hook	135	905-01-010-2710	3/16 X 7/8" Roll Pin
	1086434	Blade Guard, Const. Of:	136	952-01-101-3267	Arbor Bracket Shaft
41	1086334	"See-Thru" Guard	137	902-01-200-9848	5/8"-12 L.H. Hex Arbor Nut
42	1086351	Pin	138	422-04-103-5001	Flange
43	1086388	Push Nut (Cap)	139	34-105	10" Combination Blade
44	1086337	Pivot Bracket	140	422-03-303-0002	Arbor
45	422-16-071-0002	Pin	141	927-03-010-2655	3/16 X 3/16 X 7/8" Key
46	1086387	Push Nut	142	1086894	Bearing
47	422-16-047-0001	Kick Back Finger	143	422-02-104-0002	Spacer
48	1086353	Spring	144	928-06-020-7382	Load Spring
49	905-01-010-6729	5/32 X 11/16" Roll Pin	145	902-07-020-7176	Spanner Nut
50	1086350	Splitter Assembly	146	902-01-200-9847	Special Nut
51	901-01-060-0606	5/16-18 X 5/8" Hex Hd. Cap Scr.	147	41-023	5/8" Bore Arbor Pulley, Incl:
52	422-03-072-0001	Clamp Plate	148	901-04-150-0206	5/16-18 X 5/16" Hex Soc Set Scr.
53	422-04-014-5012	Bracket	149	1087079	Rear Trunnion
54	901-01-060-0622	1/4-20 X 2" Hex Hd. Cap Scr.	150	422-02-014-0010	Rear Trunnion Bracket
55	902-02-040-1303	1/4 X 9/16 X 3/64" Flat Washer	151	901-01-060-0649	5/16-18 X 1" Hex Hd. Cap Scr.
56	901-01-060-0603	1/4-20 X 7/8 Hex Hd. Cap Scr.	152	904-01-030-1643	21/64 X 11/16 X 1/8" Washer
	50-864	Miter Gage, Const. Of:	153	1087080	Motor Bracket Support
57	422-01-355-0004	Miter Gage Body	154	901-01-060-3112	1/2-13 X 2-1/4" Hex Hd. Cap Scr.
58	901-04-410-4561	1/4-28 X 1/4" Headless Set Scr.	155	904-02-020-1705	1/2" Lockwasher
59	901-02-050-0723	#8-32 X 1/2" Fil Hd. Scr.	156	901-04-150-1185	1/4-20 X 5/16" Soc. Set Scr.
60	902-01-200-1086	Special Hex Nut	157	1087477	Spring
61	931-02-010-1085	Handknob	158	1087163	Motor Plate
62	904-07-010-5555	Fiber Washer	159	422-03-108-0005	Motor Plate Rod
63	422-01-112-0001	Pivot Screw	160	1087173	Guard
64	422-01-304-0001	Guide Bar	161	901-01-060-0649	5/16-18 X 1" Hex Hd. Cap Scr.
65	901-07-261-3237	Stud	162	904-01-010-1604	5/16 X 3/4 X 1/16" Washer
66	951-01-041-3988	Pointer	163	904-03-030-1656	5/16" External Tooth Lockwasher
67	422-01-088-0002	Stop Link	164	902-01-010-1300	5/16"-18 Hex Nut
68	905-04-061-2351	Steel Pin	165	34-525	7/8" Open, 5/8" Hex Box Wrench
69	901-04-410-4561	1/4-28 X 1/4" Headless Set Scr.	*	49-273	V-Belt
			*	41-043	5/8" Bore Motor Pulley

* NOT SHOWN

** NOT INCLUDED WITH BASIC MACHINE

LITHO. U. S. A.