





REPLACEMENT PARTS

Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	1343375	SPECIAL SCREW
2	904-01-010-1605	3/8" FLAT WASHER
3	1343275	10.5MM WAVE WASHER
4	1343476	SCREW
5	1311003	M10-1.5 X 12MM HEX SOC SET SCREW
6	1343477	SPRING
7	1246197	BALL
8	899819	SCALE
9	1310016	DRIVE SCREW
10	899821	BASE, T2
	1343479	BASE, T1
11	1343480	TABLE
12	899822	TABLE INSERT
13	899823	FENCE
14	1246140	6.4MM FLAT WASHER
15	1243520	6MM LOCK WASHER
16	1243336	M6-1.0 X 20MM HEX SOC HD SCREW
17	1246104	M6-1.0 X 25MM HEX SOC HD SCREW
18	1243520	6MM LOCK WASHER
19	1246140	M6.4 FLAT WASHER
20	1246140	6.4MM FLAT WASHER
21	1243520	6MM LOCK WASHER
22	899824	LEVER
23	1343539	KNOB
24	1343484	PLUG
25	432-07-101-0004	5MM ALLEN WRENCH
26	1330154	2MM ALLEN WRENCH
27	1342906	1/2" BLADE WRENCH
28	1348257	WARNING LABEL, T2



REPLACEMENT PARTS


Ref.	No.	Part No.	Description
	29	1310016	DRIVE SCREW
	31	1246002	M6-1.0 X 12MM CHEESE HD SCREW
	32	1243520	6MM LOCK WASHER
	33	900406	SUPPORT PLATE ASSY, T2
		1343485	SUPPORT PLATE ASSY, T1, NOTE B
	34	900830	SCREW, T2
	35	900831	SCREW, T2
	36	1343486	SCREW
	37	1343487	BOLT
	38	899826	BRACKET, T2
		1343488	BRACKET, T1
	39	1343489	SPRING
	40	1341235	M4-0.7 X 12MM CHEESE HD SCREW
	41	1343490	STOP
	42	899833	UPPER BLADE GUARD, INCL., T2
		1343491	UPPER BLADE GUARD, INCL., T1, NOTE B
42A		1344359	WARNING LABEL (EMO)
42B		899829	NAMEPLATE, T2
		1344359	NAMEPLATE, T1
42C		1343546	NAMEPLATE (EMO)
42D		1344357	NAMEPLATE
43	n	893244	12MM FLAT WASHER
44		1343492	M12-1.75 LOCK NUT
45		900400	PIN, INCL., T2
		1343543	PIN, INCL., T1
46		1343544	SPRING
47		1343495	SCREW
48		1343496	8MM WASHER
49		900257	LEVER
50		1343540	M5-0.8 X 16MM CARRIAGE HD SCREW
51		899834	COVER, T2
		1343498	COVER, T1
52		1343541	SHOULDER SCREW
53		1343500	SPACER
54		1246102	5.3MM FLAT WASHER
55		900537	GUARD KIT, INCL.;
			Ref. 31, 33, 49, 50, 51, 52, 56, 59, & 60
56		1343502	SPRING
57		1310163	M5-0.8 X 16MM PAN HD SCREW
58		1343499	SCREW
59		899836	PLATE
60		1343504	M5 LOCK NUT
61		899837	BEVEL BRACKET, T2
		1343505	BEVEL BRACKET, T1
62		1343506	PIN
63		1343507	BLADE BOLT
65		1343508	BLADE FLANGE
66		OPTIONAL	BLADE , NOTE A
67		1243569	M4-0.7 HEX NUT
68		1341997	M4-0.7 X 20MM HEX SOC SET SCREW
69		900401	POINTER
70		1343545	4.1MM FLAT WASHER
71		1243501	M4-0.7 X 10MM CHEESE HD SCREW
72		900241	DUST BAG, INCL., T2
		36-044	DUST BAG, INCL., T1
73		1343511	CLAMP
74		1343510	ADAPTER
75		1243395	M5-0.8 HEX NUT
76		1344933	M5-0.8 X 20MM HEX SOC HD SCREW
77		899847	BEVEL SCALE, T2
77A		899845	WARNING LABEL, T2
77B		899827	WARNING LABEL, T2

EMO=EARLY MODELS ONLY

CMO=CURRENT MODELS

NOTE A: USE CROSS CUT BLADES ONLY! DO NOT USE BLADES DESIGNED FOR RIPPING, COMBINATION BLADES OR BLADES WITH EXCESSIVE HOOK ANGLES.

NOTE B: WHEN REPLACING T1 SUPPORT PLATE REF. 33 OR T1 UPPER BLADE GUARD REF. 42 USE BLADE GUARD KIT 900537 REF. 55.



REPLACEMENT PARTS

Ref.	No.	Part No.	Description
*		1343513	MOTOR, INCL.:
78		1310161	M4 X 18MM PAN HD SCREW
79		1243525	4.1MM LOCK WASHER
80		1343514	RETAINING PLATE
81		1343515	JACKSHAFT ASSY
87		1343259	NEEDLE BEARING
88		899840	HOUSING, T2
		1343516	HOUSING, T1
89		900407	ARBOR LOCK, T2
		1343517	ARBOR LOCK, T1
90		1313120	BEARING
91		1343518	FAN BAFFLE
92		1343519	ARMATURE
93		1343520	BEARING
94		1343932	M4.8 X 72MM PAN HD SCREW
95		1343538	5MM LOCK WASHER
96		1343521	5MM LOCK WASHER
97		1343522	FIELD
98		1343523	LEAD
99		438-01-007-0042	WIRE NUT
100		899841	SWITCH, T2
		1343524	SWITCH, T1
101		1343525	14.5MM WAVE WASHER
102		1343526	M4 X 16MM SELF TAP SCREW
103		1343527	CLAMP
104		1343528	CORD
105		1343529	LEAD
106		1343530	BRUSH HOLDER
107		1343531	BRUSH
108		1343532	BRUSH CAP
109		1343533	5MM LOCK WASHER
110		1343538	5MM LOCK WASHER
111		1341770	M5-0.8 X 72MM PAN HD SCREW
112		1343534	MOTOR HOUSING, INCL;
112A		1346967	WARNING LABEL
112C		1343548	INSULATION TAG, T1
113		1343535	M4-0.7 X 28MM PAN HD SCREW
114		1243525	4.1MM LOCK WASHER
115		1343536	HANDLE
116		899842	LOCK BUTTON, T2
		1343537	LOCK BUTTON, T1
117		1243569	M4-0.7 HEX NUT
118		899843	DEC PLATE, T2
*		NOT SHOWN ASSEMBLED EMO=EARLY MODELS ONLY CMO=CURRENT MODELS	

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Center for repair with damaged or missing standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department, your service outlet, or by visiting the Delta Website @ www.deltamachinery.com.