



REPLACEMENT PARTS

Ref.			Ref.		
No.	Part No.	Description	No.	Part No.	Description
1	898375	AIR TUBE	71	n 900668	DRIVE LINK
2	1330682	CLAMP	73	1343538	WASHER
3	1340243	SCREW	74	898469	SCREW
4	898376	AIR NOZZLE	75	898470	SCREW
5	898380	NUT	76	1343638	BUSHING
6	898381	BELLOWS CUP	77	899173	TABLE
7	898382	SPRING	78	1349887	SPACERS
8	898383	DIAPHRAGM	79	898479	PIN
9	898449	PLUG	80	n 900200	TABLE INSERT
10	898402	COVER	81	n 900211	INSERT
11	898403	NOSE	82	898456	TRUNNION
12	898466	SCREW	83	898459	KNOB
13	898450	POINTER	84	898460	WASHER
14	898404	MAGNET	85	898461	WASHER
15	898405	COVER	86	1246135	SCREW
16	898406	NOSE	87	898457	TRUNNION GLIDE
17	898467	SCREW	88	1246098	SCREW
18	1243501	SCREW	89	898427	SUPPORT
19	1243525	WASHER	90	898462	ANGLE SCALE
20	1243570	SCREW	91	898428	RIVET
21	898407	SCREW	92	898471	SCREW
22	898408	BOX	93	898429	BRACKET
25	898451	PLUG	94	898472	SCREW
26	898452	KNOB	95	898463	WASHER
27	898453	ROD	96	898464	WASHER
28	898454	BRACKET	97	898465	COLLAR
29	1243339	SCREW	98	1341856	SCREW
30	898480	FOOT	99	898430	BASE
31	1310062	WASHER	100	1246017	SCREW
32	1243520	WASHER	101	1246157	WASHER
33	1347291	SCREW	102	898431	MOTOR SUPPORT
34	898411	UPPER ARM	103	898432	SCREW
35	898455	LINK	104	1310216	WASHER
36	1343623	SCREW	105	1246124	SCREW
37	898468	SCREW	106	1243456	NUT
38	1340311	WASHER	107	898473	SCREW
39	1342242	COVER	108	898433	COVER
40	1342241	SUPPORT	109	1246117	SCREW
41	902011205432	NUT	110	898434	KNOB A
42	1342245	LINK	111	898435	SPRING
43	1330670	RETAINING RING	112	898474	WASHER
44	1342246	SHAFT	113	898436	SLIDE BAR
45	1340302	WASHER	114	898437	DUST BOX
46	1340303	SPRING	115	898438	COVER
47	n 900382	TENSION LEVER	116	898439	SLIDE BAR
48	1342253	PIN	117	1347527	SCREW
49	1344032	RETAINING RING	118	898997	MOTOR
50	1342308	SPRING	119	899174	CIRCUIT BOARD
51	1342256	SPACER	120	898475	STRAIN RELIEF
52	1347103	SCREW	121	898440	SWITCH BOX
53	1346120	BLADE CLAMP	122	898476	SCREW
54	1346124	CAM	123	898441	KNOB
55	1346121	PAD	124	1343759	SWITCH
56	1346122	SPRING	125	400060680002	SWITCH KEY
57	1347101	SPRING	126	898481	CORD
58	1346123	BUSHING	127	1341198	WIRE NUT
59	1346119	NUT	128	898477	WASHER
60	898412	LOWER ARM	129	901020100525	SCREW
61	1343659	NUT	131	n 900383	PLATE-DEC
62	898413	BOLT	132	898823	WARNING LABEL
63	898414	WASHER	133	898999	CAPACITOR
64	898415	WASHER	134	899175	VS SWITCH
65	1344954	WASHER	135	n 900385	LABEL
66	898416	COUNTER BALANCE	136	899658	LABEL
67	898424	SCREW	137	899699	FUSE HOLDER ASSY, INCL.: 138
68	1330410	PIN	138	899697	FUSE
69	1344047	PIN			
70	1343635	BUSHING			

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product which is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.