

REPLACEMENT PARTS

Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	438-01-302-0712	POWER CORD
2	410-09-752-0014	LABEL
3	438-01-004-0106	BUSHING
4	901-03-040-8015	1/4-20 X 1/2" HEX SOC HD SCREW
5	904-02-020-1702	1/4" LOCK WASHER
6	410-10-372-0001	HOUSING END CAP, INCL:
7	410-09-752-0017	WARNING LABEL
9	901-06-143-1848	08-18 X 3/8" PAN HD SCREW
10	410-10-054-0001	OUTLET GUARD
11	901-05-213-1498	10 X 1/2" HEX WASHER HD SCREW
12	410-09-331-0006	CONTROL PANEL ASSY, INCL:, REF. 1, 2, & 3
13	902-01-133-1529	1/4-20 FLANGED NUT
14	438-01-029-0027	CAPACITOR
*	410-10-440-0002	BLOWER ASSY, INCL:, REF. 15, 16, 17, 18 & 20
15	410-09-752-0018	WARNING LABEL
16	901-02-763-1515	1/4-20 X 5/8" HEX WASHER HD SCREW
17	904-03-030-1757	1/4" EXT TOOTH WASHER
18	410-10-131-0001	MOTOR ASSY
19	400-06-416-0002	WEATHER STRIP
20	410-10-440-0004	FAN ASSY, INCL:
21	901-04-020-0308	5/16-18 X 3/4" SQ HD SET SCREW
23	438-01-004-0054	TIE STRAP
24	901-11-323-1781	EYEBOLT
25	902-01-133-1529	1/4-20 FLANGE NUT
26	901-03-040-8015	1/4-20 X 1/2" HEX SOC SCREW
27	410-09-331-0004	COVER ASSY W/INSERTS, INCL:
28	410-09-063-0001	HANDLE
29	410-09-752-0015	NAMEPLATE
30	410-09-016-0002	RUBBER BUMPER
32	50-823	5 POCKET INTERNAL FILTER
33	50-822	DISPOSABLE PLEATED FILTER
34	410-09-160-0001	REMOTE, INCL:
35	410-09-752-0016	LABEL
36	901-02-453-1123	10-32 X 5/8" PAN HD SCREW
37	902-01-293-1513	10-32 HEX NUT
38	n 400-06-416-0001	GASKET

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.

