



REPLACEMENT PARTS

Ref.	No.	Part No.	Description
	1	908680	POWER CORD
	2	410-09-752-0014	CONTROL PANEL LABEL
	3	438-01-004-0063	BUSHING
	4	908528	3/16"X 3/8" SCREW
	5	908008	CONTROL PANEL , INCL.: REF. 1, 2, & 3
	6	901-01-060-0612	1/4"-20 X 5/8" SCREW
	7	895447	1/4" LOCK WASHER
	8	907375	HOUSING END CAP, INCL.: REF. 11, 12, 15 &
	9	898939	M4.2 X 12 MM PAN HEAD SCREW
	10	908529	3/16" NUT
	11	400-06-416-0001	SEAL
	12	410-09-054-0001	OUTLET GUARD
	13	906762	FAN , INCL.: REF. 14
	14	1346143	M8 X 16MM SCREW
	15	410-09-752-0017	WARNING LABEL
	16	1349903	M5 FLANGED NUT
	17	906761	MOTOR BASE
	18	895362	1/4-20 X 1" SCREW
	19	894513	1/4" FLAT WASHER
	20	907006	SPACER
	21	907378	MOTOR, INCL.:
	*	907377	CAPACITOR
	22	902-01-133-1529	1/4"-20 FRINGE NUT
	23	907379	BLOWER , INCL.: REF. 13, 14, 16, 17, 18, 19, 20, 21 & 24
	24	410-09-752-0018	WARNING LABEL
	25	908531	BRACKET
	26	908537	DEFLECTOR
	27	908538	5/16" EYEBOLT
	28	908532	5/16-18 FLANGED NUT
	29	1245142	5/16"-18 X 3/4" RD HD SCREW
	30	906764	HANDLE
	31	908539	CABINET ASSY., INCL.: REF. 28, 29, 30, 32, 33, 36, 37, & 39
	32	907380	NAME PLATE
	33	908493	INDICATOR LABEL
	34	908533	INDICATOR
	35	908534	M3 X 12MM HEX HD SCREW
	36	908535	INDICATOR PANEL
	37	898939	M4.2 X 12MM PAN HEAD SCREW
	38	410-09-016-0002	RUBBER BUMPER
	39	400-06-416-0001	SEAL
	40	50-859	FILTER
	41	50-865	FILTER
	42	907382	REMOTE CONTROL
	43	n 907374	HARDWARE PACK
	*		NOI SHOWN

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.