



REPLACEMENT PARTS

Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	913070	PANEL
1A	912787	DEC PLATE
2	901-11-323-1781	EYEBOLT
3	902-01-133-1529	FLANGE NUT
4	913071	CONNECTOR TUBE HANGER
5	913072	CONNECTOR TUBE
6	913092	CORNER PROTECTORS
7	913073	END PANEL
8	50-877	5 MICRON FILTER
9	1246164	SCREW
10	913075	MOTOR BASE
11	913095	FILTER CLIP
13	913076	HINGE
14	913077	LAMP DOOR
15	913078	WINDOW LAMP
16	913079	CABINET LAMP PANEL
20	913082	MOTOR
21	913083	BLOWER WHEEL
24	913085	LAMP BASE / PLATE
25	1349832	SCREW
27	1341624	FLANGE NUT
28	913087	BLOWER HOUSING
29	410-09-054-0001	OUTLET GUARD
30	913088	CABINET EXHAUST PANEL
31	901-03-040-8015	SCREW
33	438-01-004-0100	BUSHING
34	438-01-302-0691	CORD
36	410-09-752-0017	WARNING LABEL
37	410-09-752-0018	BLOWER WARNING LABEL
38	1310162	SCREW
40	1349904	SCREW
41	50-878	PRE-FILTER
43	913090	PULL SWITCH
44	913091	PULL SWITCH NUT
45	912220	HARDWARE PACK

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Center for repair with damaged or missing standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department, your service outlet, or by visiting the Delta Website @ www.deltamachinery.com.