




# REPLACEMENT PARTS

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	902581	M6 X 80MM CARRIAGE HD SCR	53	1320074	LEFT HAND NUT
3	1340608	FLAT WASHER	56	1320125	POWER CORD
4	902582	M6 KNOB	58	1320101	EXT TOOTH WASHER
5	902583	SPACER	59	1310057	STRAIN RELIEF
6	902584	RIGHT SPARK BREAKER	61	1320211	PLATE
7	1320090	FLAT WASHER	62	902643	M4 X 8MM PAN HD SCREW
8	1340609	HEX HD SCREW	63	902644	DRESSER HOLDER
9	1320003	TRUSS HD SCREW	64	23-006	WHEEL DRESSER
10	1320832	COVER	65	902645	WRENCH HOLDER
11	1320075	NUT-HEX	66	902590	WRENCH OPEN END 10MMX12MM
12	1320201	HEX NUT	67	902646	BASE
13	23-684	60G GRINDING WHEEL	68	n 912837	LIGHT ASSY
15	902585	R. H. WHEEL GUARD	69	900843	LAMP WARNING LABEL
16	900839	ROTATIONAL LABEL	70	1343759	SWITCH
17	1320005	TRUSS HD SCREW	71	1343758	KEY
18	902631	R. H. TOOL REST SUPPORT	72	1246007	HEX SOC SET SCREW
19	902632	RIGHT TOOL REST	73	1342734	KNOB
20	904-01-010-1604	FLAT WASHER	75	902647	VARIABLE SPEED LABEL
21	902633	5/16-18 KNOB	76	902648	SWITCH PLATE
23	901-01-060-0606	HEX HD SCREW	77	904-02-020-1702	LOCK WASHER
24	1340644	ROUND HD SCREW	78	902-01-120-1034	HEX NUT
25	902634	END BELL	79	902649	CAPACITOR
26	902635	M4X5MM HEX SOC HD SCREW	81	1320160	CLAMP
27	902636	PLATE	82	902650	CURCUIT BOARD ASSEMBLY
28	902637	SENSOR ASSEMBLY	83	1343545	FLAT WASHER
29	902638	M3 X 6MM RD HD SCREW	84	1344955	PAN HD SCREW
31	905848	WARNING & DEC PLT	85	1320217	PAD
38	902586	LEFT SPARK BREAKER	86	1320087	FLAT WASHER
43	902640	LEFT TOOL REST	87	901-02-010-0525	ROUND HD SCREW
44	902641	L. H. TOOL REST SUPPORT	88	902651	BASE COVER
48	902587	L. H. WHEEL GUARD	89	901911	EYESHIELD
51	902642	60G GRINDING WHEEL	90	901919	EYE SHIELD HDWE PACK
			91	901921	TOOL REST HDWE PACK



## STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

*This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.*