



## Receiver and Snap-In Spreader Assembly Instructions

**▲WARNING:** To reduce risk of injury, user must read instruction manual before using this accessory.

**▲WARNING:** To reduce the risk of serious personal injury, turn tool off and disconnect tool from power source before installing and removing accessories, before adjusting or changing set-ups or when making repairs. An accidental start-up can cause injury.

**▲WARNING:** This spreader is designed to be used in conjunction with an overarm blade guard system.

The following steps will assist you in the proper installation of the Receiver and the Snap-In Spreader on your table saw.

Step 1: Remove the saw blade from your table saw. If your table saw has a splitter mounted guard, remove the brackets used to mount the original equipment splitter.

Step 2: Behind where the saw blade was mounted, locate the threaded hole in the casting that was used to attach the original saw guard bracket to the interior of your saw. Using this hole, attach the RECEIVER of the ANTI-KICKBACK SPREADER to the saw by inserting from the front to the rear of the saw the 1-3/4" bolt with one flat washer installed against the head of the bolt. Install a second flat washer and lock nut, finger tight, on the threaded end of the bolt.

Step 3: Snap the SPREADER into the RECEIVER and replace the saw blade.

Step 4: Using a straight edge, position the spreader directly in line with the saw blade. Lightly tap the RECEIVER to move the SPREADER until it is aligned square to the saw blade with equal clearance visible on either side of the saw blade.

Step 5: Raise the saw blade to its maximum height. Align the SPREADER with the top of the saw blade.

Step 6: Securely tighten the bolt above the cross strap, then tighten the two nuts on the cross strap.

Step 7: Leaving your saw blade fully raised, re-check the alignment at the top and bottom of the blade.

Step 8: Re-install blade guard system and test to ensure that it is working properly.

Your T-Square Anti-Kickback Snap-In Spreader is now ready for use.

To remove the SNAP-IN SPREADER, pull the knob out to unlock the RECEIVER. The SPREADER is then removed by lifting it vertically out of the RECEIVER.

Make sure the SPREADER with anti-kickback fingers is used for all through cutting operations (ripping, cross-cutting, etc.) If your saw is equipped with the Biesemeyer T-Square Blade Guard, use a 1/2" screw in the crossarm of the T-Square Blade Guard to temporarily store the SNAP-IN SPREADER when performing non through-cutting operations when the spreader can't be used.