



Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	Cannot Furnish	Locating Plug	87	424-02-011-0009	Table Board
3	424-02-014-0001	Elevating Nut	88	424-02-011-0010	Table Board
4	Cannot Furnish	Column Base	89	424-02-011-0011	Fence
5	424-02-030-0001	Column	90	424-02-027-0002	Clamping Nut
6	Cannot Furnish	Column Key	91	424-02-112-0002	Clamping Screw
7	424-02-027-0001	Locknut	92	Cannot Furnish	Riplock Strip
8	Cannot Furnish	Stop, Incl:	98	951-01-021-3951	Pointer
9	424-03-016-0002	Rubber Bumper	94	955-03-020-2167	Hex Wrench
10	931-02-991-4794	Knob, Including:	95	Cannot Furnish	Leveling Strip
11	901-04-150-6215	1/4-20 X 3/8" Soc. Set Scr.	96	424-02-004-0007	Center Leveling Strip
12	901-06-450-2250	#4 X 3/16" Drive Scr.	97	424-02-112-0003	Leveling Screw
13	424-02-108-0001	Miter Lock Rod	98	Cannot Furnish	Guide
14	Cannot Furnish	Arm	99	424-02-055-0002	Guide
15	424-04-075-0001	Pointer	100	424-02-067-0001	Clamp Handle
16	951-02-010-7845	Miter Scale	101	424-02-095-0001	Front Trunnion
17	951-02-010-7823	Rip Scale	102	Cannot Furnish	Bevel Scale
18	920-52-011-3921	Thrust Bearing	103	Cannot Furnish	Special Washer
19	424-02-112-0005	Elevating Screw	104	Cannot Furnish	Lock Nut
20	904-10-071-3838	Collar	105	424-02-071-0001	Yoke King Bolt
21	424-02-071-0003	King Bolt	106	424-02-408-0015	Anti-KickBack Rod, Incl:
22	424-02-031-0011	End Plate	107	424-04-047-0002	Finger
23	Cannot Furnish	Rod	108	424-04-408-0002	Pin
24	Cannot Furnish	Bar	109	Cannot Furnish	1/16 X 1" Cotter Pin
25	Cannot Furnish	Cord Assembly	110	905-02-010-2489	1/8 X 7/8" Groove Pin
26	Cannot Furnish	Track	111	902-01-201-2567	Arbor Nut
27	424-02-388-0012	Stop Assembly, Incl:	112	955-01-030-1489	Arbor Nut Wrench
28	928-01-041-5310	Spring	113	955-01-010-1482	Roller Head Wrench
29	902-01-010-1300	5/16"-18 Hex Nut	114	Cannot Furnish	Roller Head
30	905-01-010-6731	5/64 X 1/2" Roll Pin	115	424-02-102-0001	Yoke
31	931-01-020-3606	Knob	116	Cannot Furnish	Plunger & Housing Incl:
32	901-06-450-8210	#00 X 1/8" Drive Screw	28	928-01-041-5310	Spring
34	Nameplate	By Request Only	31	931-01-020-3606	Knob
35	424-04-111-0002	Stud	117	Cannot Furnish	Riplock, Incl:
36	424-04-052-0001	Cib	10	931-02-991-4794	Knob, Incl:
37	901-04-160-0293	1/4-20 X 5/8" Soc. Set Scr.	11	901-04-150-6215	1/4-20 X 3/8" Soc. Set Scr.
38	Cannot Furnish	5/16-18 X 1/2" Soc. Set Scr.	118	424-02-042-0002	Bearing Stud
39	901-02-030-0406	3/4-20 X 3/4" Flat Hd. Scr.	119	424-02-111-0004	Guard Stud
40	901-02-030-0466	#8-32 X 3/8" Flat Hd. Scr.	120	424-02-095-0002	Rear Trunnion
41	901-02-010-0588	#6-32 X 3/4" Rd. Hd. Scr.	121	424-02-103-0001	Arbor Collar
42	Cannot Furnish	3/8-16 X 7/8" Flat Hd. Scr.	122	424-02-111-0005	Bearing Stud
43	901-02-010-0509	1/4-20 X 1/2" Rd. Hd. Scr.	123	Cannot Furnish	Saw Guard, Incl:
44	901-02-010-0514	1/4-20 X 3/8" Rd. Hd. Scr.	12	901-06-450-2250	#4 X 3/16" Drive Scr.
45	901-02-010-0553	#8-32 X 1/4" Rd. Hd. Scr.	34	Nameplate	By Request Only
46	901-02-010-0559	#10-32 X 1/2" Rd. Hd. Scr.	58	901-06-450-2252	#2 X 3/16" Drive Scr.
47	901-01-060-0648	3/8-16 X 1" Hex Hd. Scr.	124	960-04-010-1887	Plate
48	901-03-010-0757	5/16-18 X 5/8" Soc. Hd. Cap Scr.	125	901-04-260-1505	1/4-20 X 1/2" Thumb Scr.
50	902-01-040-1026	3/8"-16 Hex Nut	126	Cannot Furnish	Table Base
51	902-01-100-1028	1/2"-13 Hex Nut	128	Cannot Furnish	Rear Trunnion Plate
52	902-01-210-1036	3/4"-16 Lock Nut	129	Cannot Furnish	Bracket
53	901-04-170-1104	1/4-20 X 1/4" Soc. Set Scr.	130	901-04-150-0202	1/4-20 X 1/2" Soc. Set Scr.
54	902-03-000-1234	Tinnerman Nut	131	901-04-190-0237	#10-24 X 3/8" Soc. Set Scr.
55	904-01-010-1604	5/16 X 3/4 X .065" Washer	132	Cannot Furnish	3/8-16 X 3/4" Flat Hd. Scr.
56	904-02-020-1704	3/8" Lockwasher	133	901-02-030-0443	#8-32 X 1/4" Flat Hd. Scr.
57	904-02-020-1705	1/2" Lockwasher	134	901-02-030-0473	#10-24 X 5/8" Flat Hd. Scr.
58	901-06-450-2252	#2 X 3/16" Drive Scr.	135	Cannot Furnish	#10-24 X 3/8" Flat Hd. Scr.
59	438-01-629-5002	Single Phase Switch	137	901-03-010-0750	5/16-18 X 1" Soc. Hd. Cap Scr.
60	438-01-004-0007	Connector	138	901-03-010-0770	5/16-18 X 1-1/4" Soc. Hd. Cap Scr.
61	901-01-060-3117	1/2-13 X 2" Hex Hd. Scr.	139	901-03-010-0793	1/2-13 X 1" Soc. Hd. Cap Scr.
62	931-01-020-3607	Knob	141	902-01-040-1005	3/8"-16 Hex Nut
63	Cannot Furnish	Three Phase Switch	142	902-01-010-1207	3/8"-24 Hex Nut
64	438-01-008-0006	Switch Cover	143	902-01-120-1216	#10-24 Hex Nut
65	905-02-010-5030	3/16 X 3/4" Groove Pin	144	902-04-010-1429	5/16"-18 Wing Nut
66	905-02-010-5048	3/16 X 1-1/4" Groove Pin	146	904-01-010-1615	13/32 X 13/16 X 1/16" Washer
67	902-01-020-5435	5/16"-18 Hex Nut	147	904-01-010-1620	11/32 X 11/16 X 1/16" Washer
68	901-05-130-6101	#10 X 3/4" Self-Tapping Scr.	148	904-03-020-1789	3/8" Internal Tooth Lockwasher
69	905-02-040-6846	1/4 X 1" Groove Pin	149	905-05-040-2101	3/32 X 5/8" Cotter Pin
70	Cannot Furnish	Thrust Bearing	150	902-10-010-2957	5/16"-18 Palmot
71	438-01-004-0030	1/4" Pipe Clamp	151	901-06-110-3000	#6-32 X 1/4" Self-Tapping Scr.
72	Cannot Furnish	Switch Box	152	Cannot Furnish	Track Bearing
73	901-02-030-0467	#6-32 X 3/8" Flat Hd. Scr.	153	920-75-010-7333	Bearing
74	Cannot Furnish	Elevating Handle, Incl:	154	901-02-010-7502	3/8-16 X 1" Rd. Hd. Scr.
75	901-04-080-0101	1/4-20 X 1/4" Headless Set Scr.	155	34-105	10" Combination Blade
80	424-01-108-0013	Lock Rod	156	Cannot Furnish	7/32" Hex Wrench
81	Cannot Furnish	Dust Spout	157	Cannot Furnish	3/16" Hex Wrench
82	955-01-040-1485	Arbor Collar Wrench	158	955-03-010-0004	5/16" Hex Wrench
83	Cannot Furnish	Plug	159	Cannot Furnish	Overload Switch
84	Cannot Furnish	Front Table Board			
85	424-02-011-0007	Table Board			
86	424-02-011-0008	Table Board			