



# REPLACEMENT PARTS

Ref.	No.	Part No.	Description	Ref.	No.	Part No.	Description
	1	1349894	MOTOR ASSY 1725 R.P.M. , INCL:		32	1346457	M6 X 20MM SPRING PIN
	2	1346477	SWITCH BOX W/COVER, INCL:		33	900883	GRIP
	3	1340648	M3 X 10MM PAN HD SCREW		34	1346455	SPRING
	4	900893	NAMEPLATE , T2		35	898396	SHOULDER BOLT
		1349907	NAMEPLATE , T1		36	1346459	KEY
	5	1343759	SWITCH, INCL:		38	900880	COLUMN
	6	1343758	KEY ( NOTE A)		39	1246004	M6 X 16MM HEX SOC HD SCREW
	7	1346480	POWER CORD W/TERMINALS		40	1246016	M8 X 25MM HEX HEAD SCREW
	8	1320130	STRAIN RELIEF		41	1246157	M8 LOCKWASHER
	**	1349895	CAPACITOR 16UF (CMO)		42	1346464	BALL STUD
	**	1346481	CAPACITOR 20UF (EMO)		43	1346489	STABILIZER
	9	1346475	ADAPTER		44	1346483	T-HANDLE
	10	1346473	CHUCK, INCL:		45	1346484	HOLDER
	11	898392	KEY		46	1246104	M6 X 25MM HEX SOC HD SCREW
	12	1346472	M8 X 10MM TRUSS HD SCREW		47	1246140	M6 FLAT WASHER
	13	1346471	M8 X 15MM HEX SOC SET SCREW		48	1346457	M6 X 20MM ROLL PIN
	14	1346482	DEPTH STOP ROD		49	898397	RACK GEAR, AFTER S/N Q9847
	15	1246054	M8 X 20MM HEX SOC HD SCREW		49A	1346486	RACK GEAR, BEFORE S/N Q9848
	16	1346463	GUIDE		50	900884	HANDLE ASSEMBLY
	18	900879	HEAD, INCL.; T2		51	1346493	ROD
		1346465	HEAD, INCL.; T1		52	1341011	M8 X 10MM HEX SOC SET SCREW
	19	900891	WARNING LABEL, T2		53	900881	HOLD DOWN
		1349909	WARNING LABEL, T1		54	1341011	M8 X 10MM HEX SOC SET SCREW
	20	1342455	M5 X 10MM PAN HD SCREW		55	900882	FENCE
	21	1346468	HINGE		56	1346453	M6 X 35MM FLAT HEAD SCREW
	22	1346467	COVER		57	1346452	TABLE
	22A	900889	WARNING LABEL, T2		58	1346451	BASE
		1349906	WARNING LABEL, T1		59	1346496	T-NUT
	23	1346470	M8 X 20MM HEX SOC SET SCREW		60	901178	HARDWARE PACK
	24	1346469	BUSHING				
	25	1246070	M6 X 30MM HEX SOC HD SCREW				
	26	898393	GEAR, AFTER S/N Q9847				
	26A	1346462	GEAR, BEFORE S/N Q9848		61	900886	SPACER, INCL.; T2
	27	898394	COLLAR, AFTER S/N Q9847			14-611	SPACER, INCL.; T1
	27A	1346460	COLLAR, BEFORE S/N Q9848		62	1246176	M8 X 80MM HEX HD SCREW
	28	1346461	M5 X 5MM HEX SOC SET SCREW				
	29	898395	COLLAR, AFTER S/N Q9847, INCL.: REF. 30		**		NOT SHOWN
	29A	1346458	HUB ASSEMBLY, BEFORE S/N Q9848, INCL:				EMO=EARLY MODELS ONLY
	30	1246025	M6 X 30MM SPRING PIN				CMO=CURRENT MODELS ONLY
	31	1346456	HANDLE ASSEMBLY, INCL:				

## ACCESSORIES: (Optional)

**NOTE A:** DELTA HAS USED A NUMBER OF DIFFERENT TYPES OF SWITCHES FOR PRODUCTION. ALL SWITCHES ARE INTERCHANGEABLE BUT THE KEYS ARE DIFFERENT. REPLACEMENT SWITCHES COME COMPLETE WITH KEY, IF A REPLACEMENT KEY IS NEEDED, REFER TO DRAWING BELOW TO SELECT THE PROPER ONE.



## STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Center for repair with damaged or missing standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department, your service outlet, or by visiting the Delta Website @ [www.deltamachinery.com](http://www.deltamachinery.com).