




Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	902-04-010-1404	3/8"-16 Wing Nut	67	904-01-010-1604	5/16" Flat Washer
2	1202111	Lower Guard	68	904-02-020-2086	5/16" Lockwasher
3	901-04-191-9277	3/8-16 X 2" Set Scr.	69	901-01-060-0607	5/16-18 X 3/4" Hex Hd. Scr.
4	1202100	Plate	70	1202083	Drive Spacer
5		Sanding Belt	71	1202102	Contact Wheel Ass'y.
6	902-01-013-1032	7/8"-9 L.H. Arbor Nut	72	904-01-031-5713	7/8 X 1-1/2" X 3/32 Flat Washer
7	904-01-031-5713	7/8 X 1-1/2 X 3/32" Flat Washer	73	902-01-010-5420	7/8-9 R.H. Arbor Nut
8	1202102	Contact Wheel Ass'y.	74		Sanding Belt
11	1202099	Platen Brkt. Ass'y.	75	1202100	Plate
12	901-04-173-1023	3/8-16 X 3/8" Set Scr.	76	1202108	Lower Guard
13	1202096	Table	77	901-04-191-9277	3/8-16 X 2" Set Scr.
14	904-01-010-1605	3/8" Flat Washer	78	902-04-010-1404	3/8"-16 Wing Nut
15	904-02-020-1704	3/8" Lockwasher	79	901-06-110-3039	#10-32 X 1/2" Rd. Hd. Scr.
16	901-01-060-0650	3/8-16 X 7/8" Hex Hd. Scr.	80	904-02-020-1725	#10 Lockwasher
17	1202083	Drive Spacer	81	904-01-010-1603	Flatwasher
18	904-01-010-1604	5/16" Flatwasher	82	1202085	Deflector Plate
19	904-02-020-2086	5/16" Lockwasher	83	1202106	Upper Guard
20	901-01-060-0607	5/16-18 X 3/4" Hex Hd. Scr.	84	905-01-010-2715	3/16 X 1-1/8" Roll Pin
21	1202109	Lower Bracket - L.H.	*	1202091	Idler Pulley, Incl:
22	901-04-150-6202	5/16-18 X 3/8" Set Scr.	85	1202075	Pulley
23	1202095	Column	86	901-04-150-1185	1/4-20 X 5/16" Set Scr.
24	1202094	Collar	87	904-15-010-7410	Retaining Ring
25	901-04-160-1101	3/8-16 X 3/8" Set Scr.	88	920-04-020-5384	Bearing
26	905-01-013-1042	5/16 X 2-1/2" Roll Pin	89	928-06-023-1012	Wave Washer
27	1203035	Spring	90	1202076	Spacer
28	1202104	Upper Bracket	91	1202090	Shaft
29	1200088	Special Screw	92	905-01-012-0310	3/16 X 2-1/2 Roll Pin
*	1202093	Tracking Shaft Ass'y., Incl:	93	1202107	Upper Bracket
30	1202092	Stud	94	902-01-210-1072	5/16"-18 Locknut
31	931-01-101-4063	Handle	95	1202081	Rod
32	931-01-041-3544	Ball	96	901-01-060-0609	5/16-18 X 1-1/2" Hex Hd. Scr.
33	1202082	Stud	97	1202080	Cam
34	901-01-060-0609	5/16-18 X 1-1/2" Hex Hd. Scr.	98	1202082	Stud
35	1202081	Rod	*	1202093	Tracking Shaft Ass'y., Incl:
36	1202080	Cam	99	1202092	Stud
37	902-01-210-1072	5/16"-18 Locknut	100	931-01-041-3544	Ball
38	905-01-012-0310	3/16 X 2-1/2 Roll Pin	101	931-01-101-4063	Handle
*	1202091	Idler Pulley, Incl:	102	1200088	Special Screw
39	1202090	Shaft	103	905-01-013-1042	5/16 X 2-1/2" Roll Pin
40	904-15-010-7410	Retaining Ring	104	1203035	Spring
41	920-04-020-5384	Bearing	105	1202094	Collar
42	1202076	Spacer	106	901-04-160-1101	3/8-16 X 3/8" Set Scr.
43	928-06-023-1012	Wave Washer	107	1203045	Switch Guard
44	1202075	Pulley	*	23-805	Pedestal Ass'y., Const. Of:
45	901-04-150-1185	1/4-20 X 5/16" Set Scr.	110	1201879	Pedestal
46	1202105	Upper Guard	111	1201928	Cover
47	905-01-010-2715	3/16 X 1-1/8" Roll Pin	112	901-02-010-0509	1/4-20 X 1/2" Rd. Hd. Mach. Scr.
48	1202085	Deflector Plate	113	412-01-005-5002	Base
49	904-01-010-1603	Flat Washer	114	904-02-020-1705	1/2" Lockwasher
50	904-02-020-1725	#10 Lockwasher	115	901-01-060-0628	1/2-13 X 1" Hex Hd. Scr.
51	901-06-110-3039	#10-32 X 1/2" Rd. Hd. Scr.	116	402-04-031-5002	Switch Opening Cover
52	901-02-010-0561	#10-32 X 3/8" Rd. Hd. Scr.	117	901-02-010-0553	#6-32 X 1/2" Rd. Hd. Scr.
53	412-01-031-5006	Base Cover	118	904-01-010-1602	3/16 X 7/17 X 20 ga. Washer
54	1203048	Base	119	902-01-120-9232	#6-32 Hex Nut
55		Motor (See A)	120	902-01-010-1300	5/16-18 Hex Nut
58	1202099	Platen Brkt. Ass'y.	121	904-02-010-1703	5/16" Lockwasher
59	901-01-060-0650	3/8-16 X 7/8" Hex Hd. Scr.	122	901-01-060-0635	5/16-18 X 2" Hex Hd. Scr.
60	904-02-020-1704	3/8" Lockwasher			
61	904-01-010-1605	3/8" Flatwasher	*	NOT SHOWN ASSEMBLED	
62	1202096	Table			
63	1202110	Lower Bracket - R.H.			
64	901-04-173-1023	3/8-16 X 3/8" Set Scr.			
65	901-04-150-6202	5/16-18 X 3/8" Set Scr.			
66	1202095	Column			

SERVICE NOTES:

A - For Exact Motor Replacement See Motor Nameplate.