



REPLACEMENT PARTS

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	902581	SCREW	38	1320077	LEFT HAND NUT
2	901911	EYESHIELD	46	1320155	GROMMET
3	1340608	WASHER	48	1320125	POWER CORD
4	902582	M6 KNOB	49	1310057	STRAIN RELIEF
5	902583	SPACER	51	1320211	PLATE
6	902584	RIGHT SPARK BREAKER	52	1346828	LAMP ASSY
7	1320090	WASHER	53	900843	WARNING LABEL (LAMP)
8	1340609	HEX HD SCREW	54	902617	BASE
9	1320003	TRUSS HD SCREW	55	904-02-020-1702	WASHER
10	1320400	COVER	56	902-01-120-1034	HEX NUT
11	1320078	5/8-11 HEX NUT RH	57	902588	BASE COVER
12	1320401	FLANGE	58	1320217	PAD
13	23-884	8IN GRIND WHEEL/60G	59	1320087	WASHER
15	902615	WHEEL GUARD RH	60	901-02-010-0525	SCREW
16	900839	ROTATIONAL LABEL	61	1346826	CAPACITOR
17	n 901-02-120-7528	SCREW	63	1320160	CLAMP
18	1320828	TOOL REST ASSY	65	1320101	WASHER
19	904-02-010-1703	WASHER	66	1320151	SWITCH
20	901-01-060-0607	SCREW	68	1320219	PLATE
21	904-01-010-1605	WASHER	69	902590	WRENCH
22	901-01-060-0606	SCREW			
23	900877	WARNING & DEC PLATE			
29	902586	LEFT SPARK BREAKER			
33	902616	WHEEL GUARD LH			
36	23-883	8IN GRIND WHEEL/36G			

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.