






REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION
1	1346617	SCR	48	1243526	(DIN 125) M8.4 FLAT WASHER
2	1346618	M8.4 NYLON WASHER	49	1313286	TRUNNION
3	1346619	RETAINER	50	904-01-031-6202	FLAT WASHER
4	1346620	SPRING	51	901-01-060-0642	3/8-16 X 1" HEX HD SCR
5	1340087	TENSION LABEL	52	1346664	SPECIAL BOLT
6	1346623	KNOB	55	1246056	(DIN 912) M6 X 12MM HEX SOC HD SCR
7	1344333	(DIN 315) M8 WING NUT	56	1246140	(DIN 125) M6.4 FLAT WASHER
8	1243526	(DIN 125) M8.4 FLAT WASHER	57	1346628	BRACKET
9	1346616	UPPER FRAME	58	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
10	1346676	M8 NUT	59	1346629	GUIDE
12	1346621	POINTER	60	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
15	1243398	(DIN 934) M8 HEX NUT	61	1346631	SHAFT
16	1346615	TENSION BLOCK	62	1346630	BALL BEARING
17	1346614	GUIDE	65	1346645	LOWER FRAME
18	1243336	(DIN 912) M6 X 20MM HEX SOC HD SCR	66	1246145	INT RET RING
19	422-29-139-0002	BALL BEARING	67	422-29-139-0002	BALL BEARING
20	1346611	SUPPORT	68	1346643	SHAFT
21	1346612	(DIN 6325) M8 X 40MM DOWEL PIN	69	1311071	KEY
22	1346613	M8 SQUARE NUT	70	422-29-139-0002	BALL BEARING
23	1346610	UPPER WHEEL	71	1346644	SPACER
24	1346609	TIRE	72	1341441	(DIN 912) M4 X 12MM HEX SOC HD SCR
25	1346608	SHAFT	73	1346639	BRACKET
26	1346668	BRACKET	74	1346625	CLAMP BRACKET
26A	1243379	(DIN 912) M6 X 10MM HEX SOC HD SCR	74A	1246177	(DIN 84) M4 X 6MM CHEESE HD SCR
26B	1246140	(DIN 125) M6.4 FLAT WASHER	75	1346642	BOTTOM WHEEL
27	1243407	EXT RET RING	76	1346609	TIRE
27A	422-29-139-0002	BALL BEARING	77	1343584	M6 FENDER WASHER
28	1246127	(DIN 916) M6 X 30MM HEX SOC SET SCR	78	1243520	(DIN 7980) M6.1 LOCK WASHER
29	1346655	INSERT	79	1246004	(DIN 912) M6 X 16MM HEX SOC HD SCR
30	1346656	TABLE	80	OPTIONAL	BLADE
31	1243456	(DIN 934) M6 HEX NUT	81	1346637	STUD
32	1246090	(DIN 84) M6 X 30MM CHEESE HD SCR	82	902-01-120-1216	#10-24 HEX NUT
32A	1246140	(DIN 125) M6.4 FLAT WASHER	83	904-03-030-1795	3/16" EXT TOOTH WASHER
33	1313281	(DIN 315) M6 WING NUT	84	1346636	KNOB
34	1346657	LEVER ASSY	85	1243501	(DIN 84) M4 X 10MM CHEESE HD SCR
35	1346658	SPACER	86	1346640	BOTTOM COVER
36	1346659	SPRING	87	1340085	WARNING LABEL
37	1346660	TRUNNION	88	1340089	NAMEPLATE
38	904-01-031-6202	FLAT WASHER	89	1346641	TOP COVER
39	1246123	(DIN 912) M8 X 70MM HEX SOC HD SCR	90	1346603	BLADE CHART
40	1243526	(DIN 125) M8.4 FLAT WASHER	90A	1340086	BLADE CHART
41	1346662	BRACKET, INCL:	91	1346653	BASE
42	1310016	5MM DRIVE SCR	92	1243526	(DIN 125) M8.4 FLAT WASHER
43	1346663	SCALE	93	1246034	(DIN 933) M8 X 20MM HEX HD SCR
44	901-01-060-0642	3/8-16 X 1" HEX HD SCR	94	1346654	FRONT BASE
45	1346661	POINTER	97	432-07-101-0004	5MM HEX WRENCH
46	1246154	(DIN 84) M4 X 16MM CHEESE HD SCR	98	428-06-101-0002	3MM HEX WRENCH
47	1246054	(DIN 912) M8 X 20MM HEX SOC HD SCR	99	428-07-101-0002	6MM HEX WRENCH





**REF.
NO.**

PART NUMBER

DESCRIPTION

100	1346638	CLAMP PLATE
101	1346624	KNOB
102	1346626	ROD
103	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
104	1346632	PLATE
105	1346627	GUARD
106	1343567	WARNING LABEL
107	1246140	(DIN 125) M6.4 FLAT WASHER
108	1246056	(DIN 912) M6 X 12MM HEX SOC HD SCR
109	1346628	BRACKET
110	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
111	1346629	GUIDE
112	1346631	SHAFT
113	1346630	BALL BEARING
114	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
115	1246140	(DIN 125) M6.4 FLAT WASHER
116	1246004	(DIN 912) M6 X 16MM HEX SOC HD SCR
120	1343759	SWITCH, INCL:
121	400-06-068-0002	SWITCH KEY
122	1346635	COVER
123	1243501	(DIN 84) M4 X 10MM CHEESE HD SCR
124	1243501	(DIN 84) M4 X 10MM CHEESE HD SCR
125	1310210	(DIN 6797A) M4.3 EXT TOOTH WASHER
	1320175	CONNECTOR
	1346665	POWER CORD


**REF.
NO.**

PART NUMBER

DESCRIPTION


128	1346634	NECK
129	1342455	(DIN 85) M5 X 10MM PAN HD SCR
130	1320131	STRAIN RELIEF
131	1345029	REAR SWITCH PLATE
132	1243526	(DIN 125) M8.4 FLAT WASHER
133	1246034	(DIN 933) M8 X 20MM HEX HD SCR
140	1243395	(DIN 934) M5 HEX NUT
141	1246102	(DIN 125) M5.3 FLAT WASHER
142	1345036	BRUSH
143	1246047	(DIN 84) M5 X 16MM CHEESE HD SCR
144	1243501	(DIN 84) M4 X 10MM CHEESE HD SCR
145	904-01-010-1602	3/16" FLAT WASHER
146	1346646	DUST SPOUT
147	1346647	DRIVEN PULLEY
148	1346648	BELT
149	1246140	(DIN 125) M6.4 FLAT WASHER
150	1243520	(DIN 7980) M6.1 LOCK WASHER
151	1246004	(DIN 912) M6 X 16MM HEX SOC HD SCR
152	1346649	BELT COVER
153	1246154	(DIN 84) M4 X 16MM CHEESE HD SCR
154	1243456	(DIN 934) M6 HEX NUT
155	1346650	STUD
156	1346651	COVER
157	1246140	(DIN 125) M6.4 FLAT WASHER
158	1246067	(DIN 84) M6 X 16MM CHEESE HD SCR

REPLACEMENT PARTS



REF. NO.	PART NUMBER	DESCRIPTION
200	1246034	(DIN 933) M8 X 20MM HEX HD SCR
201	1243526	(DIN 125) M8.4 FLAT WASHER
202	1243526	(DIN 125) M8.4 FLAT WASHER
203	1243398	(DIN 934) M8 HEX NUT
204	1346601	MOTOR
205	1311071	KEY
206	1346652	DRIVE PULLEY
207	1343584	M6 FENDER WASHER
208	1243520	(DIN 7980) M6.1 LOCK WASHER
209	1349481	(DIN 912) M6 X 20MM HEX SOC HD SCR
210	1243398	(DIN 934) M8 HEX NUT
211	1243526	(DIN 125) M8.4 FLAT WASHER
212	1246192	(DIN 933) M8 X 45MM HEX HD SCR
*	1346674	STAND, CONST OF:
225	1346670	BRACKET 20.6"
226	1346669	BRACKET 12.4"
227	1342381	PLASTIC FOOT
228	1346671	BRACKET 24.9"
229	1346673	BRACKET 16.7"
230	1346672	LEG
231	1349177	(DIN 603) M8 X 16MM CARRIAGE HD SCR
232	904-01-010-1605	3/8" FLAT WASHER
233	1243398	(DIN 934) M8 HEX NUT
235	1243526	(DIN 125) M8.4 FLAT WASHER
236	1246192	(DIN 933) M8 X 45MM HEX HD SCR

* NOT SHOWN ASSEMBLED



AVAILABLE AS AN ACCESSORY

REF. NO.	PART NUMBER	DESCRIPTION
250	28-194	BANDSAW LAMP, INCL:
251	1346668	BRACKET
252	1246140	(DIN 125) M6.4 FLAT WASHER
253	1243379	(DIN 912) M6 X 10MM HEX SOC HD SCR
254	1346667	(DIN 433) M10 FLAT WASHER
255	1341996	(DIN 985) M10 LOCK NUT
256	1346666	CLIP

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.