





REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
1	426-02-354-0046	UPPER GUARD - FRONT (PLATINUM),	38	904-01-010-1611	13/16" FLAT WASHER
1A	1087794	INCL:	39	904-02-020-1707	LOCK WASHER
1B	426-02-137-0001	RIVIT	40	902-01-100-1027	3/4-10 HEX NUT
2	406-03-060-0002	NAMEPLATE	41	426-02-005-0005	BASE
3	426-02-071-0002	KNOB	42	438-01-004-0082	CABLE CLAMP
4	426-02-071-0002	DOOR LOCK STUD	43	901-03-010-3318	#10-32 X 3/8" HEX SOC HD SCR
5	902-01-293-1513	#10-32 KEPS NUT	44	905-04-071-4460	1/4" X 3/4" DOWEL PIN
6	902-01-020-1227	1/2-20 JAM NUT	45	902-07-030-7171	BEARING NUT
7	426-03-400-0008	UPPER WHEEL ASSY, INCL:	47	920-04-020-5348	BALL BEARING
8	426-02-094-0003	TIRE	48	928-07-010-7353	BEARING LOAD SPRING
9	920-04-010-7273	BALL BEARING	49	426-02-122-0004	SPRING CLIP
10	426-02-104-0006	SPACER	51	901-03-040-8015	1/4-20 X 1/2" BUTTON HD SCR
11	901-02-012-1910	3/8-16 X 2 1/4" ROUND HD SCR	52	436-01-016-2001	BUMPER
12	904-01-010-1615	3/8" FLAT WASHER	53	426-02-026-0003	DUST SPOUT
13	426-02-054-0017	BLADE GUARD	54	901-03-063-1340	SHOULDER SCR
14	901-02-763-1527	5/16-18 X 1/2" HEX WASHER HD SCR	58	426-02-111-0001	HEX STUD
15	904-01-010-1615	3/8" FLAT WASHER	59	426-02-122-0003	DOOR CATCH
16	426-02-389-0004	UPPER FRAME ASSY, INCL:	60	901-02-051-2860	#08-32 X 1/4" FILL HD SCR
17	426-02-111-0006	STUD	61	426-02-106-0010	LOWER DRIVE SHAFT
18	426-02-354-0044	REAR GUARD (PLATINUM)	62	927-03-010-2650	1 3/8" KEY
19	902-01-133-1529	1/4-20 FLANGE NUT	63	927-01-100-2603	HI-PRO KEY
20	901-02-763-1527	5/16-18 X 1/2" HEX WASHER HD SCR	64	920-04-020-5348	BALL BEARING
21	904-01-010-1620	FLAT WASHER	65	904-01-031-4982	FLAT WASHER
22	426-02-111-0001	HEX STUD	66	426-03-400-0010	LOWER WHEEL, INCL:
23	426-02-122-0003	DOOR CATCH	67	426-02-094-0003	TIRE
24	901-02-051-2860	#08-32 X 1/4" FILL HD SCR	68	902-07-030-7171	BEARING NUT
25	904-01-032-2477	FLAT WASHER	69	901-02-763-1530	1/4-20 X 1/2" HEX WASHER HD SCR
*	426-02-359-0005	SLIDING BRACKET ASSY, CONST OF:	70	426-02-354-0047	LOWER GUARD ASSY (PLATINUM),
26	426-02-106-0004	UPPER WHEEL SHAFT			INCL:
27	426-02-059-0001	HINGE	71	426-02-754-0005	WARNING DECAL
28	426-02-412-0008	KNOB ASSY.	72	1087794	RIVIT
29	426-02-014-0003	SLIDING BRACKET	73	426-02-071-0002	DOOR LOCK STUD
30	905-04-141-3146	PIN	74	902-01-293-1513	#10-32 KEPS NUT
31	902-04-010-1403	5/16-18 WING NUT	75	406-03-060-0002	KNOB
32	901-04-261-4005	5/16-18 X 2 1/2" THUMB SCR			
33	928-01-041-3386	COIL SPRING			
34	904-07-010-5572	FIBER WASHER			
35	902-02-050-1317	3/8-16 SQUARE NUT			
36	426-02-327-0003	GUIDE LOCK KNOB			
37	901-01-060-9062	3/4-10 X 2 3/4" HEX HD SCR			

AVAILABLE AS ACCESSORIES

85	49-220	HOSE ADAPTER
86	49-228	HOSE COUPLING

* NOT SHOWN ASSEMBLED



REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
100	426-02-055-0001	GUIDE POST	138	426-03-388-0001	COLLAR ASSY, INCL:
*	426-02-355-0002	UPPER BLADE GUIDE, CONST OF:	139	901-04-150-0208	1/4-20 X 1/4" HEX SOC SET SCR
101	902-08-041-3064	5/16-24 SERRATED NUT	140	904-07-010-5571	FIBER WASHER
102	901-04-150-0297	5/16-24 X 1 3/4" HEX SOC SET SCR	141	901-02-030-0408	5/16-18 X 3/4" FLAT HD SCR
103	901-04-190-0207	5/16-18 X 1/2" HEX SOC SET SCR	*	426-02-355-0004	LOWER BLADE GUIDE, CONST OF:
106	426-02-106-0009	HEXAGON SHAFT	142	426-02-004-0001	STEEL RAIL
107	426-02-089-0002	BRACKET	143	426-02-314-0008	TRUNNION SUPPORT ASSY, INCL:
108	920-08-020-1457	BALL BEARING	144	901-01-060-3125	5/16-18 X 2 1/2" HEX HD SCR
109	901-03-040-8015	1/4-20 X 1/2" BUTTON HD SCR	145	1087640	5/16-18 LOCK NUT
*	426-02-355-0003	BRACKET ASSY, CONST OF:	146	904-10-101-3166	SPACER
110	426-02-014-0004	BRACKET	147	426-02-014-0013	ADJUSTING LINK
111	901-04-190-0225	5/16-18 X 1/4" HEX SOC SET SCR	148	901-03-030-8013	1/4-20 X 3/4" FLAT HD SCR
112	952-02-011-3254	GUIDE BLOCK	149	952-02-011-3254	GUIDE BLOCK
113	901-04-260-1520	5/16-18 X 1/2" THUMB SCR	150	901-04-190-0225	5/16-18 X 1/4" HEX SOC SET SCR
114	901-04-260-1528	5/16-18 X 1" THUMB SCR	151	426-02-098-0001	WEDGE
115	901-03-040-8015	1/4-20 X 1/2" BUTTON HD SCR	152	928-01-021-3387	COIL SPRING
116	426-02-054-0001	BLADE GUARD	153	426-02-098-0001	WEDGE
117	426-02-063-0002	TABLE INSERT	154	426-02-106-0011	SHAFT
118	426-02-391-0005	TABLE, INCL:	155	426-02-014-0006	SUPPORT BRACKET
119	426-02-071-0001	PIN	156	952-02-011-3253	ANGLE GUIDE BLOCK
120	901-01-060-0625	7/16-14 X 2 1/4" HEX HD SCR	157	920-08-020-1457	BALL BEARING
121	426-02-027-0001	CLAMP SHOE	**	28-256	COOL BLOCK BLADE GUIDES
122	426-02-095-0002	TRUNNION			
123	901-02-763-1530	1/4-20 X 1/2" HEX WASHER HD SCR			
124	901-01-060-0637	7/16-14 X 3 3/4" HEX HD SCR			
125	426-02-027-0001	CLAMP SHOE	**	28-984	HEIGHT ATTACHMENT (See A154 For Service Parts)
126	426-02-395-0002	TRUNNION ASSY, INCL:			
127	951-02-010-7832	SCALE			
128	903-03-023-1333	RIVIT	*	NOT SHOWN ASSEMBLED	
129	901-02-763-1530	1/4-20 X 1/2" HEX WASHER HD SCR	**	NOT SHOWN	
130	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR			
131	928-05-013-1378	WAVE WASHER			
132	904-07-010-5571	FIBER WASHER			
133	426-02-412-0004	ADJUSTING SCREW W/KNOB			
134	901-03-012-2144	#10-32 X 1/4" HEX SOC HD SCR			
135	951-01-010-7802	POINTER			
136	904-01-031-2925	FLAT WASHER			
137	406-03-138-0004	KNOB			

REPLACEMENT PARTS

REF
NO

PART NUMBER

DESCRIPTION

28-855

12" CAPACITY RIP FENCE, CONST OF:


201	422-16-104-0009	SPACER
202	901-03-013-1767	1/4-28 X 1 1/4" HEX SOC HD SCREW
203	426-02-055-0005	FRONT GUIDE RAIL
205	901-03-010-8082	1/4-28 X 1" HEX SOC HD SCREW
206	426-02-055-0006	REAR GUIDE RAIL
208	426-02-043-0002	FENCE
209	902-10-013-1784	1/4" PALNUT
210	426-02-084-0001	SLIDE FOOT
211	901-05-473-1815	3/8-16 X 3/4" THREAD FORMING SCREW
212	904-01-010-1615	FLAT WASHER
213	426-02-312-0001	CLAMP BODY, INCL:
214	901-06-110-3039	#10-32 X 1/2" ROUND HD SCREW
215	951-01-010-7802	POINTER
216	1087531	KNOB
217	1087212	CLAMP

RESAW ATTACHMENT


218	901-02-123-1785	1/4-20 X 2" RD HD SCREW
219	931-02-010-3622	HAND KNOB
220	426-02-111-0008	STUD

* NOT SHOWN ASSEMBLED

28-855 RIP FENCE



50-274 MOBILE BASE




REF
NO

PART NUMBER

DESCRIPTION

*	50-274	MOBILE BASE , CONST OF:
251	436-02-020-0003	CAP - 1" X 2"
252	902-01-210-1072	5/16-18 LOCK NUT
253	436-02-367-0005	FOOT LEVER ASSY, INCL;
254	904-15-012-0052	EXT RET RING
255	904-01-010-1636	FLAT WASHER
256	436-02-071-0001	PIN
257	436-02-014-0016	BRACKET
258	904-01-010-1620	FLAT WASHER
259	901-01-060-0609	5/16-18 X 1 1/2" HEX HD SCREW
260	902-01-010-1300	5/16-18 HEX NUT
261	436-02-400-0005	CASTER ASSY
262	901-01-063-1537	5/16-18 X 4" HEX HD SCREW
263	436-02-048-0008	LEVELING SCREW
264	902-01-020-1266	1/2-13 JAM NUT
265	436-02-100-0001	WHEEL
266	902-01-010-1300	5/16-18 HEX NUT
267	904-02-010-1703	5/16" LOCK WASHER
268	901-03-010-8024	5/16-18 X 2 1/4" HEX SOC HD SCREW

* NOT SHOWN ASSEMBLED



REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION
*	426-02-131-0001	1 HP MOTOR ASSY, CONST OF:
300	62-268	MOTOR - 1 HP
301	422-39-067-0001	SWITCH ACTUATOR
302	438-01-017-0206	SWITCH
303	426-02-754-0003	NAMEPLATE
304	901-02-010-0567	#06-32 X 1/4" ROUND HD SCR
305	438-01-008-0074	SWITCH COVER
306	402-07-104-5007	SPACER
307	438-01-021-0149	SWITCH PLATE
308	422-04-116-0001	GASKET
309	402-07-111-5002	STUD
310	901-02-120-7533	1/4-20 X 2 3/4" TRUSS HD SCR
311	438-01-011-0064	PLUG
312	438-01-001-0055	UTILITY BOX
313	438-01-004-0099	CORD CLAMP
314	430-02-104-0005	1-3/4" SPACER
315	904-02-020-1702	1/4" LOCK WASHER
316	902-01-120-1034	1/4-20 HEX NUT
**	438-01-302-0688	SWITCH CORD
**	438-01-302-0689	POWER CORD
**	901-06-423-1170	#10-32 X 5/8" HEX HD GROUND SCREW
322	426-02-054-0024	PULLEY GUARD (PLATINUM) <i>(Included w/Basic Machine)</i>
323	901-01-060-0612	1/4-20 X 5/8" HEX HD SCR <i>(Included w/Basic Machine)</i>
324	904-01-010-1614	FLAT WASHER <i>(Included w/Basic Machine)</i>
325	902-01-120-1034	1/4-20 HEX NUT <i>(Included w/Basic Machine)</i>
*	426-02-318-0006	STAND (PLATINUM), CONST OF:
326	901-01-060-0613	5/16-18 X 1 3/4" HEX HD SCREW
327	904-01-010-1605	3/8" FLAT WASHER
328	902-01-503-1514	5/16-18 FLANGE NUT
329	438-01-011-0051	BUSHING INSULATOR
330	426-02-318-0005	CABINET ASSY (PLATINUM)
331	438-01-011-0065	PLUG
332	438-01-011-0020	INSULATOR
333	436-01-004-0022	MOTOR BRACKET (BLACK)
334	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCREW
335	902-01-503-1514	5/16-18 FLANGE NUT
336	901-01-060-0607	5/16-18 X 3/4" HEX HD SCREW
337	436-01-305-0001	SUB BASE
338	902-01-503-1514	5/16-18 FLANGE NUT
340	901-06-443-1806	#10-24 X 1/2" HEX HD SCREW
341	436-01-123-0007	PANEL (PLATINUM)
350	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCREW
351	902-01-503-1514	5/16-18 FLANGE NUT
354	926-01-043-1763	4 5/8" DRIVEN PULLEY, INCL:
355	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
356	926-01-041-9366	2 1/4" MOTOR PULLEY, INCL:
357	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
358	49-051	52" OC V-BELT
360	438-01-004-0054	CABLE TIE
*	NOT SHOWN ASSEMBLED	
**	NOT SHOWN	

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.