




A Pentair Company

28-345
20" METAL CUTTING
VARIABLE SPEED BAND SAW
(For Units w/Serial No 94D-38976 & Lower)

BS-4A

Part No 426-05-651-0002

Revised 4-29-94



REPLACEMENT PARTS


REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
1	426-04-318-5007	FRAME ASSY	63	426-05-134-5002	SPROCKET, INCL:
2	426-05-072-0001	SPEED CHART	64	901-04-150-0202	1/4-20 X 1/2" HEX SOC SET SCREW
3	426-05-055-5002	GUIDE	65	904-10-021-2096	COLLAR
4	901-04-190-0286	#08-32 X 1/4" HEX SOC SET SCREW	66	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
5	426-05-328-5001	CLUTCH ASSY	67	438-01-011-0021	INSULATOR (<i>Early Models Only</i>)
6	901-03-010-0763	1/4-20 X 3/8" HEX SOC HD SCREW	68	426-04-017-5001	BRASS BUSHING
7	901-06-450-2250	#04 X 3/16" ROUND HD SCREW	69	902-01-020-5435	5/16-18 JAM NUT
8	426-05-075-5001	POINTER	70	901-01-060-0649	5/16-18 X 1" HEX HD SCREW
9	901-02-010-0554	#08-32 X 1/2" ROUND HD SCREW	71	426-05-014-5022	LEVER BRACKET
10	901-06-450-2250	#04 X 3/16" ROUND HD SCREW	72	927-01-010-2634	KEY
11	426-05-072-5030	BLADE CHART PLATE	73	426-05-367-5002	SPEED CONTROL LEVER ASSY, INCL:
12	901-02-010-0514	1/4-20 X 3/8" ROUND HD SCREW	74	905-01-010-6716	3/8" X 1 1/2" SPRING PIN
13	426-05-032-5001	COUNTR BALANCE	75	901-04-190-0214	3/8-16 X 1 1/4" HEX SOC SET SCREW
14	426-05-014-5005	BRACKET	76	902-01-020-5433	3/8-16 JAM NUT
15	902-01-120-1034	1/4-20 HEX NUT	77	426-05-031-5018	REAR COVER
16	901-06-110-3002	#08-32 X 3/8" ROUND HD SCREW	78	426-05-063-5006	HANDLE
17	901-02-010-0502	1/4-20 X 1/4" ROUND HD SCREW	79	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
18	426-05-031-5007	COVER			
19	904-03-030-1795	3/16" EXT TOOTH WASHER			
20	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW			
21	426-05-331-5003	UPPER DOOR ASSY, INCL:			
22	426-05-068-5001	LATCH			
23	904-03-020-1775	3/16" INT TOOTH WASHER			
24	902-01-120-1203	#10-32 HEX NUT			
25	901-02-010-0561	#10-32 X 3/8" ROUND HD SCREW			
26	426-04-754-0001	NAMEPLATE			
27	901-06-450-2250	#04 X 3/16" ROUND HD SCREW			
28	426-00-752-0006	WARNING LABEL			
29	426-05-063-5006	INSERT HANDLE			
30	901-25-030-7545	#07 X 1/2" WOOD SCREW			
31	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW			
32	426-05-014-5006	BRACKET			
33	426-05-113-5001	WIPER - LOWER WHEEL			
34	426-05-331-5012	LOWER DOOR ASSY, INCL:			
35	902-01-120-1203	#10-32 HEX NUT			
36	904-03-020-1775	3/16" INT TOOTH WASHER			
37	426-05-068-5001	LATCH			
38	901-02-010-0561	#10-32 X 3/8" ROUND HD SCREW			
39	426-05-063-5006	INSERT HANDLE			
40	901-02-010-0559	#10-32 X 1/2" ROUND HD SCREW			
41	426-04-036-5001	DUST PLATE			
42	904-01-010-1615	FLAT WASHER			
43	901-01-060-0648	3/8-16 X 1 1/4" HEX HD SCREW			
44	902-01-120-1203	#10-32 HEX NUT			
45	902-01-040-1026	3/8-16 HEX NUT			
46	426-04-026-5001	CHUTE			
47	402-07-019-5001	CAM			
48	904-15-010-7008	EXT RET RING			
49	904-01-031-2937	FLAT WASHER			
50	901-01-060-0607	5/16-18 X 3/4" HEX HD SCREW			
51	927-01-010-2633	KEY			
52	927-01-010-2634	KEY			
53	426-05-106-5023	SHAFT			
54	426-05-134-5001	SPROCKET, INCL:			
55	901-04-150-0202	1/4-20 X 1/2" HEX SOC SET SCREW			
56	426-05-323-5002	CHAIN ASSY, INCL:			
57	901-04-190-0286	#08-32 X 1/4" HEX SOC SET SCREW			
58	426-05-055-5002	GUIDE			
59	901-02-010-0554	#08-32 X 1/2" ROUND HD SCREW			
60	426-05-135-5001	LINK			
61	426-05-079-5012	TURNBUCKLE			
62	902-01-120-1216	#10-24 HEX NUT			

ITEMS LISTED BELOW AVAILABLE AS ACCESSORY

28-720	CHIP BLOWER, CONST OF:
426-05-061-5001	HOSE
906-00-000-8720	FITTING
426-05-361-5001	HOSE ASSY (<i>SPOUT W/NOZZLE</i>)
426-05-036-5001	DEFLECTOR
1086894	BALL BEARING
426-05-020-5001	CAP
438-01-033-0012	FAN
41-052	PULLEY, INCL:
901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
908-13-061-7669	BELT
426-05-116-5003	GASKET
426-05-072-5035	END PLATE - LH
901-01-060-0651	1/4-28 X 1/2" HEX HD SCREW
426-05-012-5005	BODY
901-01-060-0623	1/4-20 X 1" HEX HD SCREW
904-01-010-1620	FLAT WASHER
902-01-120-1034	1/4-20 HEX NUT
426-05-346-5003	FILTER ASSY
426-05-072-5034	END PLATE - RH
426-05-002-5001	ARBOR
426-05-063-5009	INSERT
904-15-101-7147	INT RET RING
426-05-083-5001	SHIM WASHER
438-01-033-0012	FAN
426-05-122-5001	SPRING

* NOT SHOWN ASSEMBLED

EARLY MODEL CHIP BLOWER



EARLY MODEL UPPER & LOWER BLADE GUIDES

REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
125	426-05-400-5009	UPPER WHEEL ASSY, INCL:	172	426-05-314-5005	BRACKET ASSY (See Service Note A),
126	901-04-150-1133	1/2-20 X 3/4" HEX SOC SET SCREW			INCL:
127	426-04-094-5002	TIRE	173	901-03-010-0755	5/16-18 X 3/4" HEX SOC HD SCREW
*	426-05-358-5002	UPPER HEADSTOCK, CONST OF:	174	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW
128	426-05-106-5005	SHAFT	175	426-05-110-5002	POST
129	406-03-079-0001	SPANNER NUT	176	426-05-354-5002	BLADE GUARD, INCL:
130	920-04-020-5383	BALL BEARING	177	902-01-120-1203	#10-32 HEX NUT
131	426-04-079-5006	JAM NUT	178	904-03-020-1775	3/16" INT TOOTH WASHER
132	426-05-058-5002	HEADSTOCK	179	426-05-014-5020	GUARD BRACKET
133	920-08-020-5336	BALL BEARING	180	901-02-010-7562	#10-32 X 5/16" ROUND HD SCREW
134	902-01-201-2558	BEARING NUT	181	901-02-010-0558	#08-32 X 1/4" ROUND HD SCREW
135	901-11-010-2371	3/8-16 X 2 1/2" SQUARE HD SCREW	182	902-01-120-1203	#10-32 HEX NUT
136	904-01-010-1606	3/8" FLAT WASHER	183	904-03-030-1795	3/16" EXT TOOTH WASHER
137	928-01-041-4148	COIL SPRING	184	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
138	426-05-084-5002	SLIDE	185	904-01-010-1609	FLAT WASHER
139	426-04-052-5001	GIB	186	426-04-014-5013	BRACKET
140	904-02-020-1704	3/8" LOCK WASHER	187	1200464	FINGER GUARD
141	901-01-060-0642	3/8-16 X 1" HEX HD SCREW	188	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
142	901-02-010-0567	#06-32 X 1/4" ROUND HD SCREW	189	901-02-010-0558	#08-32 X 1/4" ROUND HD SCREW
143	426-04-072-5009	TENSION SCALE	190	901-01-060-0649	5/16-18 X 1" HEX HD SCREW
144	904-01-010-1606	3/8" FLAT WASHER	*	426-05-355-5008	UPPER BLADE GUIDE (Current Models
145	426-05-409-5001	EXTENSION, INCL:			Only, See Service Note B), CONST OF:
146	905-01-010-2704	1/8" X 3/4" SPRING PIN	191	426-05-014-5036	BRACKET
147	901-04-530-6149	1/2-13 X 1 15/16 HEX SOC SET	192	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
		SCREW	193	904-01-010-1614	FLAT WASHER
148	902-01-020-1266	1/2-13 JAM NUT	194	901-03-010-0760	1/4-20 X 1 1/4" HEX SOC HD SCREW
149	928-01-041-4149	COIL SPRING	195	426-05-063-5008	PLATE
150	951-01-011-3992	POINTER	196	426-05-380-5001	ROLLER ASSY
151	426-04-074-5001	SPRING CAP			
152	426-04-072-5007	MOUNTNG PLATE			
153A	952-01-121-3268	TENSION SCREW (Early Models Only),	200	41-022	PULLEY, INCL:
		One End Threaded)	201	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
153	1201927	TENSION SCREW (Current Models,	202	0906506	BALL BEARING (See Service Note B)
		Only, Both Ends Threaded)	203	0906505	NEEDLE BEARING
154	905-01-010-2711	1/8" X 5/8" SPRING PIN (Current	204	901-01-060-0606	5/16-18 X 5/8" HEX HD SCREW
		Models Only)	205	426-05-079-5004	RETAINER
155B	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW	206	426-05-072-5022	PLATE
		(Early Models Only)	207	426-05-346-5002	FILTER ASSY
155	930-01-033-1336	HANDWHEEL (Current Models Only)	208	426-05-106-5014	SHAFT (See Service Note B)
155A	931-03-991-4766	HANDWHEEL (Early Models Only)	209	426-05-012-5004	BODY
156	902-01-010-5900	3/8-16 HEX NUT (Current Models Only)	*		UPPER BLADE GUIDE (See Service Note C)
157	904-02-020-1705	1/2" LOCK WASHER	220	901-03-012-2146	5/16-18 X 1 1/4" HEX SOC HD SCREW
158	901-01-060-0628	1/2-13 X 1" HEX HD SCREW	221	904-01-031-2926	FLAT WASHER
159	901-01-060-0617	3/8-16 X 1 1/2" HEX HD SCREW	222	426-05-072-5026	PLATE
160	426-04-112-5001	THREADED BUSHING	223	426-05-072-5021	PLATE
161	901-01-060-3102	3/8-16 X 1 3/4" HEX HD SCREW	224	426-05-072-5020	PLATE
162	901-02-120-7528	1/4-20 X 1/2" TRUSS HD SCREW (Early	225	426-05-014-5021	SUPPORT BRACKET
		Models Only)	226	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
163	931-04-010-3635	CLAMP HANDLE (Early Models Only)	227	1202640	BEARING ASSY
164	426-04-112-5002	CLAMP SCREW (Early & Intermediate	*		LOWER BLADE GUIDE (See Service Note
		Models Only)			C)
165	406-03-033-0001	HANDLE (Intermediate Models Only)	228	426-05-014-5018	BRACKET
166	406-03-122-0002	SPRING (Intermediate Models Only)	229	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
167	406-03-112-0003	SPECIAL SCREW (Intermediate Models	230	1202640	BEARING ASSY
		Only)	231	426-05-072-5021	PLATE
168	426-04-412-0001	KNOB ASSY (Current Models Only)	232	426-05-072-5020	PLATE
169	901-01-060-0617	3/8-16 X 1 1/2" HEX HD SCREW	233	904-01-031-2926	FLAT WASHER
170	426-04-112-5001	THREADED BUSHING	234	901-03-012-2146	5/16-18 X 1 1/4" HEX SOC HD SCREW
171	901-02-010-0593	#10-24 X 3/8" ROUND HD SCREW			


* NOT SHOWN ASSEMBLED

SERVICE NOTES:

A - Cast iron bracket and bracket cover are assembled and machined as a set. They cannot be furnished separately.

B- Ball bearing inner races (Ref No 202) are bonded to shaft (Ref No 209 with bearing grade Loctite).

C- All units after Serial No 173-5436, incorporate a new blade guide assembly (426-05-355-5008). This new assembly will replace either the early model upper or early model lower blade guides. The current model blade guide assembly is completely interchangeable with the early model guides.





REPLACEMENT PARTS


REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
300	426-04-063-5001	INSERT	337	426-04-079-5005	JAM NUT
301	426-05-091-5003	TABLE W/PIN, INCL:	338	901-01-060-0605	5/16-18 X 1/2" HEX HD SCREW
302	426-02-071-0001	PIN (<i>Current Models Only</i>)	339	426-05-072-5019	PLATE
302A	906-00-000-2438	1/8" PIPE PLUG (<i>Early Models Only</i>)	340	920-04-022-4022	BALL BEARING
303	426-04-095-5002	REAR TRUNNION	341	927-03-010-2653	KEY
304	904-02-020-1704	3/8" LOCK WASHER	342	426-05-106-5010	SHAFT
305	901-01-060-0617	3/8-16 X 1 1/2" HEX HD SCREW	343	426-05-013-5001	GEAR BOX
306	901-01-060-0649	5/16-18 X 1" HEX HD SCREW	344	920-04-022-4021	BALL BEARING
*	426-05-355-5008	LOWER BLADE GUIDE (<i>Current Models Only, See Service Note D</i>), CONST OF:	345	904-15-010-7024	EXT RET RING (<i>Current Models Only, See Service Note D</i>)
307	426-05-014-5036	BRACKET	345A	904-15-192-1593	RING (<i>Early Models Only, See Service Note D</i>)
308	426-05-380-5001	ROLLER ASSY	346	904-10-031-3803	WASHER
309	426-05-063-5008	PLATE	347	901-01-060-0648	3/8-16 X 1 1/4" HEX HD SCREW
310	904-01-010-1614	FLAT WASHER	348	426-04-112-5001	THREADED BUSHING
311	901-03-010-0760	1/4-20 X 1 1/4" HEX SOC HD SCREW	349	904-02-020-1704	3/8" LOCK WASHER
312	901-02-010-0558	#08-32 X 1/4" ROUND HD SCREW	350	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW
313	426-05-079-0001	RETAINER (<i>Current Models Only</i>)	351	426-05-014-5033	RETAINING BRACKET
313A	426-05-113-5002	WIPER	352	901-01-060-0650	3/8-16 X 7/8" HEX HD SCREW
313B	426-05-079-5001	RETAINER (<i>Early Models Only</i>)	353	901-04-130-0139	3/8-16 X 1 1/4" HEX SOC SET SCREW
313C	901-02-010-0571	#08-32 X 1 1/2" ROUND HD SCREW (<i>Early Models Only</i>)	354	902-01-020-5433	3/8-16 JAM NUT
314	901-02-010-0555	#08-32 X 3/8" ROUND HD SCREW (<i>Current Models Only</i>)	355	901-04-170-1102	5/16-18 X 1" HEX SOC SET SCREW
314A	426-05-104-5002	SPACER (<i>Early Models Only</i>)	356	902-01-020-5435	5/16-18 JAM NUT
315	901-04-020-0306	1/4-20 X 3/4" HEX SOC SET SCREW	357	426-05-067-5004	LEVER
316	902-01-120-1034	1/4-20 HEX NUT	358	426-05-108-5001	ROD
317	426-04-004-5003	STOP BAR	359	901-04-150-0231	5/16-18 X 3/8" HEX SOC SET SCREW
318	901-01-060-0642	3/8-16 X 1" HEX HD SCREW	360	426-05-014-5016	BRACKET
319	901-01-060-0632	7/16-14 X 2 3/4" HEX HD SCREW	361	901-04-140-0252	5/16-18 x 5/16" HEX SOC SET SCREW
320	426-02-027-0001	CLAMP SHOE	362	928-01-041-5302	SPRING
321	426-04-095-5001	FRONT TRUNNION	363	921-01-010-0028	STEEL BALL
322	402-05-075-5001	POINTER	364	426-05-031-5012	COVER
323	901-02-010-0502	1/4-20 X 1/4" ROUND HD SCREW	365	419-02-047-5001	YOKE FINGER
324	426-04-014-5012	BRACKET	366	438-01-004-0019	CABLE CLAMP
325	426-05-072-5032	SCALE	367	414-03-346-5001	PLUG
326	901-06-450-2252	#02 X 3/16" ROUND HD SCREW	368	901-01-060-0609	5/16-18 X 1 1/2" HEX HD SCREW
327	902-01-040-1004	7/16-14 JAM NUT	369	426-05-402-5003	YOKE, INCL:
328	426-05-072-5031	SHIFT & LUBE PLATE	370	905-01-010-2735	1/8" X 1 1/4" SPRING PIN
329	901-06-450-2250	#04 X 3/16" ROUND HD SCREW	375	426-05-106-5012	MOTOR PLATE SHAFT
330	426-05-400-5010	LOWER WHEEL ASSY, INCL:	376	904-15-010-7008	EXT RET RING
331	426-04-094-5002	TIRE	377	426-05-072-5028	PLATE
332	901-04-150-1133	1/2-20 X 3/4" HEX SOC SET SCREW	378	904-03-030-1656	5/16" EXT TOOTH WASHER
333	426-04-112-5001	THREADED BUSHING	379	1202596	STUD
334	901-01-060-0617	3/8-16 X 1 1/2" HEX HD SCREW	380	904-01-010-1620	FLAT WASHER
335	904-01-010-1615	FLAT WASHER	381	904-02-010-1703	5/16" LOCK WASHER
336	901-01-060-0648	3/8-16 X 1 1/4" HEX HD SCREW	382	902-01-020-5435	5/16-18 JAM NUT
			*	NOT SHOWN ASSEMBLED	

SERVICE NOTE:

D - Current retaining ring fits into a groove in the shaft. Early retaining ring gripped onto the shaft (no groove).



EARLY MODEL SPEED CONTROL



EARLY MODEL DOOR ASSY

REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
400	426-05-104-5008	SPACER	440	926-05-992-5504	MOTOR PULLEY ASSY (7/8" BORE), INCL:
401	920-24-061-5141	NEEDLE BEARING	440A	926-05-992-5513	MOTOR PULLEY ASSY (1 1/8" BORE) INCL:
402	426-05-051-5011	GEAR	441	901-04-150-0217	5/16-18 X 1/2" HEX SOC SET SCREW
403	904-15-010-7017	EXT RET RING	442	402-04-108-5020	ROD
404	426-05-028-5004	CLUTCH	443	928-01-601-8891	SPRING
405	0907876	RACE	444	402-07-079-5009	RETAINER
406	920-24-062-4024	NEEDLE BEARING	445	904-15-010-7025	EXT RET RING
407	426-05-351-5008	GEAR ASSY	446	426-05-079-5011	RETAINER
408	426-05-104-5010	SPACER	446	426-05-379-5002	RETAINER ASSY, CONST OF:
409	920-24-062-4025	NEEDLE BEARING	447	920-04-012-4029	BALL BEARING
410	920-04-022-4021	BALL BEARING	448	904-15-102-0180	INT RET RING
410	426-05-051-5008	GEAR	449	904-15-010-7042	EXT RET RING
411	0907875	SPACER	450	955-03-010-0003	WRENCH (Early Models Only)
412	426-05-051-5007	GEAR			
413	906-00-000-2439	PIPE PLUG (Current Models Only)			
413A	906-00-000-2439	PIPE PLUG (Early Models Only)			
414	906-05-013-1473	STREET ELL (Current Models Only)			
414A	906-07-013-1299	TEE (Early Models Only)			
414B	906-10-013-1298	NIPPLE (Early Models Only)			
415	920-04-022-4022	BALL BEARING	475	426-05-328-5001	CLUTCH ASSY
416	0905981	RETAINING RING	476	426-05-323-5003	CABLE & PULLEY ASSY, INCL: (See Service Note F)
417	0907875	SPACER	477	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
418	426-05-085-5002	SPINDLE	478	901-01-060-0623	1/4-20 X 1" HEX HD SCREW
419	927-01-010-2614	WOODRUFF KEY	479	902-01-120-1034	1/4-20 HEX NUT
420	920-04-022-4023	BALL BEARING	480	426-05-079-5012	TURNBUCKLE
421	426-05-072-5018	RETAINING PLATE	481	902-01-120-1216	#10-24 HEX NUT
422	901-01-060-0605	5/16-18 X 1/2" HEX HD SCREW	482	961-05-021-5005	CLIP W/ NUTS
423	902-07-010-7157	1 3/8-18 BEARING NUT	483	927-01-010-2633	KEY
424	426-05-080-5002	ROLLER	484	426-05-106-5021	SHAFT
425	905-04-011-1772	1/4" X 1 1/2" DOWEL PIN	485	902-01-020-5433	3/8-16 JAM NUT
426	426-05-067-5012	LEVER	486	901-04-150-0231	5/16-18 X 3/8" HEX SOC SET SCREW
*	1200506	SPINDLE PULLEY, CONST OF:	500	426-05-331-5006	DOOR ASSY (Early Models Only), INCL:
427	426-05-379-5001	SINGLE SHEAVE W/BEARING & RETAINER, INCL:	501	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
428	905-01-010-2728	3/8" X 1 1/4" SPRING PIN	502	961-04-021-5001	HINGE
429	926-05-992-5531	SINGLE SHEAVE ASSY, INCL:	503	904-03-020-1775	3/16" INT TOOTH WASHER
430	901-04-150-0232	1/4-20 X 3/8" HEX SOC SET SCREW	504	902-01-120-1203	#10-32 HEX NUT
431	402-04-108-5012	NYLON ROD	505	901-05-131-7351	#12 X 1/2" ROUND HD SCREW
432	426-04-079-5006	JAM NUT	506	961-04-042-3110	CATCH
433	426-05-108-5007	SUPPORT ROD (See Service Note E)	507	426-05-063-5006	HANDLE
434	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW	508	901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
*	426-05-379-5002	RETAINER ASSY, CONST OF:	509	904-03-030-1795	3/16" EXT TOOTH WASHER
435	426-05-079-5011	RETAINER	*		NOT SHOWN ASSEMBLED
436	920-04-012-4029	BALL BEARING			
437	904-15-102-0180	INT RET RING			
438	904-15-010-7042	EXT RET RING			
439	49-159	V-BELT - 55" OC			

ITEMS LISTED BELOW FOR EARLY MODLES ONLY

SERVICE NOTES:

E - Old style support rod was tubular steel; new style is steel angle. When replacing old style with new style, always replace in pairs

F - This part is no longer available, but can be replaced with service kit 426-05-323-5003 which includes all parts necessary to convert old style units to a new style speed control.

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.