





REPLACEMENT PARTS

REF NO.	PART NUMBER	DESCRIPTION
1	1347441	UPPER DOOR, INCL:
1A	1347431	NAMEPLATE
2	901-03-010-0229	1/4-20 X 1/2" HEX SOC HD SCR
3	1347442	HINGE PIN
4	1347502	TRACKING KNOB
5	1347439	MAIN FRAME, INCL:
6	1347432	WARNING LABEL
7	1347435	DIRECTION LABEL
8	1347500	CABLE STOP
9	1347496	CABLE
10	1347497	BRACKET
11	901-06-121-7383	#10-24 X 3/8" PAN HD SCR
12	1347495	INDICATOR
13	901-03-010-3322	#10-24 X 1/2" HEX SOC HD SCR
13A	1347434	TENSION SCALE
14	902-01-120-1034	1/4-20 HEX NUT
15	904-02-020-1702	1/4" LOCK WASHER
16	904-01-010-1603	1/4" FLAT WASHER
17	1347444	KNOB
18	901-04-140-9406	1/4-20 X 3/4" HEX SOC HD SCR
19	1347494	BUSHING
20	1347428	BALANCE SPRING
21	904-01-031-2929	FLAT WASHER
22	901-01-060-0645	3/8-16 X 3" HEX HD SCR
23A	1349128	CONTACTOR 1 PH (CMO)
23B	1349129	CONTACTOR 3 PH 220V (CMO)
23C	1349130	CONTACTOR 3 PH 440V (CMO)
24	1347440	PLATE
24A	1320102	(DIN 6797A) M4.3 EXT TOOTH WASHER (CMO)
24B	1313227	(DIN 7513B) M4 X 12MM CHEESE HD SCR (CMO)
25	402-07-111-5002	STUD
26	438-01-017-0101	SWITCH, MAGNETIC
27	402-07-104-5007	SPACER
28	1340100	SWITCH COVER ASSY
29	901-02-010-0567	#06-32 X 1/4" ROUND HD SCR
30	901-06-121-7381	#10-24 X 1/2" PAN HD SCR
31	901-01-060-0644	3/8-16 X 2 1/2" HEX HD SCR
32	902-01-040-1026	3/8-16 HEX NUT
33	901-04-150-1112	3/8-16 X 1/2" HEX SOC SET SCR
34	1347445	MOTOR PULLEY
35	1347429	MOTOR 1 PH
35A	1347430	MOTOR 3 PH


REF NO.	PART NUMBER	DESCRIPTION
36	428-08-079-0001	KEY
37	902-01-010-1300	5/16-18 HEX NUT
38	904-01-010-1604	5/16" FLAT WASHER
39	901-01-060-0642	3/8-16 X 1" HEX HD SCR
40	902-01-040-1026	3/8-16 HEX NUT
41	1347450	MOTOR BASE
42	904-01-010-1604	5/16" FLAT WASHER
42A	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR
43	1343419	3/8-16 HEX NUT
43A	1340597	3/8-16 X 3" HEX HD SCR
44	1347452	LOWER GUARD
45	902-04-010-1402	1/4-20 WING NUT
46	904-01-010-1610	FLAT WASHER
47	901-06-121-7381	#10-24 X 1/2" PAN HD SCR
48	1347451	DUST SPOUT
49	1347444	KNOB
50	901-04-140-9406	1/4-20 X 3/4" HEX SOC HD SCR
51	902-01-040-1026	3/8-16 HEX NUT
52	1347456	SPRING
53	901-01-060-0642	3/8-16 X 1" HEX HD SCR
54	902-01-040-1026	3/8-16 HEX NUT
55	904-02-020-1704	3/8" LOCK WASHER
56	1347454	PEDAL
57	1347455	SPECIAL SCR
58	904-01-010-1607	1/2" FLAT WASHER
59	1347453	BRAKE ASSY
60	1347443	LOWER DOOR
61	901-03-010-0229	1/4-20 X 1/2" HEX SOC HD SCR
62	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR
63	904-01-010-1604	5/16" FLAT WASHER
64	1347448	BLOCK
65	904-01-010-1604	5/16" FLAT WASHER
66	902-01-010-1300	5/16-18 HEX NUT
67	1347447	SUPPORT
68	901-03-010-0229	1/4-20 X 1/2" HEX SOC HD SCR
69	1347446	V-BELT
70	52-704	1 PH LVC BOX (EMO)
71	52-702	3 PH LVC BOX (EMO)
75	902-01-120-1216	#10-24 HEX NUT (CMO)
76	1320087	FLAT WASHER (CMO)
77	1349131	JUNCTION BOX (CMO)
78	1349132	STRAIN RELIEF (CMO)
79	1349133	STUD (CMO)
80	1349134	TERMINAL STRIP (CMO)

EMO = EARLY MODELS ONLY
CMO = CURRENT MODELS ONLY



REPLACEMENT PARTS

<u>REF.</u> <u>NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REF.</u> <u>NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
100	1243370	EXT RET RING	131	1347471	TABLE
101	1347485	PLATE	132	1347472	FENCE, <i>INCL.</i> :
102	901-01-060-0649	5/16-18 X 1" HEX HD SCR	133	1347473	KNOB
103	904-02-010-1703	5/16" LOCK WASHER	134	1347474	GUIDE BAR
104	904-01-010-1604	5/16" FLAT WASHER	135	904-02-020-1704	3/8" LOCK WASHER
105	1347490	KNOB	136	901-01-060-0642	3/8-16 X 1" HEX HD SCR
106	1347484	SHAFT	137	1342125	(DIN 912) M8 X 12MM HEX SOC HD SCR
107	901-01-060-0607	5/16-18 X 3/4" HEX HD SCR	138	1347475	BRACKET
108	1347488	BRACKET	139	901-01-060-0607	5/16-18 X 3/4" HEX HD SCR
109	901-03-010-0229	1/4-20 X 1/2" HEX SOC HD SCR	140	1347498	OILER
110	1347489	KNOB	141	1347479	LOCK RING
111	1347486	BLADE GUARD ASSY, <i>INCL.</i> :	142	1347478	BLOCK
112	1347487	COVER	143	1347477	GUIDE
113	901-03-040-8015	1/4-20 X 1/2" BUTTON HD SCR	144	1347480	BACKUP GUIDE
114	1347433	WARNING LABEL	145	1347498	OILER
115	1243370	EXT RET RING	146	1347476	BRACKET
116	1347481	BLOCK	147	904-01-010-1604	5/16" FLAT WASHER
117	1347482	BRACKET	148	901-01-060-0649	5/16-18 X 1" HEX HD SCR
118	904-01-010-1604	5/16" FLAT WASHER	149	1347493	5/8-11 X 1 3/4" HEX HD SCR
119	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR	150	904-01-010-1613	11/16" FLAT WASHER
120	901-01-060-0607	5/16-18 X 3/4" HEX HD SCR	151	1347491	TRUNNION, <i>INCL.</i> :
121	1347475	BRACKET	152	1310016	(DIN 1476) 5MM DRIVE SCR
122	901-01-060-0607	5/16-18 X 3/4" HEX HD SCR	153	1347449	SCALE
123	1347498	OILER	154	904-02-020-1704	3/8" LOCK WASHER
124	1342125	(DIN 912) M8 X 12MM HEX SOC HD SCR	155	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR
125	1347498	OILER	156	901-01-060-3120	1/2-13 X 1 3/4" HEX HD SCR
126	1347479	LOCK RING	157	904-02-020-1705	1/2" LOCK WASHER
127	1347478	BLOCK	157A	904-01-010-1607	1/2" FLAT WASHER
128	1347477	GUIDE	158	901-06-121-7381	#10-24 X 1/2" PAN HD SCR
129	1347483	SHAFT	159	1347499	POINTER
130	1347480	BACKUP GUIDE	160	1347492	BRACKET



<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
180	901-01-060-0616	1/2-13 X 1 1/2" HEX HD SCR
181	1347463	BRACKET
182	1347464	SHAFT
183	1347465	THRUST BEARING
184	1347466	TENSION TAB
185	1347427	TENSION SPRING
186	1347467	BRACKET
187	902-01-100-1028	1/2-13 HEX NUT
188	1347468	SHAFT
189	1347469	HANDWHEEL, INCL:
190	901-04-150-0217	5/16-18 X 1/2" HEX SOC SET SCR
191	1347459	SHAFT
192	1243370	EXT RET RING
193	920-04-021-6559	BALL BEARING
194	1347457	UPPER WHEEL
195	1347458	SPACER
196	920-04-021-6559	BALL BEARING
197	1246126	INT RET RING
198	1347460	RETAINER

<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
200	901-01-060-0642	3/8-16 X 1" HEX HD SCR
201	426-04-094-5002	TIRE
202	426-04-094-5002	TIRE
203	1347460	RETAINER
204	904-02-020-1704	3/8" LOCK WASHER
205	901-01-060-0642	3/8-16 X 1" HEX HD SCR
206	1347501	BUSHING
207	920-04-021-6559	BALL BEARING
208	1246126	INT RET RING
209	1347470	BRUSH
210	904-01-010-1604	5/16" FLAT WASHER
211	901-01-060-0649	5/16-18 X 1" HEX HD SCR
212	1347461	LOWER WHEEL
213	1347462	SHAFT
214	1243370	EXT RET RING
215	920-04-021-6559	BALL BEARING
216	901-01-060-3102	3/8-16 X 1 3/4" HEX HD SCR
217	902-01-040-1026	3/8-16 HEX NUT

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.