




28-708 GRAVITY FEED ATTACHMENT FOR 20" METAL CUTTING BAND SAWS

BS-4D

426-05-655-0005

Revised 11-1-85



Replacement Parts

Ref. No.	Part No.	Description
*	426-05-360-5001	Holder Ass'y., Const. Of:
1	426-05-060-5002	Holder
2	928-03-061-5890	Spring
3	905-01-010-2734	5/16 X 1" Roll Pin
4	928-03-061-5889	Spring
5	426-05-019-5001	Cam
6	931-01-991-6375	Handle
7	426-05-081-5002	Cable (65" Long)
8	426-05-402-5002	Yoke w/Pulley, Incl:
9	426-05-027-5001	Clamp
10	901-01-060-0640	3/8-16 X 3/4" Hex Hd. Scr.
11	426-05-081-5001	Cable (48" Long)
12	426-05-402-5001	Yoke w/Pulley
13	904-02-020-1705	1/2" Split Lockwasher
14	902-01-010-1282	1/2"-13 Hex Jam Nut
15	901-01-060-0620	1/2-13 X 1-1/4" Hex Hd. Scr.
16	426-05-067-5009	Lever
17	426-05-106-5015	Shaft
18	904-02-020-1705	1/2" Split Lockwasher
19	901-01-060-3130	1/2-13 X 3/4" Hex Hd. Scr.
20	426-05-412-5001	Locking Screw Assembly
21	901-01-060-0640	3/8-16 X 3/4" Hex Hd. Scr.
22	426-05-027-5001	Clamp
* *	28-826	Counterbalance Weight, Incl:
24	961-04-011-5023	#2 Skotch Fastener
25	426-05-332-5001	Counterbalance Weight
26	426-05-055-5001	Guide
27	901-01-060-0607	5/16-18 X 3/4" Hex Hd. Scr.
28	902-01-010-1300	5/16"-18 Hex Nut
29	904-02-010-1703	5/16" Split Lockwasher
30	426-05-014-5023	Bracket
31	901-01-060-0607	5/16-18 X 3/4" Hex Hd. Scr.
32	904-02-010-1703	5/16" Split Lockwasher
33	902-01-010-1300	5/16"-18 Hex Nut
34	902-01-010-1282	1/2"-13 Hex Jam Nut
35	904-02-020-1705	1/2" Split Lockwasher
36	426-05-067-5008	Lever
37	402-05-067-5006	Treadle
38	901-01-060-0616	1/2-13 X 1-1/2" Hex Hd. Scr.
39	901-01-060-0624	1/2-13 X 2-3/4" Hex Hd. Scr.
40	904-01-010-1618	9/16 X 1-3/8" X 12 ga. Washer
41	426-05-104-5004	Spacer
42	426-05-104-5006	Spacer
43	904-02-020-1705	1/2" Split Lockwasher
44	902-01-010-1282	1/2"-13 Hex Jam Nut

* NOT SHOWN ASSEMBLED

* * NOT SUPPLIED WITH #28-708 GRAVITY FEED ATTACHMENT
BUT AVAILABLE AS AN ACCESSORY #28-826 COUNTERBALANCE WEIGHT.