





REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
ITEMS LISTED BELOW FOR CURRENT MODELS ONLY			ITEMS LISTED BELOW FOR EARLY MODELS ONLY		
1	422-04-055-0001	FRONT GUIDE RAIL	51	422-04-055-0001	FRONT GUIDE RAIL
2	901-09-090-6138	3/8-24 X 2 3/4" FILL HD SCREW	52	901-09-090-6138	3/8-24 X 2 3/4" FILL HD SCREW
3	422-04-104-0001	SPACER	53	422-04-104-5009	SADDLE BLOCK
4	902-01-010-1207	3/8-24 HEX NUT	54	902-01-010-1207	3/8-24 HEX NUT
5	422-04-055-0002	REAR GUIDE RAIL	55	422-04-055-0002	REAR GUIDE RAIL
6	961-01-010-7462	END PLUG	56	426-04-343-5001	FENCE BODY - STEEL
10	901-01-060-0605	5/16-18 X 1/2" HEX HD SCREW	57	422-04-012-5001	CLAMP BLOCK
11	904-01-010-1620	FLAT WASHER	58	961-01-010-7462	END PLUG
12	422-04-010-5002	BLOCK	59	905-04-101-4453	3/8" X 1 15/16" DOWEL PIN
13	905-04-071-4459	1/4" X .797 DOWEL PIN	61	422-04-112-5002	SPECIAL SCREW
14	928-01-041-4118	COIL SPRING	62	928-01-041-4117	COIL SPRING
15	422-04-027-0001	HOOK	63	905-04-101-4453	3/8" X 1 15/16" DOWEL PIN
16	422-04-067-5001	LEVER	64	901-04-150-0202	1/4-20 X 1/2" HEX SOC SET SCREW
17	426-04-043-0001	FENCE BODY - EXTRUDED	65	422-04-027-5002	CLAMP
18	422-04-108-0001	REAR CLAMP ROD	66	422-04-351-5002	PINION ASSY
19	901-01-060-0677	3/8-24 X 1/2" HEX HD SCREW	66A	901-02-010-0569	#08-32 X 3/16" ROUND HD SCREW
20	904-01-033-1451	FLAT WASHER	67	931-01-011-4091	BALL HANDLE
21	901-02-010-0551	#10-32 X 1/4" ROUND HD SCREW	68	422-04-111-5001	STUD
22	951-01-020-7849	POINTER	69	422-04-042-5001	ECCENTRIC
23	928-01-021-5301	SPRING	70	931-02-010-3622	HAND KNOB
24	422-04-105-5001	SLEEVE	71	904-01-010-1614	FLAT WASHER
*	422-04-312-5008	CLAMP ASSY, CONST OF:	72	951-01-010-7802	POINTER
25	422-04-071-5005	PIN	73	904-01-010-1610	FLAT WASHER
26	422-04-071-5004	PIN	74	901-02-010-0551	#10-32 X 1/4" ROUND HD SCREW
27	422-04-111-5002	LEVER	75	904-01-033-1451	FLAT WASHER
28	931-01-011-4091	BALL HANDLE	76	901-01-060-0677	3/8-24 X 1/2" HEX HD SCREW
29	422-04-351-5002	PINION ASSY	77	426-04-108-5002	REAR CLAMP ROD
30	928-01-201-5898	SPRING	78	904-01-010-1620	FLAT WASHER
31	422-04-327-5002	FRONT CLAMP ASSY	79	901-01-060-0629	5/16-18 X 3/8" HEX HD SCREW
32	904-08-021-4550	RUBBER BUSHING	80	422-04-010-5002	BLOCK
33	928-01-041-4123	SPRING	81	905-04-071-4459	1/4" X .797 DOWEL PIN
34	422-04-012-5005	CLAMP BODY	82	422-04-027-0001	HOOK
35	422-04-042-5002	ECCENTRIC	83	928-01-041-4118	COIL SPRING
36	901-04-160-6218	1/4-20 X 1/4" HEX SOC SET SCREW	84	422-04-067-5001	LEVER

* NOT SHOWN ASSEMBLED

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.