




REPLACEMENT PARTS

<u>REF NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REF NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1341630	COVER SCR	28	904-01-010-1604	5/16" FLAT WASHER
2	1243526	(DIN 125) 8.4MM FLAT WASHER	29	1243321	(DIN 916) M6 X 10MM HEX SOC SET SCR
3	1341626	COVER	30	1341628	DRIVE WHEEL
4	1341641	NAMEPLATE	31	1246017	(DIN 933) M8 X 30MM HEX HEAD SCR
5	1340679	WARNING LABEL	32	1246135	(DIN 963) M6 X 16MM FLAT HEAD SCR
6	OPTIONAL	BELT	33	1246161	(DIN 915) M6 X 15MM HEX SOC SET SCR
7	1246196	(DIN 471) EXT RET RING	34	1341644	TABLE
8	1341629	IDLER W/BEARING WHEEL	35	1243526	(DIN 125) 8.4MM FLAT WASHER
8A	1341631	IDLER SHAFT	36	1341647	SPACER
9	1341669	COVER	37	1340656	LEVER
10	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR	38	1340657	COIL SPRING
11	1340546	ROTATION LABEL	39	1340658	SCR
12	1341625	MAIN FRAME	40	1341627	MOTOR
13	1246196	(DIN 471) EXT RET RING	41	1320151	SWITCH
14	1341629	IDLER W/BEARING WHEEL	42	1342001	(DIN 7971B) #2.9 X 6.5MM PAN HEAD SCR
15	1341633	IDLER SHAFT	43	1340667	SWITCH GUARD
16	1341640	SPRING	44	1341648	SWITCH BOX
17	1310310	(DIN 1481) M3 X 18MM ROLL PIN	44A	1340677	NAMEPLATE
18	1341634	SUPPORT	45	1340645	CAPACITOR
19	1341636	TRACKING ADJUST SCR	45A	438-01-007-0042	WIRE NUT
20	1341635	SPRING	46	1341649	SWITCH COVER
21	1341632	SPRING	47	1340648	(DIN 7982B) M3 X 10MM PAN HEAD SCR
22	1341652	RETAINING RING	48	1320130	STRAIN RELIEF
23	1341643	WASHER	49	1341654	CORD W/TERMINAL
24	1341637	BOLT	51	1341645	BASE
25	1341996	(DIN 985) M10 LOCK NUT	52	1341639	RUBBER FOOT
26	1341638	PLATEN	53	1246157	(DIN 7980) 8.1MM LOCK WASHER
27	1341441	(DIN 912) M4 X 12MM SOC HEAD SCR	54	1246034	(DIN 933) M8 X 20MM HEX HEAD SCR
			55	428-06-101-0002	3MM HEX WRENCH

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.