






REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
1	31-401	TILT TABLE, INCL:	64	406-03-054-0015	GUARD
2	406-03-137-0004	NAMEPLATE	65	406-03-004-0001	CLAMP BAR
3	901-06-450-2250	#04 X 3/16" DRIVE SCREW	66	406-03-054-0004	GUARD PAN
4	406-03-395-0003	TRUNNION ASSY, INCL:	68	902-01-201-2560	1.00-20 HEX NUT
5	1231522	PIN	69	406-01-362-0006	DRIVE DRUM
7	901-04-193-1064	1/4-28 X 1" HEX SOC SET SCREW	70	406-03-036-0002	DEFLECTOR
8	1087397	POINTER	71	406-03-054-0013	GUARD
10	901-02-010-0561	#10-32 X 3/8" ROUND HD SCREW	72	406-03-036-0001	DUST PLATE
11	418-03-055-0001	KEY	73	904-02-010-1726	LOCK WASHER
12	901-01-060-0608	5/16-18 X 7/8" HEX HD SCREW	74	901-03-010-8072	#06-32 X 3/4" HEX SOC HD SCREW
12A	904-01-010-1620	FLAT WASHER	75	901-03-010-3318	#10-32 X 3/8" HEX SOC HD SCREW
13	406-03-112-0006	SPECIAL SCREW	76	406-03-079-0001	SPANNER NUT
14	406-03-122-0002	SPRING	77	406-03-104-0003	SPACERS
15	406-03-033-0002	RATCHET HANDLE	78	920-04-020-5360	BALL BEARING
16	902-01-201-2579	7/16-14 HEX NUT	79	406-03-027-0001	CLAMP RING
17	904-01-010-1606	7/16" FLAT WASHER	80	406-03-012-0001	HOUSING
18	406-03-111-0002	STUD	81	901-01-060-0639	7/16-14 X 3 1/2" HEX HD SCREW
19	406-03-412-0007	ADJUSTING SCREW	82	406-03-106-0002	SHAFT
20	406-03-138-0003	KNOB	83	927-03-010-2650	1 3/8" KEY
21	904-07-010-5567	1/2" FIBER WASHER	84	920-04-020-5348	BALL BEARING
22	901-03-010-0229	1/4-20 X 1/2" HEX SOC HD SCREW	85	902-07-030-7171	.802-28 BEARING NUT
23	406-03-049-0002	BRACKET	90	406-03-005-0004	BASE
24	905-01-010-2705	7/32X 1 7/8" SPRING PIN	91	901-01-060-0645	3/8-16 X 3" HEX HD SCREW
25	418-03-088-0001	STOP BLOCK	92	904-01-010-1606	7/16" FLAT WASHER
26	406-03-071-0002	STEEL PIN	93	902-01-010-5900	3/8-16 JAM NUT
27	406-03-067-0001	LEVER	94	901-03-011-9984	3/8-24 X 1 1/2" HEX SOC HD SCREW
*	1086998	SCREW ASSY, CONST OF:	95	901-04-020-8670	STOP PIN
28	902-02-010-1304	7/16-14 SQUARE NUT	96	902-01-201-2579	7/16-14 HEX NUT
29	406-03-122-0001	SPRING	97	904-01-010-1606	7/16" FLAT WASHER
30	406-03-031-0001	SLEEVE	98	901-01-060-0688	3/8-24 X 3/4" HEX HD SCREW
31	928-01-021-3381	COIL SPRING	99	406-03-354-0020	BELT GUARD
32	1086990	SCREW, INCL:	100	901-03-040-8015	FLAT WASHER
33	905-01-010-2704	1/8" X 3/4" SPRING PIN	101	904-01-010-1614	1/4" FLAT WASHER
34	904-10-031-3804	COLLAR	102	902-01-120-1034	1/4-20 HEX NUT
35	904-07-011-5711	7/16" FIBER WASHER	103	41-064	PULLEY - 4" OD, 3/4" BORE PULLEY, INCL:
37	406-03-020-0001	FLANGE	104	901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
38	406-03-438-0001	CRANK, INCL:	105	49-035	V-BELT - 55-3/8" OC
39	901-04-190-0225	5/16-18 X 1/4" HEX SOC SET SCREW	106	406-00-752-0001	WARNING DECAL
40	0919783	SCREW			
41	406-03-138-0004	KNOB			
42	904-01-031-2925	FLAT WASHER			
43	420-01-111-0003	STUD			
44	406-03-054-0014	GUARD			
47	901-06-450-2250	#04 X 3/16" DRIVE SCREW			
48	951-02-010-7822	SCALE			
49	406-03-104-0002	IDLER ASSY, CONST OF:			
50	406-03-108-0001	DRUM SHAFT, INCL:			
50A	902-01-281-7295	1/4-20 HEX NUT			
50B	902-01-020-1227	1/2-20 JAM NUT			
51	406-03-362-0003	IDLER DRUM (PAIR)			
52	406-03-104-0002	SPACER			
55	406-03-014-0001	IDLER DRUM BRACKET, INCL:			
56	902-07-020-7176	BEARING CLOSURE NUT			
57	920-04-010-7273	BALL BEARING			
58	905-01-010-5085	5/16" X 3/4" SPRING PIN			
59	406-03-071-0001	KEY			
60	406-03-091-0001	PLATEN			
61	901-01-060-0640	3/8-16 X 3/4" HEX HD SCREW			
62	904-01-010-1605	3/8" FLAT WASHER			
63	901-04-340-7605	SCREW			


* NOT SHOWN ASSEMBLED



31-014 WOOD FENCE



31-403 BACKSTOP



50-114 STAND

REPLACEMENT PARTS

<u>REF NO</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
*	31-014	WOODEN FENCE, CONST OF:
150	406-03-043-0001	WOODEN FENCE
151	406-03-014-0002	BRACKET
152	406-03-033-0001	HANDLE
153	902-04-030-1408	7/16-14 SERRATED NUT
154	406-03-112-0003	SPECIAL SCREW
155	406-03-122-0002	SPRING
156	904-10-031-2097	WASHER
157	420-01-111-0003	STUD
158	904-10-031-3803	WASHER
159	901-02-030-0409	5/16-18 X 1 1/4" FLAT HD SCREW
*	31-403	BACKSTOP, CONST OF:
180	406-03-088-0001	BACK STOP
181	406-03-014-0004	LINK
182	904-10-031-2097	WASHER
183	901-09-070-6124	7/16-14 X 3.06 HEX HD SCREW
184	406-03-033-0001	HANDLE
185	432-01-027-0004	SERRATED NUT
186	406-03-112-0003	SPECIAL SCREW
187	406-03-122-0002	SPRING
188	904-10-031-2097	WASHER
189	420-01-111-0003	STUD
*	50-114	STAND, CONST OF:
227	901-01-060-0645	3/8-16 X 3" HEX HD SCREW
228	904-01-010-1606	7/16" FLAT WASHER
229	902-01-010-5900	3/8-16 JAM NUT
230	1087794	RIVET
231	406-03-137-0003	NAMEPLATE
232	436-01-318-0011	CABINET
233	901-06-443-1806	#10-24 X 1/2" HEX HD SCREW
234	436-01-123-0002	SIDE PANEL
235	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCREW
236	436-01-004-0006	MOTOR BRACKET
237	902-01-503-1514	5/16-18 FLANGE NUT
240	438-01-011-0020	INSULATOR
241	901-01-060-0607	5/16-18 X 3/4" HEX HD SCREW
242	902-01-503-1514	5/16-18 FLANGE NUT
243	436-01-305-0001	SUB BASE
246	436-01-074-0002	HOLE PLUG
247	438-01-011-0065	PLUG

ITEMS LISTED BELOW USED TO MOUNT MOTOR TO MOTOR BRACKET

**	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCREW
**	902-01-010-1300	5/16-18 HEX NUT
**	904-01-010-1605	3/8" FLAT WASHER
**	904-02-010-1703	5/16" LOCK WASHER

* NOT SHOWN ASSEMBLED
 ** NOT SHOWN

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.