




REPLACEMENT PARTS

Ref.

No.	Part No.	Description
*	406-03-362-0006	IDLER DRUM BRACKET ASSY, CONST OF
1	406-03-014-0013	IDLER DRUM BRACKET
1A	902-07-020-7176	1 5/8-20 BEARING NUT
2	905-01-010-5085	SPRING PIN
3	406-03-071-0001	KEY
5	920-04-010-7273	BEARING
6	406-03-104-0002	SPACER
7	406-03-362-0003	IDLER DRUM (PAIR)
8	406-03-108-0001	IDLER DRUM SHAFT, INCL:
8A	902-01-281-7295	1/4-20 HEX NUT
8B	902-01-020-1227	1/2-20 HEX JAM NUT
9	406-03-104-0002	SPACER
15	406-03-067-0001	BELT TENSION LEVER
16	406-03-071-0002	BELT TENSION LEVER PIN
17	904-07-010-5567	1/2" FIBER WASHER
18	406-03-138-0003	KNOB
19	406-03-412-0007	BELT ADJUSTING SCREW ASSEMBLY
20	406-03-049-0004	FRAME
21	951-02-010-7822	TILT SCALE
22	901-06-450-2250	04 X 3/16" ROUND HEAD SCREW
23	901-03-010-0229	1/4-20 X 1/2" SOC HEAD SCREW
24	905-01-010-2705	SPRING PIN
25	418-03-088-0001	STOP BLOCK
*	31-401	TILTING TABLE ASSEMBLY, INCL:
27	406-03-091-0007	TABLE
27A	406-03-137-0006	NAMEPLATE
27B	901-06-450-2250	04 X 3/16" ROUND HEAD SCREW
28	406-03-395-0003	TRUNNION, INCL:
29	418-03-055-0001	KEY
30	901-02-010-0561	10-32 X 3/8" ROUND HEAD SCREW
32	1087397	POINTER
33	901-04-193-1064	1/4-28 X 1" HEX SOC SET SCREW
35	1231522	PIN
36	901-01-060-0608	5/16-18 X 7/8" HEX HD SCREW
36A	904-01-010-1620	5/16" FLAT WASHER
37	406-03-122-0002	SPRING
38	406-03-112-0006	SPECIAL SCREW
39	406-03-111-0002	STUD
40	904-01-013-1884	3/8" FLAT WASHER
41	902-01-201-2579	7/16-14 HEX NUT
42	406-03-033-0002	RATCHET HANDLE
*	1086998	SCREW ASSEMBLY
45	902-02-010-1304	7/16-14 SQUARE NUT
46	406-03-122-0001	SPRING
47	406-03-031-0001	SLEEVE
48	928-01-021-3381	COIL SPRING
49	1086990	SCREW
50	904-10-031-3804	COLLAR
51	905-01-010-2704	SPRING PIN
52	904-07-011-5711	FIBER WASHER
54	406-03-020-0001	FLANGE
55	406-03-438-0001	CRANK
56	901-04-190-0225	5/16-18 X 1/4" HEX SOC SET SCREW
57	n 919783	SCREW
59	406-01-362-0006	DRIVE DRUM (PAIR)
60	406-03-079-0001	SPANNER NUT
61	406-03-104-0003	SPACERS
62	920-04-020-5360	BEARING
63	406-03-027-0001	CLAMP RING
64	406-03-012-0001	HOUSING
65	901-01-063-1882	7/16-14 X 3 1/2" HEX HEAD SCREW
66	420-01-106-0003	DRIVE SHAFT, INCL:
66A	904-15-013-1047	EXT RET RING
66B	902-01-023-1475	LOCK NUT
67	927-03-010-2656	KEY
68	920-04-020-5348	BEARING
69	902-07-030-7171	BEARING NUT
70	420-01-354-0005	BELT GUARD
71	901-03-040-8015	1/4-20 X 1/2" BUT HEAD SCREW
71A	904-01-010-1620	5/16" FLAT WASHER
72	41-074	ARBOR PULLEY, 4-1/2IN OD-3/4B, INCL:
73	901-04-150-0206	5/16-18 X 5/8" HEX SOC SET SCREW
74	49-035	55-3/8" OC V-BELT
78	420-01-005-0002	BASE
79	904-02-020-1704	3/8" LOCKWASHER
80	901-01-060-0648	3/8-16 X 1 1/4" HEX HEAD SCREW
81	901-03-011-9984	3/8-24 X 1 1/2" SOC HEAD SCREW
82	904-01-013-1884	3/8" FLAT WASHER


Ref.

No.	Part No.	Description
83	901-01-060-0688	3/8-24 X 3/4" HEX HEAD SCREW
84	901-04-020-8670	STOP PIN
85	902-01-201-2579	7/16-14 HEX NUT
90	416-02-054-0005	GUARD
91	961-01-010-7499	PLUG
94	420-01-111-0003	STUD
100	416-02-327-0002	CLAMP W/PINS
101	n 422-04-075-5001	POINTER
102	901-02-010-0502	1/4-20 X 1/4" ROUND HEAD SCREW
103	406-03-138-0004	KNOB
104	928-01-021-4125	SPRING
105	904-01-031-2925	FLAT WASHER
*	416-02-395-0001	TRUNNION ASSEMBLY, CONST OF:
106	416-02-095-0001	TRUNNION
107	951-02-010-7820	TILT SCALE
108	901-06-450-2250	04 X 3/16" ROUND HEAD SCREW
109	904-01-010-1614	FLAT WASHER
110	901-01-060-0612	1/4-20 X 5/8" HEX HEAD SCREW
111	31-034	DISC ASSY
112	901-03-030-0761	1/4-20 X 1/2" FLAT HEAD SCREW
113	901-04-190-0201	5/16-18 X 5/16" HEX SOC SET SCREW
114	416-02-091-0002	TILTING TABLE
117	416-02-095-0001	TRUNNION
118	904-01-010-1614	FLAT WASHER
119	901-01-060-0612	1/4-20 X 5/8" HEX HEAD SCREW
122	901-01-063-1883	3/8-16 X 3" HEX HEAD SCREW
123	904-01-013-1884	1/4" FLAT WASHER
124	902-01-010-5900	3/8-16 HEX JAM NUT

ACCESSORIES: (Optional)

126	31-421	2-12IN PSA DISC 50G
	31-422	2-12IN PSA DISC 80G
	31-423	2-12IN PSA DISC 120G
127	31-402	6X48 AL OXIDE 80G
	31-404	6X48 AO BELT 100G
	31-405	6X48 AO BELT 50G
INCLUDED WITH STAND AND ELECTRICALS:		
140	41-033	PULLEY - 5/8"BORE
141	901-04-150-0206	5/16-18 X 5/8" HEX SOC SET SCREW
*	NOT SHOWN ASSEMBLED	

REPLACEMENT PARTS




Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
150	901-04-340-7605	SCREW
151	406-03-054-0022	GUARD
152	406-03-091-0006	PLATEN
153	904-01-010-1605	3/8" FLAT WASHER
154	901-01-060-0640	3/8-16 X 3/4" HEX HEAD SCREW
155	406-03-138-0004	KNOB
156	904-01-031-2925	FLAT WASHER
157	420-01-111-0003	STUD
158	406-03-054-0021	GUARD
162	406-03-054-0023	GUARD
163	904-02-010-1726	LOCK WASHER
164	901-03-010-8072	06-32 X 3/4" SOC HEAD SCREW
165	406-03-036-0007	DEFLECTOR
166	901-03-010-3318	10-32 X 3/8" SOC HEAD SCREW
169	406-03-036-0006	DUST PLATE
171	406-03-054-0020	GUARD PAN
172	406-03-004-0001	CLAMP BAR
173	406-00-752-0002	WARNING DECAL


Ref.

No. Part No. Description
ACCESSORIES: (Optional)

*	31-403	BACKSTOP, ASSEMBLY, CONST OF:
175	406-03-088-0002	BACKSTOP
176	406-03-014-0014	LINK
177	904-10-031-2097	COLLAR WASHER
178	901-09-070-6124	7/16-14 X 3" HEX HEAD SCREW
179	420-01-111-0003	STUD
180	904-10-031-2097	COLLAR WASHER
181	432-01-027-0004	NUT
182	406-03-033-0001	HANDLE
183	406-03-122-0002	SPRING
184	406-03-112-0003	SPECIAL SCREW
*	31-014	FENCE, CONST OF:
190	406-03-043-0001	WOODEN FENCE
191	901-02-030-0409	5/16-18 X 1 1/4" FLAT HEAD SCREW
192	406-03-014-0015	BRACKET
193	406-03-112-0003	SPECIAL SCREW
194	406-03-122-0002	SPRING
195	406-03-033-0001	HANDLE
196	902-04-030-1408	7/16-14 SERRATED NUT
197	904-10-031-2097	COLLAR WASHER
198	420-01-111-0003	STUD
199	904-10-031-3803	COLLAR WASHER
*	34-568	CLAMP ATTACHMENT (FOR 34-895 MITER GAGE)
*	34-895	MITER GAGE
*	NOT SHOWN ASSEMBLED	
**	NOT SHOWN	



REPLACEMENT PARTS



Ref.

No.	Part No.	Description
*	50-115	BASIC STAND, CONST OF:
227	901-01-063-1883	3/8-16 X 3" HEX HEAD SCREW
228	904-01-013-1884	3/8" FLAT WASHER
229	902-01-010-5900	3/8-16 HEX JAM NUT
230	1087794	RIVIT
231	406-03-137-0005	NAMEPLATE
232	436-01-318-0023	CABINET ASSEMBLY
233	901-06-443-1806	10- X 1/2" HEX HD SCREW
234	436-01-123-0008	SIDE PANEL
235	901-11-020-0834	5/16-18 X 3/4" CARRIAGE BOLT
236	436-01-004-0022	MOTOR BRACKET
237	902-01-503-1514	5/16-18 FLANGE HEX NUT
240	438-01-011-0020	INSULATOR
241	901-01-060-0607	5/16-18 3/4" HEX HEAD SCREW
242	904-01-010-1620	5/16"FLAT WASHER

Ref.

No.	Part No.	Description
243	436-01-305-0001	SUBBASE
244	902-01-503-1514	5/16-18 FLANGE HEX NUT
246	436-01-074-0002	HOLE PLUG
247	438-01-011-0065	PLUG
**	901-11-020-0834	5/16-18 3/4" CARRIAGE BOLT
		For Mounting Motor To Motor Bracket
**	902-01-010-1300	5/16-18 HEX NUT
		For Mounting Motor To Motor Bracket
**	904-03-030-1656	5/16" EXT TOOTH WASHER
		For Mounting Motor To Motor Bracket
*		NOT SHOWN ASSEMBLED
**		NOT SHOWN

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.