


# REPLACEMENT PARTS

Ref.			Ref.		
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	901615	PAN HD SCREW	86	1349810	STUD
2	901612	END COVER	87	1349811	BUMPER
3	1343271	PAD	88	899887	KNOB
4	901613	MOTOR HOUSING	89	901688	HEX LOCKNUTF
5	1347143	BRUSH	90	901440	BEVEL TRUNNION
6	1347142	BRUSH HOLDER	91	1246175	HEX HD SCREW
7	1343504	LOCKNUT	92	901644	BRACKET
8	901614	PAN HD SCREW	93	901442	PINCH GUARD
9	1343538	LOCK WASHER	94	1246045	CHEESE HD SCREW
10	1246102	FLAT WASHER	95	901646	BEVEL BRACKET
11	1343267	WAVE WASHER	96	1349817	SPRING SLEEVE
12	920-08-020-5352	BEARING	97	1349816	SPRING
13	1348661	SPECIAL WASHER	98	n 1310159	M4 X .7 X 6MM PAN HD SCREW
14	1348660	SPECIAL WASHER	99	901647	POINTER
15	901616	FIELD	100	901648	O-RING
16	1346935	HEX HD SCREW, CF	101	1345533	PIN
17	901617	ARMATURE	102	901689	SHAFT
18	1310042	BEARING	103	1246051	HEX SOC HD SCREW
19	1347138	FAN BAFFLE	104	1246016	HEX HD SCREW
20	901619	FRONT BRG HOUSING	105	1246157	LOCK WASHER
21	901620	MOTOR PULLEY	106	1349481	HEX SOC HD SCREW
23	1345433	PLATE	107	901649	BEVEL SCALE
24	899898	LOWER GUARD	108	901650	DUST SHIELD
25	1342998	SPRING	109	904421	TABLE/LOWER GUARD ASSY., INCL.: REF. 61, 65, 70, 121
26	1343053	PAN HD SCREW	110	903287	BASE
28	1343054	CARRIAGE HD SCREW	111	1310016	DRIVE SCREW
29	n 1342989	BLADE BOLT	112	899885	SCALE
30	1347150	OUTER FLANGE	113	1347115	LOCK PLATE
31	n 903441	SEE CATALOG	114	1347116	POINTER
32	903441	UPPER ARM, INCLS REF. 22 & 27	115	1347119	PAD
33	1344933	ROUND HD SCREW	116	1347117	BRACKET
34	900243	DUST BAG	117	899913	SOFT GRIP HANDLE
35	1243398	HEX NUT	118	1243526	FLAT WASHER
36	1330682	CLAMP	119	1246017	HEX HD SCREW
37	1243394	CHEESE HD SCREW	121	901655	M6 X 1 DOWEL PIN
38	1243456	HEX NUT	122	1347120	PIVOT STUD
39	1246015	HEX HD SCREW	123	1243502	FLAT WASHER
40	901622	KEY	124	1343275	WAVE WASHER
41	901623	ARBOR SHAFT	125	1341996	LOCKNUT
42	883095	BEARING	126	901656	EXTENSION BRACE
43	1341061	EXT RET RING	127	1330410	SPRING PIN
44	901624	BEARING RETAINER	128	1243530	HEX SOC HD SCREW
45	1343545	FLAT WASHER	129	901657	FENCE
46	1347527	PAN HD SCREW	130	901653	GUARD LINKAGE
47	901625	HELICAL GEAR	131	1349953	SPECIAL SCREW
48	1343259	NEEDLE BEARING	132	901645	DUST CHUTE PIN
49	901626	GASKET	133	901643	DUST CHUTE
50	901687	RTNG EXTL IN RING	134	901690	SLEEVE BUSHING
51	901627	SPRING	135	900023	RETAINING RING
52	901628	ARBOR LOCK PIN	136	901441	STOP BRACKET
53	901629	PINION SHAFT PULLEY	137	901443	HAT BUSHING
54	1340654	FLAT WASHER	138	1243426	STEEL BALL
55	903286	HEX NUT	139	901691	CPRSN SPRING
56	901630	BELT	140	1345430	GUARD BUMPER
57	901631	KEY	141	901817	SMALL INSULATING PAPER
58	901632	JACKSHAFT	142	901818	LARGE INSULATING PAPER
59	1342607	DOWEL PIN	143	1349489	PLATE
60	901633	GEAR HOUSING CAP	144	899854	NAME PLATE
61	1243520	LOCK WASHER	145	899923	DEC PLATE
62	1246104	HEX SOC HD SCREW	146	900264	FRONT CASTING DEC PLATE
63	901634	MOTOR MOUNT COVER	147	899864	WARNING LABEL
64	1310157	PAN HD SCREW	148	901823	BELT GUARD DEC PLATE
65	1246140	FLAT WASHER	150	1348257	WARNING LABEL
66	901636	PAN HD SCREW	151	1246161	HEX SOC SET SCREW
67	n 904368	HANDLE SET - CMO, INCL.: REF. 71	152	901-02-010-0561	ROUND HD SCREW
	901637	TOP HANDLE, EMO	153	900227	FLAT WASHER
68	901685	PAN HD SCREW	154	1345550	CLAMP CUP
69	899883	SWITCH	155	1345549	SUPPORT
70	1246004	HEX SOC HD SCREW	156	n 36-221	SHAFT
71	n 904368	HANDLE SET - CMO, INCL.: REF. 67	157	899862	KNOB SOFT GRIP
	901638	LOWER HANDLE, EMO	158	1345548	RETAINER
72	901639	HANDLE MOUNT COVER	159	1246118	SPRING PIN
73	1246117	FLAT HD SCREW	160	1246056	SCREW
74	1341235	CHEESE HD SCREW	180	1342906	WRENCH
75	1320101	EXT TOOTH WASHER	191	1234381	RAIL
76	1320102	EXT TOOTH WASHER	192	900571	STOP BLOCK
78	1345695	CORD CLAMP	193	903834	THUMB SCREW
79	1343019	3/8" GROMMET	194	900574	RETAINER
80	901640	HANDLE MOUNT			
81	901641	POWER CORD			
82	438-01-007-0042	WIRE NUT			
83	901642	POWER JUMPER			
84	n 911769	HANDLE			
85	1310311	SPRING PIN			




---

#### STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

*This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.*