



REPLACEMENT PARTS

Ref.			Ref.		
No.	Part No.	Description	No.	Part No.	Description
1	34-916	FENCE	45	422-27-001-0002	ADAPTOR
2	400-06-327-0001	CLAMP ASSY	46	904-02-010-1716	7/16" LOCK WASHER
3	400-06-312-0005	FENCE BODY ASSEMBLY, INCL:	47	901-01-060-0664	7/16-20 X 1" HEX HD SCREW
4	422-27-754-0009	LABEL	48	901-11-020-0821	1/4-20 X 3/4" CARRIAGE HD SCREW
5	422-27-752-0018	LABEL	49	422-27-089-0007	ANGLE BRACKET
6	422-27-754-0013	LABEL	50	901-25-043-1791	#8 X 3/4" HEX WASHER HD SCREW
7	422-39-112-0005	LEVELING SCREW	51	904-01-010-1614	FLAT WASHER
8	422-39-048-0001	ADJUSTMENT PLUG	52	902-01-120-1034	1/4-20 HEX NUT
9	902-01-010-1300	5/16-18 HEX NUT	53	422-27-089-0018	TABLE SUPPORT
10	422-27-048-0001	REAR SUPPORT FOOT	54	901-01-060-0612	1/4-20 X 5/8" HEX HD SCREW
11	422-27-068-0003	LOCKING LUG	55	904-01-010-1614	FLAT WASHER
12	905-01-010-2702	1/4" X 5/8" SPRING PIN	56	901-25-043-1791	#8 X 3/4" HEX WASHER HD SCREW
13	908-25-013-1808	O-RING	58	422-27-366-0005	LEG ASSY
14	904-01-010-1620	FLAT WASHER	59	422-27-112-0005	U-BOLT
15	424-12-060-0005	KNOB	60	902-01-120-1034	1/4-20 HEX NUT
16	901-02-443-1812	#8-32 X 1/2" PAN HD SCR	61	904-01-010-1614	FLAT WASHER
17	904-01-013-1738	3/16" FLAT WASHER	62	422-27-089-0017	SHELF SUPPORT
18	400-06-375-0002	CURSOR	64	1350481	LEG ADAPTER
19	921-01-110-0001	BALL	66	902-01-020-5433	3/8-16 JAM NUT
20	928-01-250-0001	SPRING	67	901-09-131-5295	LEVELING SCREW
21	901-04-150-9440	1/4-20 X 1/2" HEX SOC SET SCREW	**	422-27-628-0024	FLIP STOP HDWE PACK
22	422-27-104-0002	THRUST WASHER	81	n 901-01-060-0649	5/16-18 X 1.00 HEX HEAD SCREW
23	422-39-106-0002	SHAFT	82	n 422-27-084-0007	BRACKET
24	908-25-013-1756	O-RING	83	902-01-212-2409	LOCKNUT
25	905-01-103-1370	5/16" X 1 1/4" SPRING PIN	84	422-27-088-0002	FLIP STOP
26	901-05-163-1229	#10-16 X 1/2" PAN HD SCREW	85	904-07-010-5573	WASHER
27	422-39-019-0001	CAM HANDLE	86	424-12-060-0005	KNOB 2" 5/16-18
28	422-39-138-0002	HANDLE	87	n 901-01-060-0622	1/4-20 X 2" HEX HEAD SCREW
29	422-39-105-0001	GRIP	95	36-893	TABLE
30	422-19-089-0013	EXT WING SUPPORT	96	422-27-725-0016	HARDWARE PACK
31	901-01-060-0642	3/8-16 X 1" HEX HD SCREW			
33	904-01-010-1615	3/8" FLAT WASHER	*		NOT SHOWN ASSEMBLED
34	902-01-010-5900	3/8-16 JAM NUT			
37	902-01-010-5900	3/8-16 JAM NUT			
39	901-01-060-0648	3/8-16 X 1 1/4" SCREW			
41	422-27-055-0008	FRONT GUIDE RAIL, INCL:			
42	400-06-432-0001	SCALE KIT (SEE NOTE A)			
43	422-27-020-0003	END CAP-LH			
44	422-27-020-0004	END CAP-RH			

SERVICE NOTE:

A – Scale is provided oversize and must be cut to proper length.

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.