






REPLACEMENT PARTS

<u>REF NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
*	37-191	CUTTERHEAD ASSY, INCL:
1	1347041	BAR
2	37-658	KNIVES (SET OF 3)
3	1347042	KNIFE SCR
4	1347044	PULLEY
5	1347043	SUPPORT RH
6	1086894	BALL BEARING
7	1342579	KEY
8	1347040	(DIN 7991) M5 X 12MM FLAT HD SCR
9	901-04-150-0232	1/4-20 X 3/8" HEX SOC SET SCR
10	1347039	CUTTERHEAD
11	920-04-010-5355	BALL BEARING
12	1347045	SUPPORT LH
13	1347046	STUD
14	904-02-020-1704	3/8" LOCK WASHER
15	902-01-010-1207	3/8-24 HEX NUT
16	1347017	STOP SCR
17	901-03-010-0762	5/16-18 X 5/8" HEX SOC HD SCR
18	902-01-010-1300	5/16-18 HEX NUT
19	1347016	BLOCK
20	902-01-010-1300	5/16-18 HEX NUT
21	901-04-190-0287	5/16-18 X 1 1/4" HEX SOC SET SCR
22	1347037	LOCK
23	902-01-120-1034	1/4-20 HEX NUT
24	901-04-150-0296	1/4-20 X 1" HEX SOC SET SCR
25	1347015	GIB
26	37-108	JOINTER PUSH BLOCK
27	901-04-150-0208	1/4-20 X 1/4" HEX SOC SET SCR
28	1347020	M11.5 FLAT WASHER
29	901-03-040-8015	1/4-20 X 1/2" BUTTON HD SCR
30	904-01-010-1619	FLAT WASHER
31	1347022	KNOB
32	1347021	COLLAR
33	1313194	(DIN 137B) M8.4 WAVE WASHER
34	1347019	BLOCK
35	904-02-010-1703	5/16" LOCK WASHER
36	901-03-010-0779	5/16-18 X 1 1/2" HEX SOC HD SCR
37	1347018	SCR SHAFT
38	1347023	GUARD, INCL:
38A	1246008	(DIN 916) M5 X 12MM HEX SOC SET SCR
39	1347003	WARNING LABEL

<u>REF NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
41	1347011	INDEX PIN
42	1347012	SPRING
43	1347013	PLUNGER HOUSING
44	1347014	BALL KNOB
45	1347024	POINTER
46	1310159	(DIN 85) M4 X 6MM PAN HD SCR
47	1347025	PLATE
48	1347026	SPRING
49	1347027	CUP
50	1347028	RETAINER
51	1310161	(DIN 85) M4 X 18MM PAN HD SCR
52	1347008	BLOCK, INCL:
53	1310016	(DIN 1476) M2 X 5MM DRIVE SCR
54	1347009	SCALE
55	1347010	LOCK LEVER
56	901-03-010-0775	3/8-16 X 1" HEX SOC HD SCR
57	1347006	NAMEPLATE
58	1347029	PIN
59	1347030	BRACKET
60	901-03-010-3350	5/16-18 X 1/2" HEX SOC HD SCR
61	904-02-010-1703	5/16" LOCK WASHER
62	1330258	EXT RET RING
63	1347031	LINK
64	1347032	SPECIAL BOLT
65		BASE ASSY (SEE NOTE A)
66	1341113	.50-12 HEX NUT
67	1347035	LEVER ROD
68	1347036	KNOB
69	901-04-150-1185	1/4-20 X 5/16" HEX SOC SET SCR
70	1347034	BLOCK
71	1347033	SHAFT
71A	1246027	EXT RET RING
72	1347038	DUST CHUTE
72A	1330689	SEAL
73	1343918	KNIFE WRENCH
74	428-07-101-0002	6MM HEX WRENCH
75	432-07-101-0004	5MM HEX WRENCH
76	428-06-101-0002	3MM HEX WRENCH


* NOT SHOWN ASSEMBLED

NOTE A: BASE, FRONT AND REAR TABLES CANNOT BE SUPPLIED SEPARATELY, AS THE RE-ASSEMBLED MACHINE WOULD NOT BE ACCURATE. FOR TRUE ALIGNMENT, WE FINISH-GRIND OUR JOINTER TABLES AFTER ASSEMBLY ON THE BASE.



REPLACEMENT PARTS


<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
90	1347047	FENCE
91	1347049	KNOB
92	1347048	STUD
93	1347069	SPECIAL SCR
94	1347070	WASHER
95	904-01-010-1603	1/4" FLAT WASHER
96	1347068	LEAF GUARD
97	1347050	LOCK LEVER
98	1347051	BLOCK
99	1347052	BLOCK
100	902-01-120-1034	1/4-20 HEX NUT
101	901-04-150-0296	1/4-20 X 1" HEX SOC SET SCR
102	1347053	SUPPORT
103	901-04-150-0208	1/4-20 X 1/4" HEX SOC SET SCR
104	901-03-010-0779	5/16-18 X 1 1/2" HEX SOC HD SCR
105	1347054	COLLAR
106	1347055	SHAFT
107	1347056	INDEX COLLAR
108	1347005	CAUTION LABEL
109	1347057	SHAFT
110	901-03-010-0779	5/16-18 X 1 1/2" HEX SOC HD SCR
111	1246184	(DIN 1481) M3 X 20MM SPRING PIN
112	1347060	BALL KNOB
113	1347059	SPRING
114	1347058	INDEX PIN
115	901-03-010-0779	5/16-18 X 1 1/2" HEX SOC HD SCR
116	902-01-020-5435	5/16-18 JAM NUT
117	1347056	INDEX COLLAR
118	1347066	LOCK LEVER
119	904-01-031-2937	FLAT WASHER
120	1347063	COVER
121	901-03-010-0779	5/16-18 X 1 1/2" HEX SOC HD SCR
122	1347061	CAP
123	901-02-010-0514	1/4-20 X 3/8" ROUND HD SCR
124	901-03-010-3350	5/16-18 X 1/2" HEX SOC HD SCR
125	1347067	GUARD
126	1347062	BAR
127	901-03-010-8024	5/16-18 X 2 1/4" HEX SOC HD SCR
128	1347064	SUPPORT
129	1347065	(DIN 1481) M4 X 16MM SPRING PIN



REPLACEMENT PARTS

<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
140	1347090	DUST OUTLET	162	1347081	BRACE
141	1347071	COVER, INCL:	163	1347080	BRACE
141A	1347004	WARNING LABEL	164	904-02-020-1704	3/8" LOCK WASHER
142	1347072	WING SCR	165	1347085	SPECIAL STUD
143	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR	166	1347086	BRACE
144	1347073	DUST CHUTE	167	1347082	BRACE
145	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR	168	1342381	PLASTIC FOOT
146	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR	169	1347076	MOTOR CORD
147	904-01-031-6202	FLAT WASHER	170	1347075	POWER CORD
148	902-01-010-1300	5/16-18 HEX NUT	171	1320131	CLAMP
149	1347077	MOTOR PULLEY	172	1347089	BOX
150	1342579	KEY	173	902-01-120-1204	#08-32 HEX NUT
151	904-02-020-1702	1/4" LOCK WASHER	174	904-03-030-1795	3/16" EXT TOOTH WASHER
152	901-02-010-0514	1/4-20 X 3/8" ROUND HD SCR	175	901-02-010-0555	#08-32 X 3/8" ROUND HD SCR
153	1347078	BELT COVER	176	901-05-743-1218	#08-32 X 1/2" FLAT HD SCR
154	901-04-150-0208	1/4-20 X 1/4" HEX SOC SET SCR	177	902-01-120-1204	#08-32 HEX NUT
155	1347074	MOTOR	178	904-01-010-1602	3/16" FLAT WASHER
156	1347088	V-BELT	179	1347087	COVER
157	1347083	BRACE	180	901-02-010-0555	#08-32 X 3/8" ROUND HD SCR
158	902-01-010-1300	5/16-18 HEX NUT	181	1343759	SWITCH, INCL:
159	904-01-031-6202	FLAT WASHER	182	1343758	KEY (SEE NOTE B)
160	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR			
161	1347079	LEG			

NOTE B: DELTA HAS USED A NUMBER OF DIFFERENT TYPES OF SWITCHES FOR PRODUCTION. ALL SWITCHES ARE INTERCHANGEABLE BUT THE KEYS ARE DIFFERENT. REPLACEMENT SWITCHES COME COMPLETE WITH KEY. IF A REPLACEMENT KEY IS NEEDED, REFER TO DRAWING BELOW TO SELECT THE PROPER ONE.



STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.