






REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION
*	37-191	CUTTERHEAD ASSY, INCL:
1	1340195	BAR
2	37-658	KNIVES (SET OF 3)
3	1340196	KNIFE SCR
4	1340112	PULLEY
5	1340113	SUPPORT RH
6	1086894	BALL BEARING
7	1340114	KEY
8	1246158	(DIN 916) M5 X 16MM HEX SOC SET SCR
8A	1330112	NUT
9	1243321	(DIN 916) M6 X 10MM HEX SOC SET SCR
10	1340115	CUTTERHEAD
11	920-04-010-5355	BALL BEARING
12	1340116	SUPPORT LH
13	1340117	STUD
14	1243360	(DIN 7980) M10.2 LOCK WASHER
15	1243496	(DIN 934) M10 HEX NUT
16	1340118	STOP SCR
17	1246122	(DIN 912) M8 X 16MM HEX SOC HD SCR
18	1243398	(DIN 934) M8 HEX NUT
19	1340119	BLOCK
20	1243398	(DIN 934) M8 HEX NUT
21	1246150	(DIN 913) M8 X 25MM HEX SOC SET SCR
22	1340120	LOCKSCR
23	1243456	(DIN 934) M6 HEX NUT
24	1246187	(DIN 914) M6 X 25MM HEX SOC SET SCR
25	1340121	GIB
26	37-108	JOINTER PUSH BLOCK
27	1310055	(DIN 913) M6 X 6MM HEX SOC SET SCR
28	1347020	M11.5 FLAT WASHER
29	1345859	(DIN 7380) M6 X 12MM BUTTON HD SCR
30	1340622	M6.4 FLAT WASHER
31	1340122	KNOB
32	1340123	COLLAR
33	1313194	(DIN 137B) M8.4 WAVE WASHER
34	1340124	BLOCK
35	1246157	(DIN 7980) M8.1 LOCK WASHER
36	1246006	(DIN 912) M8 X 50MM HEX SOC HD SCR
37	1340125	SCR SHAFT
38	1340126	GUARD, INCL:
38A	1246008	(DIN 916) M5 X 12MM HEX SOC SET SCR
39	1349888	WARNING LABEL

REF. NO.	PART NUMBER	DESCRIPTION
41	1340127	INDEX PIN
42	1340128	SPRING
43	1340129	PLUNGER HOUSING
44	1340130	BALL KNOB
45	1340131	POINTER
46	1310159	(DIN 85) M4 X 6MM PAN HD SCR
47	1340132	PLATE
48	1340133	SPRING
49	1340134	CUP
50	1340135	RETAINER
51	1310161	(DIN 85) M4 X 18MM PAN HD SCR
52	1340136	BLOCK, INCL:
53	1310016	5MM DRIVE SCR
54	1340137	SCALE
55	1340138	LOCK LEVER
56	1246122	(DIN 912) M8 X 16MM HEX SOC HD SCR
57	1349891	NAMEPLATE
58	1340139	PIN
59	1340140	BRACKET
60	1342125	(DIN 912) M8 X 12MM HEX SOC HD SCR
61	1246157	(DIN 7980) M8.1 LOCK WASHER
62	1330258	EXT RET RING
63	1340141	LINK
64	1340142	SPECIAL BOLT
65		BASE ASSY (SEE NOTE A)
66	1243476	(DIN 934) M12 HEX NUT
67	1340143	LEVER ROD
68	1340144	KNOB
69	1243339	(DIN 916) M6 X 8MM HEX SOC SET SCR
70	1340145	BLOCK
71	1340146	SHAFT
71A	1246027	EXT RET RING
72	1340147	DUST CHUTE
72A	1330689	SEAL
74	428-06-101-0003	2.5MM HEX WRENCH
75	428-06-101-0002	3MM HEX WRENCH
76	422-29-101-0002	4MM HEX WRENCH
77	428-07-101-0002	6MM HEX WRENCH
78	1343918	8 X 10MM OPEN END WRENCH
79	1347832	12 X 14MM OPEN END WRENCH

* NOT SHOWN ASSEMBLED


NOTE A: BASE, FRONT AND REAR TABLES CANNOT BE SUPPLIED SEPARATELY, AS THE RE-ASSEMBLED MACHINE WOULD NOT BE ACCURATE. FOR TRUE ALIGNMENT, WE FINISH-GROUND OUR JOINTER TABLES AFTER ASSEMBLY ON THE BASE.



REPLACEMENT PARTS

<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
*	1340197	FENCE ASSY, CONST OF:
90	1340148	FENCE
91	1340149	KNOB
92	1340150	STUD
93	1340151	SPECIAL SCR
94	1340622	M6.4 FLAT WASHER
95	1313194	(DIN 137B) M8.4 WAVE WASHER
96	1340152	LEAF GUARD
97	1340153	LOCK LEVER
98	1340154	BLOCK
99	1340155	BLOCK
100	1246175	(DIN 931) M6 X 30MM HEX HD SCR
101	1243456	(DIN 934) M6 HEX NUT
102	1340156	SUPPORT
103	1330200	(DIN 916) M8 X 12MM HEX SOC SET SCR
104	1243530	(DIN 912) M8 X 30MM HEX SOC HD SCR
105	1340157	COLLAR
106	1340158	SHAFT
107	1340159	INDEX COLLAR
108	1347005	CAUTION LABEL
109	1340161	SHAFT
111	1246184	(DIN 1481) M3 X 20MM SPRING PIN
112	1340162	BALL KNOB
113	1340163	SPRING
114	1340164	INDEX PIN
115	1246055	(DIN 912) M6 X 50MM HEX SOC HD SCR
116	1345980	(DIN 936) M6 HEX LOW NUT
117	1340165	INDEX COLLAR
118	1340166	LOCK LEVER
119	1340637	(DIN 9021) M8.4 FLAT WASHER
120	1340167	COVER
121	1243554	(DIN 912) M8 X 35MM HEX SOC HD SCR
122	1340168	CAP
123	1246045	(DIN 84) M6 X 10MM CHEESE HD SCR
124	1342125	(DIN 912) M8 X 12MM HEX SOC HD SCR
125	1340169	GUARD, INCL:
125A	1348226	WARNING LABEL
126	1340170	BAR
127	1340194	(DIN 912) M8 X 55MM HEX SOC HD SCR
128	1340171	SUPPORT
129	1347065	(DIN 1481) M4 X 16MM SPRING PIN
130	1243530	(DIN 912) M8 X 30MM HEX SOC HD SCR

* NOT SHOWN ASSEMBLED



REPLACEMENT PARTS

<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
140	1340172	DUST OUTLET
141	1340173	COVER, <i>INCL.</i>
141A	1349890	WARNING LABEL
142	1347072	WING SCR
143	901-11-020-0830	5/16-18 X 1-1/4" CARRIAGE HD SCR
144	1348665	DUST CHUTE
145	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR
146	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR
147	904-01-031-6202	FLAT WASHER
148	902-01-010-1300	5/16-18 HEX NUT
149	1340176	MOTOR PULLEY
150	1342579	KEY
151	1243520	(DIN 7980) M6.1 LOCK WASHER
152	1246045	(DIN 84) M6 X 10MM CHEESE HD SCR
153	1340177	BELT COVER
154	1310055	(DIN 913) M6 X 6MM HEX SOC SET SCR
155	1348664	MOTOR
156	1340179	V-BELT
157	1344111	BRACE (<i>GRAY, CMO</i>)
157A	1340180	BRACE (<i>BLACK, EMO</i>)
158	902-01-010-1300	5/16-18 HEX NUT
159	904-01-031-6202	FLAT WASHER
160	901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCR
161	1344112	LEG (<i>GRAY, CMO</i>)
161A	1340181	LEG (<i>BLACK, EMO</i>)
162	1344113	BRACE (<i>GRAY, CMO</i>)
162A	1340182	BRACE (<i>BLACK, EMO</i>)
163	1344114	BRACE (<i>GRAY, CMO</i>)
163A	1340183	BRACE (<i>BLACK, EMO</i>)
164	1243360	(DIN 7980) M10.2 LOCK WASHER
165	1340184	SPECIAL STUD
166	1344115	BRACE (<i>GRAY, CMO</i>)
166A	1340185	BRACE (<i>BLACK, EMO</i>)
167	1344116	BRACE (<i>GRAY, CMO</i>)
167A	1340186	BRACE (<i>BLACK, EMO</i>)
168	1340187	PLASTIC FOOT
169	1340188	MOTOR CORD
170	1340189	POWER CORD
171	1340190	CLAMP
172	1340191	BOX
173	1243569	(DIN 934) M4 HEX NUT
174	1320101	(DIN 6797A) M5.3 EXT TOOTH WASHER
175	1347527	(DIN 7985) M4 X 10MM PAN HD SCR
176	1349832	(DIN 7380) M4 X 12MM BUTTON HD SCR
177	1243569	(DIN 934) M4 HEX NUT
178	1246102	(DIN 125) M5.3 FLAT WASHER
179	1340192	COVER
180	1347527	(DIN 7985) M4 X 10MM PAN HD SCR
181	1343759	SWITCH, <i>INCL.</i>
182	1343758	KEY

EMO = EARLY MODELS ONLY
CMO = CURRENT MODELS ONLY

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.