




REPLACEMENT PARTS

REF. NO.	PART NO.	DESCRIPTION
1	413-93-043-0002	Fence
2	901-11-010-2353	1/4-20 x 3/4" Sq Hd Bolt
3	904-01-010-1614	1/4" Flat Washer
4	902-01-120-1034	1/4-20" Hex Nut
5	901-04-121-3615	#8-32 x 1/2" Nylok Headless Set Screw
6	413-93-014-0010	Swivel Bracket
7	1231559	5/16 x 1 3/4" Modify Carr Bolt
8	413-93-629-0003	Swivel Slide, Incl:
9	905-01-010-2729	3/16 x 1/2" Roll Pin
10	422-01-088-0002	Stop Link
11	1231637	5/16" Push Nut
12	413-93-014-0008	Slide Bracket
13	904-01-010-1620	5/16" Flat Washer
14	413-93-327-0001	Clamp Assy
15	413-93-089-0004	Fence Support
16	1231567	Knob
17	901-11-020-0830	5/16-18 x 1 1/4" Carr Bolt
18	904-01-010-1620	5/16" Flat Washer
19	418-06-004-0001	Lock Bar
20	37-659	Set of Three (3) Knives
21	901-09-070-6120	Special Screw
*	37-258	Cutterhead Assy, Const of:
22	413-94-357-0002	Cutterhead, Incl:
23	920-04-010-5355	Bearing
24	418-03-060-0003	Holder
25	1231622	2" OD, 9/16" Bore, Cutterhead Pulley, Incl:
26	901-04-150-0206	5/16-18 x 5/16" Hex Soc Set Screw
27	927-03-010-2666	Key
28	413-93-629-0005	Swing Guard Assy, Incl:
29	418-06-754-0001	Warning Decal
30	413-93-091-0001	Front Table
31	901-06-450-2254	#8 x 3/8" Rd Hd Drive Screw
32	928-02-161-3399	Spring
33	413-93-108-0003	Motor Plate Rod
34	901-03-010-0758	5/16-18 x 2" Soc Hd Cap Screw
35	901-01-060-0648	3/8-16 x 1 1/4" Hex Hd Cap Screw
36	904-02-020-1704	3/8" Lockwasher
37	1231635	Spring
38	413-93-108-0002	Rod
39	413-93-067-0002	Lever
40	1231566	Elevation Screw
41	1231609	Lock Knob
42	1231624	Elevation Knob
43	901-04-150-1112	3/8-16 x 1/2" Soc Set Screw
44	1231612	Depth Scale
45	901-06-121-7383	#10-24 x 3/8" Rd Hd S/T Screw
46	413-93-005-0001	Base
47	1231575	5/16-18 x 1" Long Lok Hex Hd Cap Screw
48	904-01-010-1620	5/16" Flat Washer
49	1231661	Shim Washer
50	413-93-054-0002	Belt Guard
51	413-93-091-0002	Rear Table
52	901-02-120-7528	1/4-20 x 1/2" Truss Hd Mach Screw
53	41-023	2 1/2" OD, 5/8" Bore Pulley, Incl:
54	901-04-150-0206	5/16-18 x 5/16" Hex Soc Set Screw
55	927-03-010-2666	Key
56	1231516	Rubber Washer
57	438-02-314-0982	Rotor/Stator Assy
58	413-93-372-0001	Motor Plate, Incl:
59	413-93-016-0001	Bumper
60	1231279	1/4-20 x 3/4" Hex Hd Screw w/Lockwasher
61	902-02-010-1315	1/4-20 Sq Nut
62	901-06-121-7383	#10-24 x 3/8" Rd Hd S/T Screw
63	904-03-030-1795	#10 Lockwasher
64	1087714	Ground Wire Assy
65	429-01-302-0153	Power Cord Assy
66	429-01-004-0109	Bushing
67	904-07-010-5571	Fiber Washer
68	1231642	Cable Clip
69	438-01-017-0194	Switch Circuit Breaker
70	438-01-015-0032	Start Relay
71	1231545	Jumper Wire
72	429-01-004-0108	Capacitor Clamp
73	1225324	Capacitor
74	429-01-007-0105	Wire Joint
75	49-271	25 1/8" OC V-Belt
*	37-259	Stand Assy, Const of:
76	901-01-060-0602	5/16-18 x 1 1/4" Hex Hd Cap Screw
77	904-01-010-1605	5/16" Flat Washer
78	427-99-066-0035	Leg
79	427-99-014-0041	Bracket 1 x 2 5/8 x 24 3/4"
80	427-99-048-0001	Foot
81	427-99-014-0042	Bracket 1 x 2 5/8 x 29 3/4"
82	427-99-014-0020	Bracket 1 x 2 5/8 x 14 3/4"
83	427-99-014-0032	Bracket 1 x 2 5/8 x 9 3/4"
84	427-99-014-0044	Bracket 1 x 2 5/8 x 24 3/4" w/Cut Out
85	901-11-020-0834	5/16-18 x 3/4" Carr Bolt
86	904-01-010-1620	5/16" Flat Washer
87	902-01-010-1300	5/16-18" Hex Nut
88	413-93-054-0005	Pulley Guard
89	901-06-121-7383	#10-24 x 3/8" Rd Hd S/T Screw
90	37-108	Push Block Set of Two (2)
91	955-03-010-0003	3/16" Allen Wrench
92	955-03-010-0010	1/4" Allen Wrench
93	37-522	Wrench

* Not Shown Assembled