





BASE ASSEMBLY



FENCE ASSEMBLY

REPLACEMENT PARTS

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	904-01-031-2903	Special Washer	45	418-04-105-5001	Nut
2	904-10-101-3151	Eccentric Shaft Bushing	46	418-04-010-5001	Block
3	928-01-020-7393	Coil Spring	47	418-04-412-5005	Adj. Scr.
4	901-11-320-0091	Clamp Eye Bolt	48	926-01-991-2294	Cutterhead Pulley, Incl:
5	37-810	Cutter Head, Incl:	49	901-04-150-0206	5/16-18 X 5/16" Set Scr., Cup
6	37-308	Set of 3 Knives	50	Nameplate	By Request Only
7	901-09-070-6120	1/4"-28 Hex Hd. Machine Scr.	51	418-04-088-5004	Knife Stop
8	418-04-079-5001	Front Bearing Housing	52	951-02-011-3982	Scale
9	418-04-079-5002	Rear Bearing Housing	53	931-01-011-4091	Handle Ball
10	418-04-020-5001	Front Bearing Cap	54	902-01-200-9764	Spec. Nut
11	904-01-071-2915	Clamping Collar	55	902-04-020-1418	Spec. Nut
12	418-04-079-5003	Clamping Nut	56	951-01-010-7802	Pointer
13	418-04-004-5001	Throat Block	57	928-01-021-3352	Spring
14	928-01-021-3357	Spring	58	901-04-150-0202	1/4-20 X 1/2" Soc. Hd. Scr.
15	901-03-010-0224	10-32 X 1/2" Cap Scr.	59	901-04-150-0205	5/16-18 X 1/4" Soc. Hd. Scr.
16	902-01-020-1226	5/8"-18 Hex Jam Nut	60	901-04-150-0206	5/16-18 X 5/16" Set Scr.
17	920-04-020-5348	Bearing #99504XIC	61	901-04-020-0306	1/4-20 X 3/4" Set Scr.
18	418-04-106-5003	Fence Pivot Shaft	62	901-02-010-0561	10-32 X 5/8" Rd. Hd. Scr.
19	418-04-055-5001	Key	63	901-01-060-0608	5/16-18 X 7/8" Cap Scr.
20	418-04-042-5001	Clamping Shaft	64	901-01-060-0617	3/8-16 X 1-1/2" Cap Scr.
21	418-04-354-5002	Guard, Incl:	65	901-02-050-0742	10-32 X 3/8" Fil. Hd. Scr.
22	928-02-151-4137	Spring	66	901-03-010-0750	5/16-18 X 1" Cap Scr.
23	905-05-040-2107	Cotter Pin	67	902-01-120-1034	1/4"-20 Hex Nut
24	905-05-040-2110	Cotter Pin	68	902-01-020-1228	5/16"-24 Hex Jam Nut
25	418-04-014-5001	Rabbeting Ledge	69	904-01-010-1609	Washer
26	418-04-068-5001	Fence Lock Collar	70	904-02-010-1703	Lockwasher
27	418-04-411-5001	Clamp Stud	71	904-02-020-1704	Lockwasher
28	418-04-098-5001	Lower Wedge	72	901-06-450-2250	4 X 3/16" Drive Scr.
29	418-04-098-5002	Upper Wedge	73	927-03-010-2662	Key
30	951-02-011-3979	Fence Scale	74	905-01-010-2703	1/8 X 1/2" Roll Pin
31	418-04-005-5001	Fence Base	75	905-01-010-2715	3/16 X 1-1/8" Roll Pin
32	418-04-043-5001	Fence	76	901-04-090-4554	5/16-24 X 1" Set Scr.
33	418-04-090-5001	Rocker Arm	77	905-01-010-6706	1/16 X 3/8" Roll Pin
34	418-04-412-5003	Lock Knob	78	901-02-120-7528	1/4-20 X 1/2" Mach. Scr.
35	418-04-089-5001	Fence Support	79	931-04-010-3635	Handle
36	418-04-027-5002	Clamping Bushing	80	904-01-031-2945	5/16 X 5/8 X 1/16" Washer
37	418-04-088-5001	Indexing Collar	81	422-04-111-5001	Stud
38	418-04-106-5003	Upper Pivot Shaft	82	48-245	Wrench
39	418-04-027-5003	Clamp Washer	82	Cannot Furnish	Wrench
40	418-04-071-5003	Indexing Pin	83	37-522	Wrench
41	930-01-991-6368	Handwheel, Incl:	84	49-135	V-Belt
42	901-04-150-0217	5/16-18 X 1/2" Hex Set Scr.	85	41-114	Motor Pulley, Incl:
43	418-04-052-5001	Gib	86	901-04-190-0201	5/16-18 X 5/16" Set Scr.
44	904-10-021-2077	Collar			