




Replacement Parts

Ref. No.	Part No.	Description	Ref. No.	Part No.	Description
1	430-02-406-0001	Lower Plunger, Incl:	*	430-01-314-0001	Guide Ass'y., Const. Of:
2	430-02-074-0001	Cork Plug	50	430-01-014-0002	Upper Saw Guide Brkt.
3	422-02-046-0001	Filter	51	430-01-110-0001	Saw Guide Post
*	402-01-020-0001	Oil Hole Cover	52	430-01-055-0002	Saw Blade Guide
*	430-02-325-0004	Chuck, Const. Of:	53	904-01-031-2924	Steel Washer
5	430-02-012-0005	Lower Chuck Body	54	430-02-027-0005	Hold Down Spring
6	430-02-027-0002	Lower Chuck Clamp	55	430-02-054-0006	Blade Guard
7	430-02-064-0002	Groove Jaw	56	901-04-080-0102	1/4-20 X 3/8" Hdls. Set Scr.
8	430-02-064-0003	Plain Jaw	57	901-01-060-0611	1/4-20 X 1/2" Cap Scr.
9	905-01-010-2716	Clamp Pin	58	901-02-180-2316	Screw
10	901-04-260-1543	#10-32 x 5/8" Thumb Screw	59	904-01-010-1603	Washer
11	901-02-551-2857	Fil. Hd. Cap Scr.	60	901-04-260-1542	#10-32 X 1/2" Thumb Scr.
12	430-01-391-0001	Table	61	430-01-061-0001	Air Nozzle
13	426-02-063-0001	Table Insert	*	430-01-325-0002	Upper Plunger Ass'y., Incl:
14	905-01-010-6711	1/8 X 3/8" Roll Pin	62	901-02-551-2857	Fil. Hd. Cap Screw
15	1088260	Nameplate	63	928-01-101-3385	Coil Spring
17	951-02-010-7831	Tilt Scale	64	904-07-101-2947	Sq. Hole Fiber Washer
18	426-02-095-0001	Trunnion	65	430-01-020-0005	Safety Cap
19	904-02-020-1702	1/4" Lockwasher	66	904-08-021-3886	Rubber Washer
20	901-02-010-0514	1/4-20 X 3/8" Mach. Scr.	67	430-01-012-0001	Upper Plunger Housing
21	430-01-027-0001	Trunnion Clamp	68	1086316	Upper Chuck Body
22	901-07-290-4155	7/16-14 X 3-1/8" Stud	69	1086318	Jaw with Pin
23	430-01-314-0002	Trunnion Bracket	70	1086317	Plain Jaw
24	904-03-050-1752	5/16" Lockwasher	71	430-01-378-0001	Plunger
25	901-02-050-0711	5/16-18 X 1-1/4" Mach. Scr.	72	430-01-349-0002	Frame, Incl:
26	951-01-011-3953	Pointer	73	426-03-074-0001	Expansion Plug
27	901-02-010-0569	#8-32 X 3/16" Mach. Scr.	74	920-75-011-2795	Bushing
28	928-01-021-4125	Coil Spring	75	920-75-011-3913	Bushing
29	1087528	Handknob	76	960-02-010-1879	Plate
30	430-01-320-0001	Housing, Incl:	77	901-06-450-2250	#4 X 3/16" Drive Screw
31	920-75-101-3912	Bronze Bushing	78	901-04-291-4003	Thumb Screw
32	430-01-406-0001	Driver Shaft	79	901-04-080-0106	5/16-18 X 1/2" Set Screw
33	422-01-404-0002	Set Collar, Incl:	80	194	Hex Wrench
34	901-04-150-0205	5/16-18 X 1/4" Set Screw	81	40-526	Wrench
35	904-01-091-2939	Steel Washer	82	49-105	V-Belt
36	430-01-355-0001	Crosshead, Incl.:	83	41-043	Motor Pulley, Incl:
37	901-04-160-9414	Screw	84	901-04-150-0206	5/16-18 x 5/16" Hex Soc. Set Scr.
38	430-01-071-0003	Crosshead Pin	85	1088264	Nameplate
39	901-04-190-0276	1/4-28 X 1/8" Set Scr.			
40	430-01-354-0001	Pulley Guard	*	NOT SHOWN	
41	901-02-010-0593	#10-20 X 3/8" Mach. Scr.			
42	5400-B	Pulley, Incl:			
43	901-04-150-0206	5/16-18 X 5/16" Set Scr.			
44	901-02-010-0509	1/4-20 X 1/2" Mach. Scr.			
45	904-07-010-5573	Fiber Washer			
46	430-01-116-0001	Gasket			
47	430-01-331-0003	Crankcase Cover			
48	904-07-020-5556	Washer			
49	901-09-110-6123	Oil Filler Plug			