






REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION
1	1341442	Upper Arm Guard (Current Models Only)	45	1341423	Retaining Plate
1	1341428	Upper Arm Guard (Early Models Only)	46	904-02-010-1726	5/32" Lockwasher
2	1341434	Nameplate	47	1341441	(Din 912) M4 x 12mm Soc Hd Screw
3	1341435	Warning Label	48	1341406	Rubber Bumper
4	904-01-010-1603	1/4" Flat Washer	49	1341405	Main Frame
5	904-02-010-2051	1/4" Lockwasher	50	904-02-010-2051	1/4" Lockwasher
6	1246002	(Din 84) M6 x 12mm Cheese Hd Screw	51	1246153	(Din 933) M6 x 25mm Hex Hd Screw
7	1341408	Hex Hd Bolt	52	1243395	(Din 934) M5 Hex Nut
8	1341420	Upper Rocker Arm w/Bushing	53	904-02-020-1725	3/16" Lockwasher
9	1341425	Blade Tension Rod and Handle	54	1246005	(Din 912) M6 x 45mm Soc Hd Screw
10	1341436	Bushing	55	904-02-010-2051	1/4" Lockwasher
11	1341441	(Din 912) M4 x 12mm Soc Hd Screw	56	1341411	Table
12	904-02-010-1726	5/32" Lockwasher	57	1246144	(Din 914) M6 x 12mm Hex Soc Set Screw
13	1341423	Retaining Plate	58	1341412	1/4" Flat Washer
14	1341426	Block	59	1341413	Spring
15	1341422	Knob w/Screw	60	1246055	(Din 912) M6 x 50mm Soc Hd Screw
16	904-01-010-1603	1/4" Flat Washer	61	1341414	Rear Table Mount
17	1341413	Spring	62	1243456	(Din 934) M6 Hex Nut
18	1341421	Blade Holder Clamp	63	1341438	(Din 1378) 6.4mm Wave Washer
19	1341431	Plate	64	1341412	1/4" Flat Washer
20	904-02-010-1726	5/32" Lockwasher	65	1341409	Table Angle Scale
21	1341440	(Din 912) M4 x 20mm Soc Hd Screw	66	1330399	(Din 963) M5 x 14mm Flat Hd Screw
22	40-155	Blade Holder, Incl:	67	1341433	Table Lock Handle and Screw
23	904-02-010-1726	5/32" Lockwasher	68	1341412	1/4" Flat Washer
24	1341441	(Din 912) M4 x 12mm Soc Hd Screw	69	1243456	(Din 934) M6 Hex Nut
25		Vise-Hold Type Blade	70	1246045	(Din 84) M6 x 10mm Cheese Hd Screw
26		Pin Type Blade	71	1341415	Pointer
27	1341427	Spring Hold Down	72	1341410	Table Bracket
28	1341418	Retaining Clip	73	1246002	(Din 84) M6 x 12mm Cheese Hd Screw
29	1341419	Bushing	74	904-02-010-2051	1/4" Lockwasher
30	904-02-010-1726	5/32" Lockwasher	75	1341432	Side Guard
31	1341441	(Din 912) M4 x 12mm Soc Hd Screw	76	1341400	Base
32	1341407	Lower Rocker Arm w/Bushing	77	904-02-020-2086	5/16" Lockwasher
34	1246050	(Din 912) M5 x 25mm Soc Hd Screw	78	1246053	(Din 912) M8 x 25mm Soc Hd Screw
35	1341416	Connecting Link	79	904-02-010-2051	1/4" Lockwasher
36	1341439	Bearing	80	1246153	(Din 933) M6 x 25mm Hex Hd Screw
37	1341417	Bushing	81	1341404	Bushing
38	904-02-020-1725	3/16" Lockwasher	82	1246133	(Din 913) M8 x 8mm Hex Soc Set Screw
39	1243395	(Din 934) M5 Hex Nut	83	1341403	Drive Eccentric
40	1246098	(Din 912) M5 x 16mm Soc Hd Screw	84	1341437	Cord
41	904-02-020-1725	3/16" Lockwasher	85	438-01-017-0140	Switch, Incl:
42	1341429	Spring	86	400-06-068-0002	Key
43	1341408	Hex Hd Bolt	87	1341401	Motor
44	1341424	Block	88	428-06-101-0002	3mm Hex Wrench



DUST BLOWER SYSTEM (CURRENT MODELS ONLY)

REPLACEMENT PARTS

FOR USE ON UNITS WITH DUST BLOWER SYSTEMS (CURRENT MODELS ONLY)

REF. NO.	PART NUMBER	DESCRIPTION
125	1341444	Pump Housing Assembly
126	1342446	(Din 7513B) M4 x 8mm Self Tapping Screw
127	1341443	Pump Lock Plate
128	1341445	Tubing
129	1342446	(Din 7513B) M4 x 8mm Self Tapping Screw
130	904-01-010-1602	3/16" Flat Washer
131	1341446	Clamp
132	1341447	Brass Pipe

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.