




REPLACEMENT PARTS


REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
1	430-02-112-0004	BOLT	*	430-02-325-0004	LOWER CHUCK ASSY, CONST OF:
2	904-03-020-1751	5/8" INT TOOTH WASHER	66	430-02-064-0002	V-JAW
3	430-02-089-0002	OVERARM	67	901-04-260-1543	#10-32 X 5/8" THUMB SCREW
4	905-04-071-4460	1/4" X 3/4" DOWEL PIN	68	905-01-010-2716	1/8" X 9/16" SPRING PIN
5	430-02-061-0007	TUBE	69	430-02-027-0002	CLAMP
*	430-02-325-0007	UPPER PLUNGER ASSY, CONST OF:	70	430-02-012-0005	CHUCK BODY
6	430-01-020-0005	CAP	71	901-02-551-2857	#06-40 X .20 SCREW
7	904-08-021-3886	7/16" RUBBER WASHER	72	430-02-361-0006	LOWER PLUNGER ASSY, INCL:
8	430-02-628-0006	PLUNGER TUBE KIT, INCL:	73	430-02-074-0001	PLUG
9	430-02-104-0003	FIBER WASHER	*	430-02-412-0001	BEARING RETAINER ASSY, CONST OF:
9A	904-01-010-1614	FLAT WASHER	76	430-02-112-0001	BEARING RETAINER SCREW
10	928-01-101-4107	COIL SPRING	77	904-08-031-3885	5/8" WASHER
11	430-02-317-0001	BEARING W/COLLAR <i>(Early Models Only)</i>	78	904-15-210-7438	CLIP
11A	430-02-317-0002	BEARING W/COLLAR <i>(Current Models Only)</i>	79	430-02-079-0001	RETAINER
12	430-02-325-0007	CASING <i>(Early Models Only)</i>	80	430-02-017-0002	UPPER BEARING
12A	430-02-031-0005	CASING <i>(Current Models Only)</i>	81	901-03-010-8082	1/4-28 X 1" HEX SOC HD SCREW
13	904-08-101-4523	WASHER	82	904-01-021-3590	FLAT WASHER
14	430-02-020-0007	WASHER	83	901-04-190-0286	#8-32 X 1/4" HEX SOC SET SCREW
15	1086316	CHUCK	84	904-01-010-1610	FLAT WASHER
16	901-02-551-2857	#06-40 X .20 SCREW	85	951-01-010-7802	POINTER
17	1086317	FIXED JAW	86	901-02-010-0551	#10-32 X 1/4" ROUND HD SCREW
18	901-04-260-1543	#10-32 X 5/8" THUMB SCREW	87	901-07-261-3239	TRUNNION CLAMP STUD
19	1086318	JAW ASSY	88	430-02-014-0003	SWIVEL BRACKET
*	430-02-314-0006	PLUNGER HOUSING, CONST OF:	89	904-01-010-1614	FLAT WASHER
21	901-04-260-1520	5/16-18 X 1/2" THUMB SCREW	90	928-01-021-4125	SPRING
22	430-02-411-0001	KNOB ASSY	91	406-03-100-0002	STAR WHEEL
23	904-07-010-5555	1/4" FIBER WASHER	92	430-02-020-0010	BREATHER
24	430-02-105-0001	LOCK SLEEVE - RH	93	430-02-079-0002	COLLAR
26	430-02-014-0009	UPPER HEAD BRACKET	94	920-75-011-2795	LOWER PLUNGER BUSHING
27	902-01-120-1209	1/4-28 HEX NUT	95	430-02-079-0003	RING
28	430-02-105-0002	LOCK SLEEVE -LH	96	901-02-010-0503	1/4-20 X 5/8" ROUND HD SCREW
29	430-02-110-0003	GUIDE POST	97	904-07-010-5573	1/4" FIBER WASHER
30	901-01-060-0626	1/4-20 X 3/4" HEX HD SCREW	98	430-02-116-0002	GASKET <i>(Early Models Only, See Service Note A)</i>
31	904-01-010-1603	1/4" FLAT WASHER	99	430-02-014-0013	COVER/BRACKET
*	430-02-355-0003	GUIDE ASSY, CONST OF:	100	430-02-754-0001	WARNING LABEL
32	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW	102	430-02-074-0003	OIL PLUG
33	904-01-010-1614	FLAT WASHER	103	904-01-031-7720	FLAT WASHER
34	430-02-027-0005	HOLD DOWN SPRING	104	430-02-308-0001	CONNECTING ROD W/BEARINGS
35	430-02-380-0001	BLADE SUPPORT ASSY, INCL:	*	430-02-312-0008	DRIVE SHAFT HOUSING, CONST OF:
36	430-02-080-0001	ROLLER	107	901-09-120-6143	SCREW
37	905-04-071-3122	1/16" X .563 DOWEL PIN	108	901-09-080-6148	5/8-32 X .64 SCREW
38	901-04-260-1520	5/16-18 X 1/2" THUMB SCREW	109	928-01-021-4128	COIL SPRING
39	430-02-112-0002	SET SCREW	110	952-03-021-4801	VALVE DISK
40	430-02-055-0011	BLADE GUIDE	111	430-02-020-0005	PUMP HEAD
41	430-02-061-0002	AIR NOZZLE	112	901-02-010-0564	#06-32 X 3/8" ROUND HD SCREW
42	901-01-060-0626	1/4-20 X 3/4" HEX HD SCREW	113	430-02-116-0001	GASKET
43	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW	114	928-01-041-3376	COIL SPRING
44	904-01-031-2934	1/4" FLAT WASHER	115	430-02-338-0001	PISTON
45	430-02-014-0005	GUIDE BRACKET	116	430-02-010-0002	PLUNGER
46	430-02-054-0006	BLADE GUARD	117	430-02-406-0009	CRANK SHAFT ASSY, INCL:
47	905-01-010-2720	1/4" X 1" SPRING PIN	117A	905-01-010-2732	5/32" X 1" SPRING PIN
48	430-02-005-0006	BASE	118	920-04-010-7273	BALL BEARING
49	904-01-031-2923	FLAT WASHER	119	904-01-030-1644	FLAT WASHER
50	902-01-010-5446	5/8-11 HEX NUT	120	430-02-012-0007	HOUSING
55	905-01-010-6711	1/8" X 3/8" SPRING PIN	121	430-02-019-0001	ECCENTRIC
56	426-02-063-0001	TABLE INSERT	122	901-04-140-0275	1/4-28 X 1/4" HEX SOC SET SCREW
57	430-02-091-0002	TABLE	123	904-15-010-7042	EXT RET RING
58	901-06-450-2250	#04 X 3/16" ROUND HD SCREW	124	430-02-079-0005	RETAINER
59	406-03-137-0004	NAMEPLATE	125	928-07-010-7378	LOAD SPRING
60	430-02-027-0003	CLAMP SHOE	126	920-04-010-7272	BALL BEARING
61	426-02-095-0001	TRUNNION HALF	127	430-02-116-0002	GASKET <i>(Early Models Only, See Service Note A)</i>
62	951-02-010-7833	INDEX PLATE <i>(Early Models Only)</i>	128	904-07-010-5573	1/4" FIBER WASHER
63	904-02-020-1702	1/4" LOCK WASHER	129	901-02-010-0503	1/4-20 X 5/8" ROUND HD SCREW
64	901-02-010-0514	1/4-20 X 3/8" ROUND HD SCREW	130	400-06-079-0001	RETAINER
65	430-02-064-0003	PLAIN JAW	130	400-06-603-0001	ENVELOPE
			133	955-01-020-0022	.442" X .561" BOX END WRENCH

* NOT SHOWN ASSEMBLED

SERVICE NOTES:

A - Early models had gaskets, current models use Silicon sealer.

REPLACEMENT PARTS



REF
2


PART NUMBER	DESCRIPTION
201 430-02-320-0003	KNOB ASSY, INCL:
202 901-04-190-0253	1/4-20 X 1/4" HEX SOC SET SCREW
430-02-354-0007	GUARD ASSY, CONST OF:
203 430-02-014-0012	BRACKET
204 430-02-059-0001	HINGE
205 901-02-140-0584	#10-32 X 3/8" BIND HD SCREW
206 904-03-030-1795	3/16" EXT TOOTH WASHER
207 902-01-120-1203	#10-32 HEX NUT
208 901-02-453-1123	#10-32 X 1/2" PAN HD SCREW
209 430-02-112-0003	CARRIAGE BOLT
210 422-19-104-0001	SPACER
211 902-01-020-5435	5/16-18 JAM NUT
212 430-02-054-0007	GUARD
213 424-12-060-0003	KNOB
214 430-02-079-0004	RETAINER
217 901-02-011-8962	1/4-20 X 3" ROUND HD SCREW
218 422-18-104-0001	2" SPACER (<i>Variable Speed Models Only</i>)
218 430-02-104-0005	1 3/4" SPACER (<i>4 Speed Models Only</i>)
219 430-02-014-0011	ROD BRACKET (<i>Variable Speed Models Only</i>)
220 430-02-108-0008	CONTROL ROD (<i>Variable Speed Models Only</i>)
221 904-10-021-3846	COLLAR (<i>Variable Speed Models Only</i>)
222 901-02-010-0567	#06-32 X 1/4" ROUND HD SCREW (<i>Variable Speed Models Only</i>)
223 930-05-991-1643	BALL CRANK (<i>Variable Speed Models Only</i>), INCL:
224 901-04-190-0225	5/16-18 X 1/4" HEX SOC SET SCREW
225 902-01-010-5900	3/8-16 JAM NUT (<i>Variable Speed Models Only</i>)

REF
NO


PART NUMBER	DESCRIPTION
430-02-305-0008	BASE ASSY (<i>Variable Speed Models Only</i>), CONST OF:
229 430-02-005-0004	FIXED BASE
230 430-02-132-0001	SCALE
231 901-06-450-2252	#02 X 3/16" ROUND HD SCREW
232 901-11-020-0830	5/16-18 X 1 1/4" CARRIAGE HD SCREW
234 902-01-503-1514	5/16-18 FLANGE NUT
235 430-02-005-0002	MOTOR PLATE
236 422-04-075-5001	POINTER
237 901-02-010-0559	#10-32 X 1/2" ROUND HD SCREW
238 904-01-010-1610	FLAT WASHER
240 902-01-120-1203	#10-32 HEX NUT
241 901-01-060-0605	5/16-18 X 1/2" HEX HD SCREW
242 904-01-031-4993	FLAT WASHER
243 430-02-014-0007	CONTROL ROD NUT
245 430-02-104-0004	SPACER
246 901-02-010-0535	1/4-20 X 1 1/4" ROUND HD SCREW
247 904-02-020-1702	1/4" LOCK WASHER
248 904-01-031-4993	FLAT WASHER
249 904-01-010-1603	1/4" FLAT WASHER
250 902-01-120-1034	1/4-20 HEX NUT
251 901-11-020-0834	5/16-18 X 3/4" CARRIAGE HD SCREW
253 902-01-503-1514	5/16-18 FLANGE NUT
255 901-11-023-1497	1/4-20 X 5/8" CARRIAGE HD SCREW
256 902-01-293-1240	1/4-20 KEPS NUT
260 430-02-005-0005	BASE
261 901-11-020-0830	5/16-18 X 1 1/4" CARRIAGE HD SCREW (<i>4 Speed Models Only</i>)
263 902-01-503-1514	5/16-18 FLANGE NUT (<i>4 Speed Models Only</i>)
270 1200603	V-S MOTOR PULLEY
271 926-01-991-5604	DRIVEN PULLEY (<i>Variable Speed Models Only</i>), INCL:
272 901-04-150-0206	5/16-18 X 5/16" HEX SOC SET SCREW
273 49-303	V-BLT (<i>Variable Speed Models Only</i>)
275 49-340	V-BLT (<i>4 Speed Models Only</i>)
280 41-712	MOTOR PULLEY (<i>4 Speed Models Only</i>), INCL:
281 901-04-190-0201	5/16-18 X 5/16" HEX SOC SET SCREW
282 41-722	DRIVEN PULLEY (<i>4 Speed Models Only</i>), INCL:
283 901-04-190-0201	5/16-18 X 5/16" HEX SOC SET SCREW

* NOT SHOWN ASSEMBLED

REPLACEMENT PARTS



REF NO	PART NUMBER	DESCRIPTION
*	50-818	STAND, CONST OF:
301	430-02-115-0001	SHELF
302	1086711	TIE BAR - 34 1/2"
303	1086710	TIE BAR - 8 1/2"
304	436-02-066-0020	LEG
305	901-02-030-0408	5/16-18 X 3/4" FLAT HD SCREW
306	902-01-010-1300	5/16-18 HEX NUT
307	904-02-020-1704	3/8" LOCK WASHER
308	901-01-060-0642	3/8-16 X 1" HEX HD SCREW
*	NOT SHOWN ASSEMBLED	



REF NO	PART NUMBER	DESCRIPTION
*	40-202	INDIVIDUAL BLADE GUIDES, CONST OF:
320	902-01-120-1034	1/4-20 HEX NUT
321	904-01-031-2934	1/4" FLAT WASHER
322	430-02-055-0002	GUIDE
322	430-02-055-0003	GUIDE
322	430-02-055-0004	GUIDE
322	430-02-055-0005	GUIDE
322	430-02-055-0006	GUIDE
322	430-02-055-0007	GUIDE
323	430-02-014-0006	BRACKET
324	430-02-112-0002	SET SCREW
325	901-11-020-0821	1/4-20 X 3/4" CARRIAGE HD SCREW
326	901-04-260-1520	5/16-18 X 1/2" THUMB SCREW
*	40-204	LOWER BLADE GUIDES CONST OF:
327	901-01-060-0611	1/4-20 X 1/2" HEX HD SCREW
328	904-01-031-2934	1/4" FLAT WASHER
329	904-01-010-1614	FLAT WASHER
330	430-02-055-0013	GUIDE
330	430-02-055-0015	GUIDE
331	430-02-110-0002	POST
332	901-04-260-1528	5/16-18 X 1" THUMB SCREW
*	NOT SHOWN ASSEMBLED	

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Center for service/repairs. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.