


REPLACEMENT PARTS

REF NO	PART NUMBER	DESCRIPTION	REF NO	PART NUMBER	DESCRIPTION
*	43-354	Fence Assembly, Incl:	37	1088164	Clamp Rod Assembly, Incl:
1	432-01-089-0013	Fence Body - Left Hand	38	905-01-010-2721	1/8 X 7/8" Roll Pin
2	432-01-089-0012	Fence Body - Right Hand	39	905-01-010-2704	1/8 X 3/4" Roll Pin
3	432-01-004-0003	Clamp Plate	40	432-00-752-0001	Warning Label
4	902-01-201-2579	7/16-14 Hex Jam Nut	41	432-01-066-0005	Table Leg - Front
5	1087647	Adjusting Screw, Incl:	42	432-01-089-0014	Table Support - Rear
6	905-01-010-2706	3/16 X 1" Roll Pin	43	901-01-060-0671	1/2-20 X 1" Hex Hd Screw
7	432-01-047-0001	Half Collar	44	1088162	Sleeve
8	901-02-010-0551	#10-32 X 1/4" Rd Hd Screw	45	1088161	Sleeve
9	432-01-111-0005	Clamp Stud (Current Models Only)	46	432-01-014-0001	Spindle Housing Bracket
10	904-10-031-2097	Washer	47	901-01-060-0672	5/16-18 X 1 1/4" Hex Hd Screw
11	902-01-201-2579	7/16-14 Hex Jam Nut (Current Models Only)	48	432-01-105-0008	Bearing Cone
12	422-34-067-0001	Clamp Handle (Current Models Only)	49	928-01-021-4131	Coil Spring
13	406-03-122-0002	Compression Spring (Current Models Only)	50	901-04-150-0205	5/16-18 X 1/4" Hex Soc Set Screw
14	406-03-112-0006	Special Screw (Current Models Only)	51	432-01-105-0007	Spring Collar
15	432-01-111-0001	Clamp Stud (Early & Intermediate Models Only)	52	901-07-251-3247	Stud
16	904-10-031-2097	Washer	53	432-01-138-0001	Handle
17	928-01-021-4125	Coil Spring (Early Models Only)	54	432-01-054-0005	Spindle Pulley Guard
18	432-01-027-0004	7/16-14 Serrated Nut (Early Models Only)	55	901-02-010-0506	5/16-18 X 5/8" Rd Hd Screw
19	406-03-033-0001	Clamp Handle (Early Models Only)	56	43-935	1/2" Cutter Spindle, Incl:
20	406-03-122-0002	Compression Spring (Intermediate Models Only)	57	902-01-201-2575	1/2-16 Special Hex Nut
20A	904-01-010-1603	3/16" Flat Washer (Early Models Only)	58	904-05-010-1646	Keyed Lockwasher
21	406-03-112-0003	Special Screw (Intermediate Models Only)	59	432-01-406-0002	Spindle Housing w/Bearing, Incl:
21A	901-02-010-0509	1/4-20 X 1/2" Rd Hd Screw (Early Models Only)	60	926-01-051-4639	Pulley
22	424-12-060-0003	Knob	61	905-04-071-3119	Steel Pin
23	904-01-031-2937	5/16" Flat Washer	62	902-01-200-9847	Special Hex Jam Nut
24	432-02-043-0002	Fence - Left (Current Models Only)	63	901-07-251-3248	Tie Bar
24A	432-01-011-0002	Wooden Fence Plate - Left (Intermediate Models Only)	64	902-01-201-2585	Special Hex Nut
24B	432-01-011-0001	Wooden Fence Plate (Early Models Only)	65	49-105	V-Belt
25	432-02-043-0001	Fence - Right (Current Models Only)	66	43-805	Motor Pulley, Incl:
25A	432-01-011-0003	Wooded Fence Plate - Right (Intermediate Models Only)	67	901-04-150-0206	5/16-18 X 5/16" Hex Soc Set Screw
26	904-01-010-1620	5/16" Flat Washer	68	901-01-060-0672	1/2-20 X 1 1/4" Hex Hd Screw
27	901-02-010-0523	5/16-18 X 1 1/2" Rd Hd Screw (Current Models Only)	69	904-02-020-1705	1/2" Lockwasher
27A	901-02-010-0515	5/16-18 X 1 1/4" Rd Hd Screw (Early & Intermediate Models Only)	70	904-01-010-1636	1/2" Flat Washer
28	432-01-111-0003	Clamp Stud	71	432-01-089-0015	Motor Mounting Plate
29	432-01-091-0001	Table	72	901-11-020-0830	5/16-18 X 1 1/4" Carriage Bolt
30	432-01-063-0001	Table Insert	73	904-01-010-1620	5/16" Flat Washer
31	905-03-010-2422	Taper Pin	74	904-02-010-1703	5/16" Lockwasher
32	432-01-754-0001	Nameplate	75	902-01-010-1300	5/16-18 Hex Nut
33	901-06-450-2250	#4 X 3/16" Drive Screw	*	43-440	4 1/2" Dia Spindle Guard, Incl:
34	432-01-054-0003	Belt Guard	77	432-02-104-0006	Spacer
35	901-01-060-0605	5/16-18 X 1/2" Hex Hd Screw	78	43-555	3/4 to 1/2" Adapter, Incl:
36	904-01-010-1620	5/16" Flat Washer	79	432-02-104-0008	Spacer
			80	955-01-020-0023	9/16 & 7/8" Double End Wrench
			**	424-01-014-0002	Switch Guard
			**	43-185	Router Spindle, Incl:
			**	42154	1/4" Collet (Order this part from Porter Cable Corp.)

* NOT SHOWN ASSEMBLED
 ** NOT SHOWN

**50-513
SHAPER STAND**



REPLACEMENT PARTS


REF

NO	PART NUMBER	DESCRIPTION
*	50-513	Shaper Stand, Const Of:
100	901-01-060-0602	5/16-18 X 1 1/4" Hex Hd Screw
101	904-01-010-1620	5/16" Flat Washer
102	904-02-010-1703	5/16" Lockwasher
103	1087946	Top Shelf
104	436-06-031-0004	Panel
105	426-02-103-0002	Tie Bar
106	902-01-120-1034	1/4-20 Hex Nut
107	904-02-020-1702	1/4" Lockwasher
108	904-01-010-1614	1/4" Flat Washer
109	400-06-048-0001	Rubber Foot
110	901-02-120-7504	1/4-20 X 5/8" Truss Hd Screw
111	901-11-020-0834	5/16-18 X 3/4" Carriage Bolt
112	904-01-010-1605	5/16" Flat Washer
113	904-02-010-1703	5/16" Lockwasher
114	902-01-010-1300	5/16-18 Hex Nut

* NOT SHOWN ASSEMBLED


ACCESSORY REPLACEMENT PARTS

43-358 SPRING HOLD DOWNS



REF NO	PART NUMBER	DESCRIPTION
*	43-358	Spring Hold Downs, Const Of:
150	432-01-014-0003	Clamp Block
151	901-03-010-0762	5/16-18 x 1/2" Soc Hd Screw
152	432-01-111-0002	Stud
153	432-01-108-0002	Rod
154	928-09-021-4129	Spring
155	432-01-014-0004	Clamp Block
156	432-09-001-0001	Adapter
157	901-01-060-3124	1/4-20 x 1 1/12" Hex Hd Screw
158	955-03-010-0006	1/4" Wrench

* NOT SHOWN ASSEMBLED




34-895 MITER GAGE

REF NO	PART NUMBER	DESCRIPTION
*	34-895	Miter Gage, Const Of:
170	422-01-355-0004	Miter Gage Body, Incl:
171	901-04-410-4561	Special Set Screw
172	902-01-200-1086	Special Nut (Early Models Only)
173	901-04-150-9428	#8-32 x 1/2" Special Screw
174	422-02-060-0003	Lock Knob (Current Models Only)
174A	422-02-060-0001	Lock Knob (Early Models Only)
176	904-07-010-5555	Fiber Washer
177	422-04-004-0001	Bar
178	901-07-261-3237	Stud (Early Models Only)
179	422-01-088-0002	Stop Link
180	905-04-061-2351	Special Pin
181	422-01-075-0001	Pointer
182	901-04-410-4561	Special Screw
183	422-04-072-0001	Plate
184	901-02-030-5750	1/4-28 x 5/16" Flat Hd Screw
185	422-01-112-0001	Special Pivot Screw
186	37-522	Open End Wrench (Early Models Only)


* NOT SHOWN ASSEMBLED

ACCESSORY REPLACEMENT PARTS



**43-198
TABLE INSERT**

REF NO	PART NUMBER	DESCRIPTION
*	43-198	Table Insert, Const Of:
190	904-10-161-3875	Collar
191	904-10-161-3874	Collar
* NOT SHOWN ASSEMBLED		



**43-359
RING GUARD**

REF NO	PART NUMBER	DESCRIPTION
*	43-359	Ring Guard, Const Of:
195	432-01-014-0006	Flat Spring
196	901-01-060-0607	5/16-18 x 3/4" Hex Hd Screw
197	904-01-010-1620	5/16" Flat Washer
198	432-02-054-0001	Guard
199	901-02-010-0554	#8-32 x 3/8" Rd Hd Screw
200	1087782	Post
201	904-02-010-1703	5/16" Lockwasher
202	902-01-010-1300	5/16-18 Hex Nut
203	432-01-014-0005	Bracket
204	902-01-020-5433	3/8-16 Hex Jam Nut
205	904-03-030-1756	3/8" External Tooth Lockwasher
206	1087529	Hand Knob
207	901-01-060-0617	3/8-16 x 1 1/2" Hex Hd Screw
208	1087556	Plug
209	901-01-060-0608	5/16-18 x 7/8" Hex Hd Screw
210	904-02-010-1703	5/16" Lockwasher
211	902-01-010-1300	5/16-18 Hex Nut
212	432-09-014-0006	Adapter
213	901-01-060-0607	5/16-18 x 3/4" Hex Hd Screw
214	904-02-010-1703	5/16" Lockwasher

* NOT SHOWN ASSEMBLED

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.