





REPLACEMENT PARTS

<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>	<u>REF. NO.</u>	<u>PART NUMBER</u>	<u>DESCRIPTION</u>
1	1342648	MOTOR ASSY, <i>INCL:</i>	26	1342657	COVER, <i>INCL:</i>
**	1342838	CAPACITOR (25UF)	26A	1342461	WARNING LABEL
**	1342839	STRAIN RELIEF	27	904-01-031-5655	FLAT WASHER
**	1342840	CORD	28	1343572	GASKET
2	1343759	SWITCH, <i>INCL:</i>	29	1342922	5/16-18 LOCK NUT
3	1343758	KEY	30	904-01-031-2945	5/16" FLAT WASHER
4	1342649	HOUSING, <i>INCL:</i>	31	1342922	5/16-18 LOCK NUT
5	1342460	NAMEPLATE	32	904-01-031-2934	1/4" FLAT WASHER
6	1348230	WARNING LABEL	33	1342932	1/4-20 LOCK NUT
8	1348231	ROTATION LABEL	34	1342659	DEFLECTOR
9.	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR	35	1342721	CHUTE
10	1342650	DUST GATE	36	1342722	DUST GATE, <i>INCL:</i>
11	1343390	5/16" LOCK WASHER	36A	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SC
12	901-01-060-0606	5/16-18 X 5/8" HEX HD SCR	37	1342723	UPPER DRUM
13	1342652	IMPELLER	38	901-01-060-3118	5/16-18 X 3" HEX HD SCR
14	1342793	SPECIAL WASHER	39	1342655	CLAMP
15	1342794	SPECIAL NUT	40	1342922	5/16-18 LOCK NUT
16	1342476	CLAMP	41	904-01-031-2945	5/16" FLAT WASHER
17	50-194	HOSE (<i>SEE NOTE A</i>)	42	1350291	3/8-16 HEX NUT
18	901-01-060-0612	1/4-20 X 5/8" HEX HD SCR	43	904-02-020-1704	3/8" LOCK WASHER
18A	904-01-031-2934	1/4" FLAT WASHER	44	904-01-010-1605	3/8" FLAT WASHER
19	1342658	FLANGE	45	1350291	3/8-16 HEX NUT
20	901-01-060-0606	5/16-18 X 5/8" HEX HD SCR	46	904-02-020-1704	3/8" LOCK WASHER
21	904-01-031-5655	FLAT WASHER	47	1342725	BRACKET
22	901-01-060-0606	5/16-18 X 5/8" HEX HD SCR	48	1342727	CASTER
23	904-01-031-5655	FLAT WASHER	49	901-01-060-0640	3/8-16 X 3/4" HEX HD SCR
24	901-01-060-0606	5/16-18 X 5/8" HEX HD SCR	50	1342724	LOWER DRUM
25	1342728	FLANGE	51	1342654	DUST BAG
25A	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR	52	1342726	BAND CLAMP
25B	1342656	GASKET	53	1342653	ELBOW

** NOT SHOWN

NOTE A: REPLACEMENT HOSE IS PROVIDED OVERSIZE AND MUST BE CUT TO PROPER LENGTH



STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.