





REPLACEMENT PARTS

REF. NO.	PART NUMBER	DESCRIPTION	REF. NO.	PART NUMBER	DESCRIPTION
1	1342628	REDUCER	22	1342639	BAND CLAMP
2	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR	23	1342640	DUST BAG
3	1342629	UPPER CHUTE	24	904-01-031-2934	1/4" FLAT WASHER
4	901-01-060-0648	3/8-16 X 1 1/4" HEX HD SCR	25	1342932	1/4-20 LOCK NUT
5	904-01-031-2929	FLAT WASHER	26	901-01-060-0602	5/16-18 X 1 1/4" HEX HD SCR
6	1342630	GASKET	26A	904-01-031-2937	FLAT WASHER
7	410-06-027-0002	CLAMP 5"	27	1342641	SPECIAL WASHER
8	50-187	HOSE (SEE NOTE A)	28	1342642	SPECIAL SCR
9	1342631	MOTOR ASSY, 1-1/2HP, INCL:	29	901-01-060-0607	5/16-18 X 3/4" HEX HD SCR
**	1348229	WIRING LABEL	30	904-01-031-2945	5/16" FLAT WASHER
**	1342632	CAPACITOR (200 UF)	31	1342643	COVER, INCL:
**	1346564	STRAIN RELIEF	31A	1342461	WARNING LABEL
**	1342633	POWER CORD	32	1343573	GASKET
**	1340371	KEY	33	1342644	GASKET
10	1343759	SWITCH, INCL:	34	901-01-060-0612	1/4-20 X 5/8" HEX HD SCR
11	1343758	KEY	35	1342645	CHUTE
12	901-02-303-1066	#10-24 X 1/2" PAN HD SCR	36	904-01-031-2934	1/4" FLAT WASHER
13	1342634	GASKET	37	1342932	1/4-20 LOCK NUT
14	901-01-060-0612	1/4-20 X 5/8" HEX HD SCR	38	904-01-031-2945	5/16" FLAT WASHER
15	1342635	UPPER HOUSING, INCL:	39	1342922	5/16-18 LOCK NUT
16	1348230	WARNING LABEL	40	1342646	LOWER CHUTE
17	1342636	LOWER HOUSING	41	904-01-031-6202	FLAT WASHER
17A	1342647	IMPELLER	43	1350279	3/8-16 LOCK NUT
18	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR	44	1343574	DUST GATE, INCL:
19	1342637	DUST GATE	45	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR
20	1310547	(DIN 7981B) M4.2 X 12MM PAN HD SCR			
21	1342638	ELBOW			

** NOT SHOWN

NOTE A: REPLACEMENT HOSE IS PROVIDED OVERSIZE AND MUST BE CUT TO PROPER LENGTH



STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta International Machinery Corp. strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repair. Any product which is presented to a Delta Authorized Service Center for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your local service outlet.