




50-880 Wiring Diagram

REPLACEMENT PARTS

Ref.			
No.	Part No.	Description	
1	898953	BACK CURTAIN	
2	898954	SCREW	
3	898933	WASHER	
4	898932	NUT	
5	898956	SIDE CURTAIN	
9	n 902253	CURTAIN FRAME, T2	
	899482	CURTAIN FRAME, T1	
10	898959	HANDLE ASSY	
12	n 902253	TABLE TOP, T2	
	898961	TABLE TOP, T1	
13	898962	GROMMET	
14	n 902262	SKEW BOARD, T2	
	898964	SKEW BOARD, T1	
15	n 902257	BRACKET, T2	
	898966	BRACKET, T1	
16	n 902256	BRACKET, T2	
	898968	BRACKET, T1	
17	898934	SCREW	
31	n 902264	BACK MIDDLE BOARD, T2	
	898970	BACK MIDDLE BOARD, T1	
32	n 902263	MIDDLE BOARD, T2	
	900509	MIDDLE BOARD, T1	
39	n 902260	TOP MIDDLE BOARD, T2	
	898975	TOP MIDDLE BOARD, T1	
40	n 902259	BOTTOM MIDDLE BOARD, T2	
	898977	BOTTOM MIDDLE BOARD, T1	
43	898939	SCREW	
44	n 902247	SCREEN, T2	
	898940	SCREEN, T1	
45	n 902258	FILTER , T2	
	899484	FILTER , T1	
46	n 902248	MOTOR CASE, T2	
	898943	MOTOR CASE, T1	
47	898981	CASTER	
52	n 902249	TABLE FOOT, T2	
	898983	TABLE FOOT, T1	
53	898984	BOOT	
54	898945	FAN	
55	898946	SCREW	
56	n 902668	WASHER	
57	n 902250	DEFLECTOR, T2	
	898949	DEFLECTOR, T1	
58	n 902668	WASHER	
60	898951	MOTOR	
61	1340095	SWITCH	
62	n 903216	CURTAIN SIDE ROD R.H., T2	
	899002	CURTAIN SIDE ROD, T1	
63	n 902255	CURTAIN BACK ROD, T2	
	899003	CURTAIN BACK ROD, T1	
64	n 902745	WARNING LABEL, T2	
	898887	WARNING LABEL, T1	
65	899178	CORD	
70	899185	STRAIN RELIEF	
71	898985	WRENCH	
72	899480	SCREW-SHEET METAL	
73	n 902793	DEC LABEL, T2	
74	n 903216	CURTAIN SIDE ROD L.H, T2	

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product which is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.