



REPLACEMENT PARTS

| Ref. | No. | Part No. | Description |
|------|-----|-----------------|------------------------------|
| | 1 | 902181 | MOTOR, INCL.: REF. 15B |
| | 2 | 902178 | GASKET |
| | 3 | 901-01-060-0611 | 1/4-20 X 1/2" HEX HD SCREW |
| | 4 | 1343390 | 5/16" LOCK WASHER |
| | 5 | 902179 | BLOWER COVER |
| | 6 | 902180 | GASKET |
| | 7 | 902177 | IMPELLER |
| | 8 | 904-01-010-1604 | 5/16" FLAT WASHER |
| | 10 | 903044 | LOWER HANGER |
| | 11 | 901-01-060-0607 | 5/16-18 X 3/4" HEX HD SCREW |
| | 12 | 902176 | UPPER HANGER |
| | 13 | 902173 | TOP DUST BAG |
| | 14 | n 908869 | CLAMP |
| | 15A | 1348463 | SWITCH HOUSING |
| | 15B | 908005 | CAPACITOR |
| | 15C | 1348465 | CLAMP |
| | 15D | 901-06-121-7383 | 10-24 X 3/8" PAN HD SCREW |
| | 15E | 1320187 | 10-24 X 1/4" PAN HD SCREW |
| | 15F | 1343759 | SWITCH, INCL.: |
| | | 438-01-017-0141 | OPTIONAL 240V SWITCH, INCL.: |
| | 15G | 1343758 | SWITCH KEY |
| | 15H | 1348466 | POWER CORD |
| | 17 | 903045 | BLOWER HOUSING |
| | 18 | 902174 | BOTTOM DUST BAG |
| | 19 | 903046 | SUPPORT |
| | 20 | 902-01-010-1300 | 5/16-18 HEX NUT |
| | 21 | 1343390 | 5/16" LOCK WASHER |
| | 23 | 901-01-060-0606 | 5/16-18 X 5/8" HEX HD SCREW |
| | 25 | 903047 | BOARD |
| | 29 | 1350291 | 3/8-16 HEX NUT |
| | 30 | 1350288 | 3/8" LOCK WASHER |
| | 31 | 903020 | CASTER |
| | 32 | 903048 | BASE |
| | 33 | 1346521 | CAP |
| | 34 | 1342476 | CLAMP |
| | 35 | 50-530 | 4" X 5' DUST HOSE |
| | 36 | 905750 | NAME PLATE |
| | 37 | 902737 | ROTATION LABEL |
| | 38 | 902781 | WARNING LABEL |
| | 39 | 902713 | WARNING LABEL |
| | 40 | 902185 | HARDWARE PACK |

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.