





# REPLACEMENT PARTS

Ref.

| No. | Part No.        | Description                    |
|-----|-----------------|--------------------------------|
| 1   | 902581          | M6 X 80MM CARRIAGE HD SCR      |
| 2   | 901911          | EYESHIELD                      |
| 3   | 900227          | FLAT WASHER                    |
| 4   | 902582          | M6 KNOB                        |
| 5   | 902583          | SPACER                         |
| 6   | 902584          | RIGHT SPARK BREAKER            |
| 7   | 1320090         | FLAT WASHER                    |
| 8   | 1340609         | 1/4-20 X 1/4" HEX HD SCREW     |
| 9   | 908948          | KNOB                           |
| 10  | 908949          | R. H. COVER                    |
| 15  | 908955          | FLANGE                         |
| 16  | 23-269          | WHITE FRIABLE GRINDING WHEEL   |
| 18  | 908957          | R. H. WHEEL GUARD              |
| 19  | 900839          | ROTATIONAL LABEL               |
| 20  | 901-02-120-7528 | 1/4-20 X 1/2" SCREW            |
| 21  | 1320828         | TOOL REST ASSY                 |
| 22  | 904-02-010-1703 | LOCK WASHER                    |
| 23  | 901-01-060-0607 | 5/16"-18 X 3/4" HEX HD SCREW   |
| 24  | 904-01-010-1605 | FLAT WASHER                    |
| 25  | 901-01-060-0606 | 5/16"-18 X 5/8" HEX HD SCREW   |
| 26  | 1340644         | 10-24 X 5/8" SCREW             |
| 27  | 908958          | END BELL                       |
| 28  | 1346461         | M05 X 0.8 X 05 HEX SOC SET SCR |
| 29  | 908959          | PLATE                          |
| 30  | 908960          | SENSOR                         |
| 31  | 902638          | M3 X 6MM RD HD SCREW           |
| 33  | 905844          | WARNING PLATE                  |
| 40  | 902586          | LEFT SPARK BREAKER             |
| 49  | 908964          | L. H. WHEEL GUARD              |
| 52  | 23-270          | 36G GRINDING WHEEL             |
| 57  | 908968          | L. H. COVER                    |
| 60  | 1320125         | POWER CORD                     |
| 61  | 1320003         | 10-24 X 1/4" SCREW             |
| 62  | 1320101         | EXT TOOTH WASHER               |
| 63  | 1310057         | STRAIN RELIEF                  |
| 64  | 1320005         | 10-24 X 3/8" SCREW             |
| 65  | 1320211         | PLATE                          |
| 66  | 902643          | M4 X 8MM PAN HD SCREW          |
| 67  | 902644          | DRESSER HOLDER                 |

Ref.

| No. | Part No.        | Description                                                        |
|-----|-----------------|--------------------------------------------------------------------|
| 68  | 23-006          | WHEEL DRESSER                                                      |
| 69  | 902645          | WRENCH HOLDER                                                      |
| 70  | 902590          | 10MMX12MM WRENCH                                                   |
| 74  | 912837          | LAMP ASSY                                                          |
| 75  | 900843          | WARNING LABEL                                                      |
| 76  | 1343759         | SWITCH                                                             |
| 78  | 1246007         | M04 X 0.7 X 08 HEX SOC SET SCR                                     |
| 79  | 1342734         | KNOB                                                               |
| 81  | 902647          | VARIABLE SPEED LABEL                                               |
| 82  | 902648          | SWITCH PLATE                                                       |
| 83  | 904-02-020-1702 | LOCK WASHER                                                        |
| 84  | 902-01-120-1034 | 1/4"-20 HEX NUT                                                    |
| 85  | 908970          | CAPACITOR                                                          |
| 87  | 908972          | CAPACITOR CLAMP                                                    |
| 88  | 908971          | CIRCUIT BOARD ASSY                                                 |
| 89  | 1343545         | WASHER                                                             |
| 90  | 1344955         | M03.9 X 08 SCREW                                                   |
| 91  | 1320217         | PAD                                                                |
| 92  | 1320087         | WASHER                                                             |
| 93  | 901-02-010-0525 | 10-24 X 1/2" ROUND HD SCREW                                        |
| 94  | 902651          | BASE COVER                                                         |
| 100 | 908951          | R. H. QUICK RELEASE NUT                                            |
| 101 | 908966          | L. H. QUICK RELEASE NUT                                            |
| 102 | 901930          | TOOL REST HRDW PKG                                                 |
|     |                 | INCL., REF. 18, 19, 20, 21 & 22                                    |
| 103 | 903504          | HRDW PKG, INCL., REF. 1, 3, 4, 5, 6, 7, 8, 19, 20, 21, 22, 27 & 69 |
| **  | 909474          | 8" BUFFING WHEEL                                                   |
| **  | 909475          | BUFFING WHEEL SPACER                                               |
| **  | NOT SHOWN       |                                                                    |



## STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product that is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

*This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.*