





REPLACEMENT PARTS

Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
1	899881	UPPER GUARD
2	1349910	DUST DEFLECTOR
3	1243322	M04 X 0.7 X 08 SCREW
4	905751	NAMEPLATE
5	1342930	CLAMP
6	1243394	M5 X .8 X 10 SCREW
7	1246079	M8 X 11/4 X 40 HEX HD SCREW
8	1246004	M6 X 1 X 16 HEX SOC HD SCREW
9	1243520	WASHER
10	1349809	BRACKET
11	1243398	HEX NUT
13	1243456	HEX NUT
14	1343101	SCREW
15	1349817	SPRING SLEEVE
16	1349816	SPRING
17	1310311	ROLL PIN
18	911769	HANDLE ASSEMBLY
19	1343545	WASHER
20	1243501	M4 X .7 X 10 CHEESE HD SCREW
21	1246045	M6 X 1 X 10 CHEESE HD SCREW
23	1349493	PINCH GUARD
25	1343504	LOCK NUT
26	1349813	PIVOT BOLT
27	1246051	M5 X .8 X 12 HEX SOC HD SCREW
28	1349812	PLATE
29	1349953	SCREW
30	1349811	BUMPER
31	910816	PIN
32	1345534	O-RING
33	1313165	LOCK NUT
34	1341547	RETAINING RING
35	899888	SCALE
36	1310016	5MM DRIVE SCREW
38	1243581	M4 X .7 X 6 HEX SOC SET SCREW
39	899912	TABLE
40	899913	HANDLE ASSY
43	900408	TRUNNION
45	1345468	POINTER
46	1343013	SPRING
47	1343642	M6 X 1 LOCK NUT
48	1342991	CLAMP SHAFT
49	900185	TRIGGER COVER
50	1342992	INDEX PIN
51	1342995	TRIGGER
52	1343009	SPRING
53	1342990	CLAMP
54	1346910	NYLON PAD
55	1342973	PIVOT STUD
56	1343008	NYLON INSERT
57	1243526	M8.4 FLAT WASHER
58	A03641	POINTER
59	1246102	M5 FLAT WASHER
60	1243394	M5 X .8 X 10 CHEESE HD SCREW
61	899914	RH FENCE
62	1330147	M8 X 1.25 X 40 HEX SOC HD SCREW
63	1246157	'8MM LOCK WASHER
64	899915	LH FENCE
65	1330410	M5 X 20 ROLL PIN
66	1342981	STABILIZER BAR
67	899916	BASE
68	1310016	5MM DRIVE SCREW

Ref.

<u>No.</u>	<u>Part No.</u>	<u>Description</u>
69	899919	SCALE
70	1341947	WASHER FLAT WASHER
71	1342123	M8 LOCK NUT
72	1246064	RETAINING RING
73	1345426	SHAFT
74	1345427	EXTENSION WING
75	1346291	M5.3 FLAT WASHER
76	1343538	M5.1 LOCK WASHER
77	1246047	M5 X .8 X 16 CHEESE HD SCREW
78	1349810	STUD
79	1246016	M8 X 1.25 X 25 HEX HD SCREW
81	1246127	M6 X 1 X 30 HEX SOC SET SCREW
82	1246175	M06 X 1 X 30 HEX HD SCREW
83	1243456	HEX NUT
84	A03645	BRACKET
85	1246117	M4 X .7 X 10 FLAT HD SCREW
86	899911	TABLE INSERT
89	36-221	CLAMP
120	1320101	WASHER
121	1246102	WASHER
122	1343538	WASHER
123	900234	HARDWARE PKG
196	1348257	WARNING LABEL



REPLACEMENT PARTS

Ref.			Ref.		
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
25	1343504	LOCK NUT	156	1342998	SPRING
101	900225	SCREW	157	899898	LOWER GUARD
102	1246102	M5 FLAT WASHER	158	1345433	PLATE
103	1343538	M5.1 LOCK WASHER	159	1345418	LINK
104	1343019	3/8" GROMMET	161	1342906	1/2" BLADE WRENCH
105	1344952	M4.2 X 16MM PAN HD SCREW	162	432-07-101-0004	5MM HEX WRENCH
106	1345695	CORD CLAMP	164	900260	BRACKET FOR HANDLE
108	A03647	BRUSH	179	899917	WARNING LABEL (HANDLE)
109	A03648	BRUSH HOLDER	180	A03646	MOTOR ASSY.
112	899864	WARNING LABEL			
118	1347137	BEARING			
119	1310042	BEARING			
125	1343259	NEEDLE BEARING			
126	1347162	M4 X 18 PN HD SCREW			
127	1243525	M4 LOCK WASHER			
128	1347133	JACKSHAFT ASSY			
134	904367	HANDLE SET			
135	899883	SWITCH			
136	1340406	M4.2 X 10 PAN HD SCREW			
137	1246056	M6 X 1 X 12 HEX SOC HD SCREW			
138	1343051	M4.2 X 20 PAN HD SCREW			
142	1345695	CORD			
144	1341235	M4 X .7 X 12 CHEESE HD SCREW			
150	900243	DUST BAG ASS'Y			
151	1345431	SCREW			
152	SEE CATALOG	BLADE, NOTE A:			
153	1347150	OUTER FLANGE			
154	1342989	ARBOR BOLT			
155	1343054	M5 X 10MM CARRIAGE HD SCREW			

NOTE A: USE CROSS CUT BLADES ONLY DO NOT USE BLADES DESIGNED FOR RIPPING, COMBINATION BLADES OR BLADES WITH EXCESSIVE HOOK ANGLES

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product which is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.