



REPLACEMENT PARTS

Ref.			
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	
1	900200	TABLE INSERT	
2	n 897374	M3 X 12MM SPRING PIN	
3	900201	TABLE	
4	1343642	M6 LOCK NUT	
5	900202	CLAMP ASSY	
6	1243502	M10 FLAT WASHER	
7	1343643	SCALE	
8	1246140	M6.4 FLAT WASHER	
9	1243520	M6.1 LOCK WASHER	
10	1246014	M6 X 15MM HEX HD SCREW	
11	1310143	M5 X 8MM PAN HD SCREW	
12	1343649	GUARD	
13	1340490	M4 X 8MM CHEESE HD SCREW	
14	1343607	POINTER	
15	1246086	M5 X 20MM HEX HD SCREW	
16	1243395	M5 HEX NUT	
17	900674	MOTOR	
19	1343464	COLLAR	
20	1343608	SPECIAL SCREW	
21	900203	BASE	
22	1343651	COVER	
23	1310006	M5 X 20MM ROUND HD SCREW	
24	1310216	M8.4 EXT TOOTH WASHER	
25	1246033	M8 X 25MM CHEESE HD SCREW	
26	1342732	SWITCH BOX	
27	1342733	PLATE	
27A	1346435	M4 PUSH NUT	
28	1310135	M4 X 8MM FLAT HD SCREW	
29	1343612	M3.9 13MM FLAT HD SCREW	
30	1342735	BEZEL	
31	1343614	POWER SWITCH	
32	1243501	M4 X 10MM CHEESE HD SCREW	
33	1246007	M4 X 8MM HEX SOC SET SCREW	
34	1342734	KNOB	
35	1340329	SCALE	
36	1246117	M4 X 10MM FLAT HD SCREW	
36A	1347104	LABEL	
37	1343644	BUSHING	
38	1349775	POWER CORD	
39	1310210	M4.3 EXT TOOTH WASHER	
40	1243525	M4.1 LOCK WASHER	
41	1243569	M4 HEX NUT	
42	1343610	RUBBER FOOT-FRONT	
43	1343650	SLEEVE	
44	1342736	SLEEVE-SMALL	
45	1346434	CLAMP	
46	1343538	M5.1 LOCK WASHER	
47	1243395	M5 HEX NUT	
48	1243398	M8 HEX NUT	
49	1243526	M8.4 FLAT WASHER	
50	1243502	M10 FLAT WASHER	
51	1243360	M10.2 LOCK WASHER	
52	1246018	M10 X 25MM HEX HD SCREW	
53	900204	PLATE	
54	1343645	RUBBER FOOT-REAR	
55	1343652	SPECIAL SCREW	
56	1342739	CONTROL BOX	
57	1343545	M4.1 FLAT WASHER	
58	1310161	M4 X 18MM PAN HD SCREW	
59	1342740	COVER	
60	1330398	M4 X 12MM FLAT HD SCREW	
61	900675	CONTROL BOARD	
62	1342742	JUMPER	
63	n 900675	VARIABLE SPEED SWITCH	
64	900152	HARDWARE PACK	



REPLACEMENT PARTS

Ref.			Ref.		
<u>No.</u>	<u>Part No.</u>	<u>Description</u>	<u>No.</u>	<u>Part No.</u>	<u>Description</u>
100	900205	CLAMP ASSY	138	1343634	M5 SQUARE NUT
101	900206	BRACKET	139	1330410	M5 X 20MM SPRING PIN
102	1343600	SUPPORT ROD	140	1341011	M8 X 10MM HEX SOC SET SCREW
103	1341011	M8 X 10MM HEX SOC SET SCREW	141	1343635	LONG BUSHING
104	1343603	HOLD DOWN ROD	142	1343636	LINK
105	1341011	M8 X 10MM HEX SOC SET SCREW	143	1310146	M5 X 30MM PAN HD SCREW
106	1342455	M5 X 10MM PAN HD SCREW	144	1344933	M5 X 20MM HEX SOC HD SCREW
107	1246140	M6.4 FLAT WASHER	145	1343538	M5.1 LOCK WASHER
108	1343605	AIR NOZZLE	146	1341439	BALL BEARING
109	900207	HOLD DOWN BLOCK	147	1343638	SHORT BUSHING
110	1347328	HOLD DOWN FOOT	148	1343639	COUNTER BALANCE
111	1246102	M5.3 FLAT WASHER	149	1342731	PIVOT BOLT
112	1343538	M5.1 LOCK WASHER	150	1344954	M14.2 WAVE WASHER
113	1342455	M5 X 10MM PAN HD SCREW	151	1343623	SPECIAL SCREW
114	1343628	ECCENTRIC	152	900210	LOWER ARM
115	1343627	LEVER	153	1343659	M5 SQUARE NUT
116	1343626	SLEEVE	155	1343597	COVER
117	1342730	AIR DIAPHRAGM	156	1330397	M5 X 12MM FLAT HD SCREW
118	900214	SCREW W/KNOB	157	900208	SUPPORT
119	1343630	SPRING	158	1330397	M5 X 12MM FLAT HD SCREW
120	900209	UPPER ARM	159	1343599	TOOL HOLDER
121	1343631	GROMMET	160	900091	WARNING LABEL
122	1343632	BLADE SUPPORT	161	1341011	M8 X 10MM HEX SOC SET SCREW
123	1246109	M5 X 16MM SPRING PIN	201	1343648	BLADE WRENCH
124	1246160	M5 X 32MM SPRING PIN	202	422-29-101-0002	4MM HEX WRENCH
125	908-25-013-1439	O RING	203	900211	PLASTIC INSERT
*	40-251	QCK SET BLD CHUCK	204	OPTIONAL	BLADE
126	1347103	M4 X 16MM HEX HD SCREW	205	1347102	WRENCH
127	1346120	BLADE CLAMP			
128	1346124	CAM			
129	1347101	SPRING			
130	1346122	SPRING			
131	1346119	M4 LOCK NUT			
132	1346123	BUSHING			
133	1346121	PAD			
134	1343621	CHIP BLOWER TUBING			
135	1343620	LINK			
136	1246051	M5 X 12MM HEX SOC HD SCREW			
137	1343658	BLADE HOLDER			

* NOT SHOWN ASSEMBLED

ACCESSORIES: (Optional)

STANDARD SAFETY EQUIPMENT

In order to promote tool safety, Delta Machinery strictly enforces the policy of repairing or replacing any damaged or missing standard safety equipment on machines presented to Delta Authorized Service Centers for service/repairs. Any product which is presented to a Delta Authorized Service Centers for repairs which contains missing or damaged standard safety equipment will have that equipment repaired or replaced and the customer will be charged for any such service/repairs. Customers can avoid such charges only if the missing safety component is supplied to the service center at the time of repair.

This parts list is provided to aid in obtaining service parts. Copies of the instruction and maintenance literature can be obtained through the Delta Technical Publications Department or through your service outlet.