




Parts List for 892 Type 1

Item Number	Part Number	Description	Qty Required
1	A22701	MOTOR HOUSING	1
3	886538	SCREW	10
4	A10193	CORDSET	1
4	901266	STRAIN RELIEVER	1
5	696276	SCREW	10
6	610559-00	SWITCH	1
7	908697	BUSHING	1
8	A13684	BRUSH & HOLDER ASSY	2
9	682063	CONNECTOR VS	1
10	823030	SNAP-RING	1
11	876671	COLLET 1/2 INCH	1
11	876669	COLLET 1/4 INCH	1
11	42950	1/2 INCH COLLET ASSY	1
11	42999	1/4 INCH COLLET ASSY	1
11	42975	3/8 INCH COLLET ASSY	1
11	42975	3/8 INCH COLLET ASSY	1
11	42999	1/4 INCH COLLET ASSY	1
11	44010	COLLET 10MM	1
11	44008	COLLET 8MM	1
11	44006	COLLET 6MM	1
11	42999	1/4 INCH COLLET ASSY	1
11	42999	1/4 INCH COLLET ASSY	1
11	44012	COLLET 12MM	1
12	882185	SCREW MACHINE STEEL	10
13	861434	CORD CLAMP	1
14	330003-64	BALL BEARING	3
15	908573	SWITCH ACTUATOR	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 892 Type 1

Item Number	Part Number	Description	Qty Required
16	908567	COVER	1
17	908587	COVER	1
18	912755	INSULATING SLEE	1
19	912032	WASHER	10
20	911807	RACK	1
21	908596	PIN	10
22	879999	SCREW	10
23	901287	SPINDLE LOCK RETAINE	1
24	803831	BEARING	3
25	875893	COLLET NUT	1
26	903053	CHUCK	1
27	250403	MAGNETIC DISC	1
28	912753	ARMATURE	1
29	A13650	FIELD	1
30	912754	MOTOR HOUSING	1
31	908566	CAP	1
32	803157	SCREW	10
33	A13684	BRUSH & HOLDER ASSY	2
34	912756	SPEED CONTROL	1
35	861737	RING	10
39	910017	SCREW	10
40	893792	SCREW	10
41	912030	WIRE NUT	10
44	800835	PIN	10
45	893728	FAN	1
56	698709	SPRING	10
57	913226	INSULATING TAPE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for 892 Type 1

Item Number	Part Number	Description	Qty Required
58	A20304	KITBOX	1
59	A22709	OPEN-END WRENCH	1
60	75301	R TABLE ACCY KIT	1
61	907007	WRENCH	1
62	A22702	CLAMP	1
64	909866	SPINDLE LOCK ACTUATO	1
65	911800	WEAR PLATE	1
66	911801	INSERT	1
67	911751	ROD	1
68	910601	PLUG	1
69	911802	NUT	10
70	908572	HANDLE	1
71	908577	RING	10
72	911803	SCREW	10
73	908576	KNOB	1
75	911809	SCREW	10
76	810425	PLUG	1
77	911776	SCREW	10
78	911804	RETAINING RING	10
79	911796	SPRING	10
81	911797	LEVER	1
82	911710	DISK	1
83	852554	SCREW	10
84	909239	SUB BASE	1
84	904936	BASE-SUB	1
86	802596	SCREW	10
87	862641	NUT	10

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenetwork.com for current parts information.

Parts List for 892 Type 1

Item Number	Part Number	Description	Qty Required
88	909242	HANDLE ASSY	1
90	910600	WASHER	10
102	912051	KNOB	1
103	890814	WASHER	10
104	887981	TUBE	1
105	889754	SPRING	10
106	844322	BALL	1
107	910745	ROD	1
108	891797	SPRING	10
109	699400	SPRING GUIDE	1
110	893771	LINER	1
112	693953	NUT	10
113	852428	SCREW	10
114	909243	HOUSING	1
114	908926	HOUSING	1
117	911177	SPRING	10
118	911178	LEVER	1
119	699563	SET SCREW	10
120	A02649	BOLT-PLUNGE LOCK	1
120	A02649	BOLT-PLUNGE LOCK	1
121	699552	CLAMP PLUG	1
123	892744	TENSIONER	1
131	000000-00	No Longer Available	1
132	908933	POINTER	1
133	903120	SHAFT	1
134	802417	WASHER	10
135	903114	BUCKLE	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.

Parts List for 892 Type 1

Item Number	Part Number	Description	Qty Required
136	903118	PIN	10
137	903693	NUT	10
138	A00323	WEAR PLATE	1
139	802350	SCREW	10
140	859359	WASHER	10
141	802851	O RING	10
142	888894	SCREW	10
143	890156	KNOB	1
145	911179	KNOB	1
146	911208	DEPTH SCALE	1
148	881290	KNOB	1
160	A22700	BASE HOUSING	1
161	911799	AXLE	1
856	42690	ROUTER EDGE GUIDE	1
856	8911	GRIP VAC FOR 890	1

COPYRIGHT© 2005. All Rights Reserved.

Parts list, pricing, and availability subject to change. Please visit www.dewaltservicenet.com for current parts information.